

# Guidance for Stream Restoration and Rehabilitation

---

Steven E. Yochum



Yochum, Steven E. 2016. **Guidance for Stream Restoration and Rehabilitation**. Technical Note TN-102.2. Fort Collins, CO: U.S. Department of Agriculture, Forest Service, National Stream & Aquatic Ecology Center

**Cover Photos:**

Top-right: Illinois River, North Park, Colorado.

Photo by Steven Yochum

Bottom-left: Whychus Creek, Oregon.

Photo by Paul Powers

## ABSTRACT

---

A great deal of effort has been devoted to developing guidance for stream restoration and rehabilitation. The available resources are diverse, reflecting the wide ranging approaches used and expertise required to develop stream restoration projects. To help practitioners sort through all of this information, a technical note has been developed to provide a guide to the wealth of information available. The document structure is primarily a series of short literature reviews followed by a hyperlinked reference list for the reader to find more information on each topic. The primary topics incorporated into this guidance include general methods, an overview of stream processes and restoration, case studies, and methods for data compilation, preliminary assessments, and field data collection. Analysis methods and tools, and planning and design guidance for specific restoration features, are also provided. This technical note is a bibliographic repository of information available to assist professionals with the process of planning, analyzing, and designing stream restoration and rehabilitation projects.

## ADVISORY NOTE

---

*Techniques and approaches contained in this handbook are not all-inclusive, nor universally applicable. Designing stream restorations and rehabilitations requires appropriate training and experience, especially to identify conditions where various approaches, tools, and techniques are most applicable, as well as their limitations for design. Note also that product names are included only to show type and availability and do not constitute endorsement for their specific use.*

*In accordance with Federal civil rights law and U.S. Department of Agriculture (USDA) civil rights regulations and policies, the USDA, its Agencies, offices, and employees, and institutions participating in or administering USDA programs are prohibited from discriminating based on race, color, national origin, religion, sex, gender identity (including gender expression), sexual orientation, disability, age, marital status, family/parental status, income derived from a public assistance program, political beliefs, or reprisal or retaliation for prior civil rights activity, in any program or activity conducted or funded by USDA (not all bases apply to all programs). Remedies and complaint filing deadlines vary by program or incident.*

*Persons with disabilities who require alternative means of communication for program information (e.g., Braille, large print, audiotape, American Sign Language, etc.) should contact the responsible Agency or USDA's TARGET Center at (202) 720-2600 (voice and TTY) or contact USDA through the Federal Relay Service at (800) 877-8339.*

*To file a program discrimination complaint, complete the USDA Program Discrimination Complaint Form, AD-3027, found online at [http://www.ascr.usda.gov/complaint\\_filing\\_cust.html](http://www.ascr.usda.gov/complaint_filing_cust.html) and at any USDA office or write a letter addressed to USDA and provide in the letter all of the information requested in the form. To request a copy of the complaint form, call (866) 632-9992. Submit your completed form or letter to USDA by: (1) mail: U.S. Department of Agriculture, Office of the Assistant Secretary for Civil Rights, 1400 Independence Avenue, SW, Washington, D.C. 20250-9410; (2) fax: (202) 690-7442; or (3) email: [program.intake@usda.gov](mailto:program.intake@usda.gov).*

*USDA is an equal opportunity provider, employer, and lender.*

## ACKNOWLEDGEMENTS

This technical note was written by Steven Yochum, PhD, PE, Hydrologist, U.S. Forest Service, National Stream and Aquatic Ecology Center. It is updated annually. The original document was published by the USDA Natural Resources Conservation Service, Colorado State Office, with the initial version (Colorado Engineering Tech Note 27.1) released in June 2012.

Peer review of version TN-102.1 of this USFS guidance was performed by Johan Hogervorst, USFS Hydrologist; Robert Tanner, USFS Hydrologist; Paul Powers, USFS Aquatic Biologist; Brady Dodd, USFS Hydrologist; and Robert Gubernick, USFS Geologist.

Peer review of the original NRCS document was performed by Rob Sampson, NRCS State Conservation Engineer; Barry Southerland, NRCS Fluvial Geomorphologist; Brian Bledsoe, CSU Associate Professor of Civil and Environmental Engineering; Terri Sage, NRCS Biologist; and Christine Taliga, NRCS Plant Materials Specialist.

Other individuals have provided comments and clarifications to the document; all of their contributions are highly appreciated. Please email [Steven Yochum](mailto:Steven.Yochum@aphis.usda.gov) with any additional comments or suggestions, for inclusion in the next annual update.

## CONTENTS

ABSTRACT.....	i
ADVISORY NOTE .....	ii
ACKNOWLEDGEMENTS .....	iii
CONTENTS.....	iii
FIGURES .....	iv
TABLES .....	v
INTRODUCTION .....	1
GOALS AND OBJECTIVES .....	2
GENERAL METHODS.....	3
Interdisciplinary Team .....	3
Planning Process .....	3

Watershed Approach .....	4
RIPARIAN MANAGEMENT .....	5
Adaptive Management .....	5
Extent of Design and Review .....	7
OVERVIEW OF STREAM PROCESSES and RESTORATION .....	8
CASE STUDIES .....	10
DATA COMPILATION .....	11
Data Sources.....	11
<i>Water Quantity</i> .....	11
<i>Water Quality and Sediment</i> .....	11
<i>GIS Data and Mapping</i> .....	11
<i>Climate Data</i> .....	12
<i>Vegetative Information</i> .....	12
<i>Literature</i> .....	12
Geographic Information System .....	13
Historical Information .....	13
PRELIMINARY FIELD ASSESSMENT .....	14
Stream Classification.....	17
Stream Channel States and Evolution Models .....	18
Stream Ecological Valuation (SEV).....	21
Basic Assessment Tools .....	21
FIELD DATA COLLECTION .....	22
Topographic Survey Data.....	22
Bankfull Stage Identification.....	23
Discharge Measurements .....	24
Water Quality .....	24
Bed Material Sampling.....	25
Sediment Transport Measurements .....	26
Riparian Vegetation.....	27
Aquatic Organisms .....	28
ANALYSES FOR STREAM RESTORATION and REHABILITATION.....	29
Bankfull Characteristics .....	30
Flow Frequency Estimates .....	31
Natural Channel Design .....	33
River Styles .....	35

Soar and Thorne Restoration Design .....	36	MONITORING and REPORTING .....	71
Hydraulic Modeling Overview .....	37	SUMMARY .....	71
Modeling Tools .....	38	REFERENCES .....	72
<i>Hydraulic Analysis and Aquatic Habitat</i> ..	38	APPENDIX A: Table of Contents for NRCS	
<i>Bank/Bed Stability and Sediment</i> .....	39	Stream Restoration Design, NEH Part 654 .....	85
<i>Environmental Flows</i> .....	39	APPENDIX B: Glossary of Fluvial	
<i>Watershed Modeling</i> .....	40	Geomorphology Terms .....	86
Flow Resistance Estimation .....	41		
<i>General Guidance</i> .....	41		
<i>Low-Gradient Channels</i> .....	41		
<i>Mid-Gradient Channels</i> .....	42		
<i>High-Gradient Channels</i> .....	42		
<i>Floodplains</i> .....	42		
RESTORATION and REHABILITATION			
DESIGN FEATURES .....	43	<b>FIGURES</b>	
Vegetation .....	43	Figure 1: The NRCS planning process .....	3
Livestock Grazing Management .....	46	Figure 2: Project screening matrix .....	7
Large Wood .....	48	Figure 3: Channel diagnostic procedure .....	14
<i>Large Wood Structures</i> .....	49	Figure 4: Lane’s Balance .....	15
Stream Habitat and Environmental Flows ....	51	Figure 5: Levels of stability assessments .....	15
Aquatic Organism Passage .....	54	Figure 6: Montgomery and Buffington	
Fish Screening .....	56	classification system .....	17
Beavers .....	57	Figure 7: Rosgen classification system .....	17
Bank Stabilization .....	59	Figure 8: Channel evolution model, with channel	
<i>Stream Barbs</i> .....	60	cross sections illustrating the 5 channel stages..	18
<i>Vanes</i> .....	61	Figure 9: Various stream succession stages.. ....	19
<i>Bendway Weirs</i> .....	62	Figure 10: Stream evolution model .....	19
<i>Spur Dikes</i> .....	62	Figure 11: Archetypal state-and-transition model	
<i>Bioengineering</i> .....	63	network structures .....	20
<i>Toe Wood</i> .....	64	Figure 12: Differential surveying .....	22
<i>Log Jams</i> .....	65	Figure 13: Survey-grade GPS .....	23
<i>Rock Walls</i> .....	66	Figure 14: Diurnal temperature fluctuations. ....	25
<i>Riprap</i> .....	66	Figure 15: Example bed material particle size	
Bed Stabilization and Stream Diversions .....	67	distribution .....	26
Planform Design .....	69	Figure 16: Bedload trap .....	26
Dam Removal .....	70	Figure 17: Vegetation zones within a riparian	
		cross section .....	27
		Figure 18: Fish sampling .....	28
		Figure 19: Macroinvertebrate sampling	
		equipment .....	28
		Figure 20: Effective discharge computation ....	31
		Figure 21: Flow frequency estimates for the	
		Cache la Poudre River, CO .....	32
		Figure 22: Annual peak discharge trends, with	
		record lengths from 85 - 127 years .....	32
		Figure 23: Schematic illustrating the Natural	
		Channel Design method .....	34
		Figure 24: River Styles framework. ....	35

Figure 25: Soar and Thorne (2001) stream restoration design procedure .....	36
Figure 26: Analytical channel design using the Copeland method (Soar and Thorne 2001).....	38
Figure 27: Computation methodology for $\sigma_z$ ...	42
Figure 28: Channel stability ratings for various vegetative compositions .....	44
Figure 29: The use of a stinger for vegetative plantings.....	44
Figure 30: A grazing management planning process .....	47
Figure 31: Substantial wood loading in a high-gradient stream channel .....	48
Figure 32: Railroad tie drives in the Rocky Mountains resulted in instream wood removal and reduction in channel variability.....	48
Figure 33: Windthrow emulation.....	49
Figure 34: Introduced large wood.....	49
Figure 35: Typical plan view illustrating windthrow emulations orientations.....	49
Figure 36: Complex timber revetment.....	50
Figure 37: Meadow restoration of Whychus Creek, Oregon.....	52
Figure 38: Beaver dam in a previously-incised stream channel .....	52
Figure 39: Culvert outlet drop, with Coho.....	54
Figure 40: Pool and weir fishway.....	55
Figure 41: Fixed, inclined fish screen.....	56
Figure 42: Beaver-dominated stream corridor..	57
Figure 43: Beaver deceiver.....	58
Figure 44: Beaver baffle.....	58
Figure 45: Stream barb.....	60
Figure 46: J-hook vane.....	61
Figure 47: Log vanes at low flow providing bank stabilization and channel narrowing 2 years after construction.....	61
Figure 48: Log J-hook vane providing bank stabilization and pool scour 4 years after construction.....	61
Figure 49: Bendway weir.....	62
Figure 50: Spur dike.....	62
Figure 51: Installation of coir fascines.....	63
Figure 52: Rootwad with footer section.....	63
Figure 53: Toe wood cross section .....	64
Figure 54: Two cells of a toe wood plan view..	64

Figure 55: Log jam.....	65
Figure 56: Vegetated rock wall .....	66
Figure 57: Cross vane on the Rio Blanco, CO ..	67
Figure 58: Large wood grade-control structure.	67
Figure 59: Log “rock and roll” channel in the Trail Creek watershed, Colorado.....	67
Figure 60: Variable descriptions for U-vane stage-discharge rating.....	68
Figure 61: Schematic illustrating variables describing channel planform characteristics .....	69

## TABLES

---

Table 1: Quick reference guide.....	1
Table 2: Riparian practices, with expected riparian ecosystem benefits .....	6
Table 3: Role of primary field indicators for diagnosing channel condition.....	14
Table 4: Possible field indicators of stream instability and stability .....	16
Table 5: Descriptions of stream evolution model (SEM) stages, with comparison to the channel evolution model (CEM) stages presented in Schumm et al. (1984) .....	20
Table 6: Manning’s $n$ in sand-bed channels.....	41
Table 7: Grazing system compatibility with willow-dominated plant communities, as developed by Kovalchik and Elmore (1991).....	46
Table 8: Evaluation and rating of grazing strategies for stream-riparian-related fisheries values, based on observations by Platts (1990).	47

## INTRODUCTION

Nationally, more than \$1 billion is spent each year on stream restoration and rehabilitation projects (Bernhardt et al. 2005). To support this investment, a great deal of effort has been devoted to developing guidance for these projects. These resources are diverse, which reflects the wide ranging approaches used and expertise required in the practice of stream restoration. Substantial guidance is available to assist practitioners with restoration projects, with tens of thousands of pages of relevant material available. The USDA Natural Resources Conservation Service's (NRCS) Stream Restoration Design manual (NRCS 2007) alone consists of more than 1600 pages! With such extensive information available, it can be difficult for professionals to find the most relevant material available for specific projects.

To help practitioners sort through all this information, this technical note has been developed to provide a guide to the guidance. It is a bibliographic repository of information available to assist professionals with the process of planning, analyzing, and designing a stream restoration or rehabilitation project. The document structure is primarily a series of short literature reviews followed by a hyperlinked reference list for the reader to find more information on each topic. Due to the extensive use of hyperlinks, this document is best viewed as an on-screen pdf while connected to the web. Many potentially useful references for stream projects are cited. However, the quantity of the available literature can be intimidating, even when only summarized. Prudent use of the table of contents can help minimize the potential for being overwhelmed. Additionally, Table 1 provides a quick reference guide for common technical needs.

This document is not intended to be a philosophical framework for restoration design; that effort is left to other references. Additionally, this guidance is not limited to only what are currently considered restoration-focused practices. Rehabilitation features are also included, to provide a more comprehensive resource. Restoration is the reestablishment of the structure and function of ecosystems to an approximation of

pre-disturbance conditions while rehabilitation establishes conditions to support natural processes for making the land useful for human purposes (NRCS 2007). Taking the approach of restoration or rehabilitation is decided at the project inception, as goals and objectives are defined.

**Table 1:** Quick reference guide.

Technical Need	Page
Define goals and objectives	2
General methods for developing alternative restoration strategies	3
Overview of stream system processes and restoration practices	8
Learn from past restoration projects, through case studies	10
Resources for collecting existing background data	11
What should be considered when evaluating condition? What initial assessment tools can be applied?	14
What are stream channel states and evolution models?	18
Methods for field data collection (surveying, discharge, water quality, sediment, vegetation, aquatic life)	22
How is bankfull stage determined?	23
What analyses are performed for stream restoration and rehabilitation designs?	29
How are flow-frequency estimates developed?	31
What is the Natural Channel Design method?	33
What is the River Styles method?	35
What hydraulic modeling tools can be utilized?	37
How is flow resistance estimated?	41
What practices are used in restoration?	43
How important is vegetation in restoration?	43
Livestock grazing management	46
Need for and installation of large wood	48
Stream habitat and environmental flows	51
Designing for fish passage	54
Fish Screening	56
What are the roles of beavers?	57
Structures for bank stabilization	59
Bed stabilization and stream diversions	67
Dam removal	70
Index to NEH Part 654	84
Glossary of restoration-related terms	86

This document is organized in the typical sequence for assessing, analyzing, and designing stream restoration and rehabilitation projects. Additionally, appendices provide an index for the NRCS Stream Restoration Design manual (National Engineering Handbook, Part 654: NRCS 2007), and a glossary of fluvial geomorphology terms.

## GOALS AND OBJECTIVES

One of the most important steps in a stream restoration or rehabilitation project is the determination of project goals and objectives. Goals are general and are highly dependent upon context, while objectives are measurable and in support of the stated goals. Once established, goals need to be clarified through objectives that describe how the goals will be attained. Objectives need to be specific, realistic, achievable and measurable (NRCS 2007, Ch. 2). The perceived success or failure of a project is dependent upon thoughtful and consensus-based development of goals and objectives by the stakeholders and technical specialists. The social context of the restoration should be accounted for – the successful implementation of restoration is dependent upon acceptance by those who live with the stream and its floodplain (Wohl et al. 2015).

As an example, in a habitat enhancement for native cutthroat trout where excessive peak summertime temperatures is the primary impairment, a goal of increasing fish abundance needs to be clarified with such objectives as decreasing the channel width/depth ratio, increasing pool depth and frequency, and increasing shade and terrestrial food input to the stream through revegetation of channel banks and riparian zone.

Project goals and objectives often considered in stream corridor restoration and rehabilitation projects include:

- Prevent streambank erosion, to protect properties and infrastructure
- Provide habitat enhancement for native or sport fishes, to increase abundance and age class diversity
- Restore hydrologic function, including dynamic channel processes

- Establish a multi-thread channel and companion riparian meadow, from an incised or channelized reach
- Slow the procession of headcutting in a watershed, to protect upland areas and infrastructure, and to reduce sediment delivery to downstream reaches
- Reduce rates of lateral migration of channel meandering
- Narrow an overly-wide channel, decreasing the width/depth ratio of the stream
- Improve water quality, such as excessive temperature, nutrients, sediment, salts, and metals
- Remove non-native riparian vegetation, replacing with more desirable species
- Reestablish a sinuous channel, from a straight or braided form
- Establish stream reaches capable of transporting sediment supply
- Provide compliance with Endangered Species Act and Clean Water Act requirements

During the planning and design processes, the attributes of the project must be assessed to assure that the project objectives are being fully satisfied. Often, individual objectives are in conflict and need to be prioritized to best meet the project goals. After construction, monitoring should be performed to assess if the project is fulfilling the goals and objectives. If not, project remediation may be needed through the process of adaptive management. In any case, documentation of project performance needs to be maintained, for communication with stakeholders and adding to the knowledge base of the individual professional and the restoration community as a whole.

Additional information for establishing objectives for stream projects can be found in:

- [NRCS 2007, Ch. 2](#) Goals, Objectives and Risk
- [Fischenich 2006](#) Functional Objectives for Stream Restoration

## GENERAL METHODS

General methods are provided for stream corridor improvement projects. Topics covered include the assembly of an appropriate interdisciplinary team, the planning process, the watershed approach to restoration, an overview of riparian management, adaptive management, and the extent of design and review.

### Interdisciplinary Team

Stream corridor restoration and rehabilitation projects are inherently complicated. In most projects, no single individual has all the required skills to effectively perform a restoration; an interdisciplinary team is required. Needed expertise varies by project and may include engineering, hydrology, fluvial geomorphology, soil science, restoration ecology, botany, and aquatic biology. However, the team should be no larger than required, to reduce inefficiencies resulting from an excessive number of specialists being involved in a project.

## Planning Process

Stream corridor restoration and rehabilitation projects need a plan to develop a logical sequence of steps to satisfy the project objectives. The NRCS conservation planning process (Figure 1) is one example of a generally-accepted planning process. The method consists of nine steps that focus the planning team on the overall system, to determine the cause of the problem, formulate alternatives, and evaluate the effects of each alternative on the overall stream system (NRCS 2007, Ch2). These steps are not necessarily linear; the steps may need to be cycled through iteratively to develop the best set of alternative solutions to a given problem, and ultimately select and implement a certain set of practices. The nine steps are as follows:

1. **Identify problems and opportunities:** What stream characteristics should be changed? Is the noted condition actually a problem?




Figure 1: The NRCS planning process (NRCS 2007, Ch. 2).

2. **Determine overall goals and specific objectives:** What are the desired physical, chemical and biological changes?
3. **Inventory resources:** Study the stream to understand the dominant physical processes, impacts on water quality, and abundance and distribution of biological populations.
4. **Analyze resource data:** Evaluate the collected information and decide what processes most influence the desired stream condition.
5. **Formulate alternatives:** Determine which processes can be changed. Include a no action option.
6. **Evaluate alternatives:** Which alternatives are sustainable, cost effective, and best meet stated goals and objectives?
7. **Make decisions:** Develop a consensus-based decision by the stakeholders and interdisciplinary team regarding which alternative to implement.
8. **Implement the plan**
9. **Evaluate the plan:** Perform post project monitoring, to assess performance and revise practices.

Complimentary to this, standards for ecologically successful river restoration projects have been developed. It has been proposed (Palmer et al. 2005) that five criteria essential for measuring project success are:

1. A dynamic ecological endpoint is initially identified and used to guide the restoration.
2. The ecological conditions of the stream are measurably improved.
3. Through the use of natural fluvial and ecological processes, the restored stream must be more self-sustaining and resilient to perturbations than pre-restoration conditions, so that minimal maintenance is needed.
4. The implementation of the restoration does not inflict lasting harm.
5. Pre- and post-project assessments are completed and the data are made publically available so that the restoration community as a whole can benefit from knowledge learned.

## Watershed Approach

While technical assistance is typically requested to address local concerns, a watershed approach is often needed to address potential underlying mechanisms causing the impairments. An understanding of these mechanisms is necessary to develop an effective response. Unless the underlying causes of the degraded condition are addressed, restoration or rehabilitation may not be the wisest investment.

Relevant questions to address include:

- How has land use changed throughout the watershed? What are the results of these disturbances? Impacts to consider include:
  - fires
  - invasive species
  - beetle-killed forests
  - urbanization
  - roads
  - livestock grazing
  - logging activities
- How are flow diversions impacting the aquatic habitat, and stream form and function?
- Is flow augmentation from trans-basin diversions causing channel destabilization?
- Are there substantial water storage projects in the watershed? If so, how have these projects affected the magnitude, frequency, duration, timing and rate of change of flow (Poff et al. 1997)? What are the ecologic and geomorphic impacts of the water storage projects?
- Are there a substantial number of irrigation diversion weirs or culverts in the watershed that block aquatic organism passage? If so, does this relate to the project objectives?
- Do the riparian zones of the watershed have extensive populations of invasive species, such as Salt Cedar (*Tamarix spp.*) or Russian Olive (*Elaeagnus angustifolia*)? What are the ramifications?
- Are landslides or debris flows common in the watershed? Is the stream capable of transporting this material? What are the geomorphic ramifications of these disturbances?

- Is there active headcutting in the watershed? If so, does this headcutting relate to the local issues that prompted the request for technical assistance?
- Are there historic or current mining activities in the watershed? How have these activities impacted water quality?
- Have changed watershed conditions impacted water and sediment regimes to the point where the stream is in a state of flux or out of its dynamic equilibrium.

## **RIPARIAN MANAGEMENT**

---

Effective riparian management is fundamental for supporting proper stream corridor function, to develop a fully functioning stream system. A summary providing a scientific assessment of the effectiveness of riparian management practices was provided by George et al. (2011), as a part of a synthesis on the conservation benefits of rangeland practices ([Briske 2011](#)). This summary report provides a helpful evaluation of 20 management tools (Table 2), evaluating their value through a review of the peer-reviewed literature.

Engineered restoration or rehabilitation is often not needed to fulfill stakeholders objectives, with livestock management being all that is required in some situations. In other situations, riparian management is used in combination with engineered practices to satisfy project objectives in the desired timeframe. In some of the most disturbed stream systems, where channelization or incision has occurred and water surface elevations and groundwater table elevations have been substantially reduced, resulting in the shifting of former floodplain plant communities to upland terrace species, more intensive restoration may be needed to raise the channel back to the pre-disturbance elevations and restore meadow function.

In the initial stages of a project a “no action” option needs to be considered, then a management-only approach should be considered for its ability to satisfy the project objectives in the desired timeframe. If these more passive alternatives do not satisfy project objectives, then more complex engineered solutions should then be considered.

A list of 20 riparian conservation practices and their expected ecosystem benefits are provided (Table 2). Additionally, watershed condition can result in direct impacts to stream condition. For example, a severe fire in a watershed will lead to a large increase in sediment availability and mobilization, with various morphological and ecological consequences. Upland watershed management also needs to be considered in a restoration design.

## **Adaptive Management**

---

Due to the complexity involved in restoring degraded stream systems and the frequent lack of suitable reference sites that describe unimpaired conditions, the process of adaptive management can be an essential method for developing the most effective projects. With adaptive management, uncertainty in the effectiveness of restoration approaches, due to limited understanding of mechanisms, is mitigated through “learning by doing and adapting based on what’s learned” (William and Brown 2012). More information on adaptive management is provided in:

- [Bouwes et al. 2016](#) Adapting Adaptive Management for Testing the Effectiveness of Stream Restoration: An Intensely Monitored Watershed Example
- [Williams and Brown 2012](#) Adaptive Management: The U.S. Department of the Interior Applications Guide
- [Ryan and Calhoun 2010](#) Riparian adaptive management symposium: a conversation between scientists and management

**Table 2:** Riparian practices, with expected riparian ecosystem benefits (adapted from George et al. 2011).

Practice name	Code	Ecosystem services				
		Wildlife habitat	Water quality and quantity	Stable stream banks and soils	Carbon storage	Diverse plant and animal communities
Animal trails and walkways (feet)	575		X	X		
Brush management (acres)	314	X	X	X		X
Channel bank vegetation (acres)	322	X	X	X		
Conservation cover (acres)	327	X	X	X		
Critical area planting (acres)	342			X		
Fence (feet)	382	X	X	X		X
Filter strip (acres)	393		X			
Pest management (acres)	595	X	X			
Prescribed burning (acres)	338	X				X
Prescribed grazing (acres)	528	X	X	X		X
Range planting (acres)	550	X	X	X	X	X
Riparian forest buffer (acres)	391	X	X	X	X	X
Riparian herbaceous cover (acres)	390	X	X	X	X	X
Stream crossing	578		X	X	X	
Stream habitat improvement and management (acres)	395	X	X	X		
Stream bank and shoreline protection (feet)	580	X		X		
Tree/shrub establishment (acres)	612	X	X	X	X	X
Upland wildlife habitat management (acres)	645	X				
Use exclusion (acres)	472		X	X		X
Watering facility (no.)	614		X	X		

## Extent of Design and Review

To help assess the appropriate level of design and review for a specific project, Skidmore et al. (2011) developed a project screening matrix (Figure 2) based on the underlying principle of doing no lasting harm to aquatic habitat. Factors addressed in this matrix include project scale, physical attributes of the restoration, planned monitoring, bed and bank composition, bed scour risk, and the dominant hydrologic regime. The

appropriate level of assessment is needed to balance project risk with design and review expenses.

To assist with project review, [River RAT](#) (River Restoration Analysis Tool) was developed by the NOAA National Marine Fisheries Service to walk reviewers through key questions that help assess if fundamental considerations have been addressed in a project.




Figure 2: Project screening matrix (Skidmore et al. 2011).

## OVERVIEW OF STREAM PROCESSES and RESTORATION

---

There are a wide variety of approaches implemented in stream projects, with this variety a function of the goals and objectives, setting (urban vs. rural, private vs. public lands), and funding opportunities. Some practitioners focus on hard structures, constructed of concrete and quarried rock, while others prefer natural materials though also select practices that tend to fix the *form* of streams in place with respect to their longitudinal profile, plan pattern, and cross sectional dimension. Other practitioners, oftentimes in different settings that allow greater latitude, take the approach of restoring natural stream *function* and allow a greater degree of dynamic channel development over time.

Reflecting this variety of approaches to stream work and restoration, there are numerous and, in some ways, conflicting references available that provide summaries and details of stream processes, threats, and restoration practices. This technical note does not provide a critique of the various techniques and schools of thought on the subject but rather provides various perspectives for the users to educate themselves for their specific projects. Examples of these references include:

- [EPA 2015](#) Connectivity of Streams & Wetlands to Downstream Waters: A Review & Synthesis of the Scientific Evidence
- [Wohl et al. 2015](#) The Science and Practice of River Restoration
- [Niezgoda et al. 2014](#) Defining a Stream Restoration Body of Knowledge as a Basis for National Certification
- [Poff et al. 2012](#) Threats to Western United States Riparian Ecosystems: A Bibliography
- [Cramer 2012](#) Washington State Stream Habitat Restoration Guidelines
- [Weber and Fripp 2012](#) Understanding Fluvial Systems: Wetlands, Streams, and Flood Plains
- [Simon et al. 2011](#) Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools
- [Skidmore et al. 2011](#) Science Base and Tools for Evaluating Stream Engineering, Management, and Restoration Proposals
- [KIESD 2011](#) Stream Restoration. Sustain: A Journal of Environmental and Sustainability Issues, Kentucky Institute for the Environment and Sustainable Development
- [Wohl 2011](#) Mountain Rivers Revisited
- [Burton et al. 2011](#) Multiple Indicator Monitoring of Stream Channels and Streamside Vegetation
- [James et al. 2009](#) Management and Restoration of Fluvial Systems with Broad Historical Changes and Human Impacts
- [Helfman 2007](#) Fish Conservation
- [NRCS 2007](#) Stream Restoration Design
- [Conyngham et al. 2006](#) Engineering and Ecological Aspects of Dam Removal: An Overview
- [Wohl et al. 2006](#) River Restoration in the Context of Natural Variability (in USFS StreamNotes)
- [Kershner et al. 2004](#) Guide to Effective Monitoring of Aquatic and Riparian Resources
- [Doll et al. 2003](#) Stream Restoration: A Natural Channel Design Handbook
- Julien 2002 River Mechanics
- [Copeland et al. 2001](#) Hydraulic Design of Stream Restoration Projects
- [Richardson et al. 2001](#) River Engineering for Highway Encroachments
- [Soar and Thorne 2001](#) Channel Restoration Design for Meandering Rivers
- [Fischenich 2001a](#) Impacts of Stabilization Measures
- [Fischenich 2001b](#) Stability Thresholds for Stream Restoration Materials
- [Fischenich & Marrow 2000](#) Reconnection of Floodplains with Incised Channels
- Knighton 1998 Fluvial Forms and Processes: A New Perspective
- [FISRWG 1998](#) Stream Corridor Restoration: Principles, Processes and Practices
- [Biedenham et al. 1997](#) The Waterways Experiment Station Stream Investigation and Streambank Stabilization Handbook
- [Rosgen 1996](#) Applied River Morphology
- Leopold, L.B. 1994 A View of the River

- [Maser and Sedell 1994](#) From the Forest to the Sea: The Ecology of Wood in Streams, Rivers, Estuaries, and Oceans
- Leopold et al. 1964 Fluvial Processes in Geomorphology

Additionally, the following webinars, tutorials and videos on hydrology, geomorphology, and restoration can be helpful for understanding relevant processes:

- [Stream Channel Repair and Restoration Following Extreme Flooding Damage, Part 1: Background and Planning](#) 2015 (Kip Yasumiishi, Barry Southerland, Dan Moore, Larry Johnson)
- [Lessons Learned from Natural Stream Restoration/Enhancement: Insight on Natural Channel Design](#) 2013 (Dick Everhart, Angela Greene)
- [Undamming the Elwha](#) The Documentary, 2012 (Katie Campbell and Michael Werner)
- [Runoff Generation in Forested Watersheds](#) 2004 (Jeff McDonnell)
- [Dividing the Waters](#) Rethinking Management in a Water-Short World, 2004 (Sandra Postel)
- [The Geomorphic Response of Rivers to Dam Removal](#) 2004 (Gordon Grant)

## CASE STUDIES

---

Case studies can be valuable for understanding lessons learned from previous projects and to provide ideas for projects currently being planned. Case studies illustrate both perceived successes and partial failures, illustrating approaches and pitfalls. References that provide case studies are provided below. Additionally, a variety of case studies are provided in NRCS (2007), with a list of topics presented in appendix A.

- [Bouwes et al. 2016](#) Adapting Adaptive Management for Testing the Effectiveness of Stream Restoration: An Intensely Monitored Watershed Example
- [Pollock et al. 2015](#) The Beaver Restoration Guidebook: Working with Beaver to Restore Streams, Wetlands, and Floodplains
- [Powers 2015](#) Case Study: Restoration of the Camp Polk Meadow Preserve on Whychus Creek
- [East et al. 2015](#) Large-Scale Dam Removal on the Elwha River, Washington, USA: River Channel and Floodplain Geomorphic Change
- [RiverWiki](#) Tool for sharing case studies and best practices for river restoration in Europe
- [Powers 2015](#) Restoration of the Camp Polk Meadow Preserve on Whychus Creek
- [Buchanan et al. 2013](#) Long-Term Monitoring and Assessment of a Stream Restoration Project in Central New York
- [Collins et al. 2013](#) The Effectiveness of Riparian Restoration on Water Quality – A Case Study of Lowland Streams in Canterbury, New Zealand
- [Pierce et al. 2013](#) Response of Wild Trout to Stream Restoration over Two Decades in the Blackfoot River Basin, Montana
- [Ernst et al. 2012](#) Natural-Channel-Design Restorations that Changed Geomorphology Have Little Effect on Macroinvertebrate Communities in Headwater Streams
- [MacWilliams et al. 2010](#) Assessment of the Effectiveness of a Constructed Compound Channel River Restoration Project on an Incised Stream
- [Major et al. 2012](#) Geomorphic Response of the Sandy River, Oregon, to Removal of Marmot Dam
- [Walter et al. 2012](#) Assessment of Stream Restoration: Sources of Variation in Macroinvertebrate Recovery throughout an 11-Year Study of Coal Mine Drainage Treatment
- [Schiff et al. 2011](#) Evaluating Stream Restoration: A Case Study from Two Partially Developed 4th Order Connecticut, U.S.A. Streams and Evaluation Monitoring Strategies
- [Sustain 24, Spring/Summer 2011](#) Stream Restoration
- [Chin et al. 2009](#) Linking Theory and Practice for Restoration of Step-pool Streams
- [Levell and Chang 2008](#) Monitoring The Channel Process of a Stream Restoration Project in an Urbanizing Watershed – A Case Study of Kelley Creek, Oregon, USA
- [Baldigo et al. 2008](#) Response of Fish Populations to Natural Channel Design Restoration in Streams of the Catskill Mountains, New York
- [Doyle et al. 2007](#) Developing Monitoring Plans for Structure Placement in the Aquatic Environment: Recommended Report Format, Listing of Methods and Procedures, and Monitoring Project Case Studies
- [Alexander and Allen 2007](#) Ecological Success in Stream Restoration: Case Studies from the Midwestern United States
- [Niezgoda and Johnson 2007](#) Case Study in Cost-Based Risk Assessment for Selecting Stream Restoration Design Method for a Channel Relocation Project
- [Thompson 2002](#) Long-Term Effect of Instream Habitat-Improvement Structures on Channel Morphology Along the Blackledge and Salmon Rivers, Connecticut, USA
- [Purcell et al. 2002](#) An Assessment of a Small Urban Stream Restoration Project in Northern California
- [Piper et al. 2001](#) Bioengineering as a Tool for Restoring Ecological Integrity to the Carson River
- [Smith et al. 2000](#) Breaching a Small Irrigation Dam in Oregon: A Case History

## DATA COMPILATION

---

To develop sufficient understanding of the stream reach of interest, it is necessary to collect existing available data. Helpful data that can be used to assess current condition include streamflow, snowpack, water diversion, and water quality data, flow frequency estimates, biologic inventories, soils information, aerial imagery, and elevation data (including LiDAR). A Geographic Information System (GIS) is typically the most appropriate method for viewing and analyzing spatial data.

### Data Sources

---

Multiple federal and state agencies collect and distribute data that are relevant for stream restoration and rehabilitation projects. National and regional data sources that can be helpful include the following:

#### Water Quantity

---

- [USGS water data](#): real-time and historical streamgauge information, from the U.S. Geological Survey
- [USGS StreamStats](#): watershed and stream statistics, including approximate flow frequency values, mean flows and minimum flows for ungaged streams
- [USGS station statistics](#): Historic and current USGS streamgauge information
- [BOR water data](#): water data in the Pacific Northwest, from the Bureau of Reclamation
- [FEMA floodplain mapping](#): 100-year flood inundation boundaries, from the Federal Emergency Management Agency

#### Water Quality and Sediment

---

- [USGS water quality data](#): real-time field parameter data, such as temperature, conductivity, and pH, as well as historical data for many constituents
- [NorWeST Stream Temp](#): stream temperature data and geospatial map outputs from a regional temperature model for the Northwest United States

- [BYU Sediment Transport Database](#): A database of more than 15,000 sediment transport observations from nearly 500 datasets
- [USGS SPARROW Decision Support Systems](#): map based water-quality results from SPAtially-Referenced Regression on Watershed attributes modeling
- [EPA STORET](#): repository for water quality, biological, and physical data. Hosted by the Environmental Protection Agency
- [WARP Watershed Regressions for Pesticides](#): USGS pesticide mapping tool that estimates pesticide concentrations and the percentage chance of exceeding water-quality guidelines
- [USDA STEWARDS](#): Water-quality data from the Agricultural Research Service
- [NAL WQIC](#): National Agricultural Library Water Quality Information Center, for agricultural-related water quality information

#### GIS Data and Mapping

---

- [Forest Service GeoData Clearinghouse](#): Spatial data collected and managed by Forest Service programs
- [NRCS Geospatial Data Gateway](#): GIS data, such as ortho imagery, topographic images and hydrologic unit boundaries
- [USFS Geospatial Service and Technology Center](#): provides the Forest Service with a range of geographic information products and related technical and training services
- [ArcGIS online imagery](#): High-resolution aerial imagery (oftentimes 30 cm) to use as GIS basemap. Enter “imagery” in search field for ArcGIS online and select “World Imagery”
- [National Map](#): Visualize, inspect and download topographic base data, elevation data, orthoimagery, landcover, hydrography, and other GIS products (USGS)
- [EarthExplorer](#): USGS historic aerial photography archive

- [NHAAP Stream Classification Tool](#): A classification tool for generalizing the physical and biological settings of streams, from the National Hydropower Asset Assessment Program
- [FSA Aerial Photography Field Office](#): historic aerial imagery from the USDA Farm Service Agency
- [USFS Watershed Condition](#): watershed condition class and prioritization information of U.S. Forest Service managed lands
- [National Hydrography Dataset](#): Digital vectorized dataset of such features as such as lakes, ponds, streams, rivers, canals, dams and streamgages
- [EPA ECHO](#): Enforcement and Compliance History, from the Environmental Protection Agency
- [NRCS Web Soil Survey](#): soil data and information
- [SoilWeb](#): Smart phone app. providing GPS-based access to NRCS soil data
- [National Wetland Inventory](#): Wetlands and deepwater habitats, from the U.S. Fish and Wildlife Service

### Climate Data

- [National Climatic Data Center](#): climate data, from the National Oceanic and Atmospheric Administration (NOAA)
- [NOAA HDSC Precipitation Frequency](#): precipitation-frequency data, from the National Oceanic and Atmospheric Administration, National Hydrometeorological Design Studies Center
- [PRISM climate mapping system](#): Parameter-elevation Regressions on Independent Slopes Model. Precipitation product available from NRCS Geospatial Data Gateway
- [SNOTEL](#): NRCS SNOwpack TELemetry
- [CoCoRaHS](#): Community Collaborative Rain, Hail and Snow Network, high-resolution volunteer-collected precipitation data

### Vegetative Information

- [USNVC](#) U.S. National Vegetation Classification: A central organizing framework for documentation, inventory, monitoring, and study of vegetation on scales ranging from forests to plant communities.
- [GAP Land Cover Data Portal](#): national land cover data, from the National Gap Analysis Program (USGS)
- [PLANTS Database](#): standardized information about vascular plants, mosses, liverworts, hornworts, and lichens of the U.S. and its territories (NRCS)
- [Ecological Site Information System](#): Repository for ecological site descriptions and information associated with the collection of forestland and rangeland plot data (NRCS)
- [Plant Materials Program](#): application-oriented plant material technology (NRCS)
- [Tamarisk Coalition](#): education and technical assistance for the restoration of riparian lands

### Literature

- Websites for discovering published texts and journal articles relevant for a restoration project:
  - [Google Scholar](#)
  - [Google](#)
  - [National Forest Service Library](#) (internal USFS only)
  - [USFS Treesearch](#)
  - [Water Resources Abstracts](#)
  - [USGS Publications Warehouse](#)
  - [Science.gov](#)
  - [Web of Knowledge](#)
- [DigiTop](#): USDA access to journal articles from principle publishers
- [Scholarly Open Access](#): Critical analysis of scholarly open access publishing (since all journals are not created equal)

## Geographic Information System

A Geographic Information System (GIS) is the most effective method for organizing spatial data, with the overlying layers facilitating the use of a watershed approach to planning and design. Viewing data spatially helps understand context for particular stream reaches. Hence, GIS provides a powerful tool for analyzing stream systems and developing stream restoration and rehabilitation designs. Fundamental data that are useful for all projects include orthographic aerial imagery, topographic imagery (USGS topographic maps), watershed boundaries, diversion location data, and gridded elevation data. Inspection of multiple years of aerial imagery, including historical imagery, can provide a great deal of assistance in understanding dominant mechanisms causing the deficiency in question. However, the temptation to use only spatially-referenced data should be resisted, since information that could otherwise be valuable for understanding a system may be discarded.

## Historical Information

Historical information (historic analogs) can be an important tool for understanding the anthropogenic impacts and the historical range of variability of streams (Wohl 2011), to provide guidance for the potential condition. Such information can be invaluable for identifying reasonable goals and objectives for a restoration or rehabilitation. Key questions that should be asked regarding a plan or design, with respect to historical information, are:

- Does the plan allow or promote the historic condition?
- Have the elements that led to degradation been alleviated?

Methods for the use of historic information in design is provided in [NRCS \(2007\), TS2](#). Potentially-useful historic information includes:

- Contemporary descriptions
- Climatic records
- Land use records and historic maps
- Land surveys
- Historic aerial photography (see GIS Data and Mapping section)
- Ecological site descriptions
- Ground-based oblique photography

Where channels have been substantially modified, field evidence can be evident of the prior condition, including abandoned channels, relic terraces, soil and vegetative patterns, old infrastructure, etc....


However, since historical information often do not provide information on trends, but merely a snapshot in time, such information should be used with caution. This is analogous to the care needed when using reference reaches (spatial analogs), since such information alone does not show disturbance history.

## PRELIMINARY FIELD ASSESSMENT

The preliminary field assessment is a highly-valuable step in diagnosing stream impairments and their root causes. When combined with information obtained from the initial data compilation, the preliminary field assessment allows qualified practitioners to assess condition and develop hypotheses regarding causes and potential mitigation measures. Before initiating a potentially intensive and expensive field data collection effort, a preliminary field-based assessment is necessary to develop initial insights into key impairments and their root causes. This stage of a project serves as a decision point for the technical specialists and stakeholders on if it is desired to proceed with the project and what general approach may be best for the situation.

Considering that particular indicators or measurements of stream channel condition mean different things for different context and histories, a *diagnostic approach* to stream assessment and monitoring (Figure 3), similar to what is used in medical practice, has been suggested by Montgomery and MacDonald (2002) as an advisable approach to stream assessment and restoration monitoring design. The preliminary field assessment is an essential part of such a diagnostic approach.


Such a diagnostic approach requires practitioners with both appropriate training and experience, a team sufficiently diverse in expertise to sufficiently understand the system, and professionals with the ability to analyze the system independent of bias. Additionally, the overall riparian condition frequently needs to be assessed for a restoration project, rather than just the channel.



**Figure 3:** Channel diagnostic procedure (adapted from Montgomery and MacDonald 2002).

**Table 3:** Role of primary field indicators for diagnosing channel condition (adapted from Montgomery and MacDonald 2002).

Field Indicator	Role
<b>Valley Bottom Characteristics</b>	
Slope	Primary control on channel type and energy dissipation mechanism
Confinement	Primary control on possible planform channel patterns
Entrenchment	Indicates longer-term balance (or lack of) between runoff and sediment loads, and likely range of responses to high flows
Riparian Vegetation	Primary control on channel characteristics
Overbank Deposits	Indicates type and magnitude of recent deposits
<b>Active Channel Characteristics</b>	
Channel Pattern	Braided channels imply high sediment loads, non-cohesive banks, or steep slopes. Well vegetated multithread channels can indicate a minimally-disturbed channel and are often associated with large floods.
Bank Conditions	Location and extent of eroding banks relative to stream type can indicate recent disturbance.
Gravel Bars	Number, location, extent, and condition related to sediment supply.
Pool Characteristics	Distribution and amount of fine sediment deposition can indicate role of flow obstructions and whether sediment loads are high for a given channel type.
Bed Material	Size and distribution of surface and subsurface bed material can indicate relative balance between recent discharge and sediment supply.




**Figure 4:** Lane’s Balance (NRCS 2007, TS3C).

Potential impairments to consider when initially evaluating an impaired stream are wide ranging, including: excessive bank erosion; channel straitening and incision; channel modification from 3multi-thread to single-thread form; discharge modification by reservoir regulation, streamflow diversions, and urbanization; water quality impairments, from historic or current mining, agricultural operations, industry, septic systems (etc.); lack of geomorphic complexity, such as deep pools, width and bank variations, and large instream wood; insufficient riparian vegetation, for bank stabilization, cover, shading, and energy input to streams; and excessive fine sediment.

For understanding how basic variables of stream channel form and discharge relate to each other, Lane’s balance (Figure 4) can be helpful. It illustrates how sediment discharge ( $Q_s$ ) and median size ( $D_{50}$ ) relate to flow discharge ( $Q_w$  or  $Q$ ) and the channel slope ( $S$ ). Channel aggradation and degradation respond to shifts in the four variables, with increased discharge and slope, the product of which is representative of stream power ( $\Omega = \gamma QS$ , where  $\gamma$  is the specific weight of water), typically results in channel degradation until increases in sediment conveyance and sediment size balance the increased stream power. With decreased discharge and slope (decreased stream power), aggradation occurs, with decreased sediment transport and material size. Variation in

Lane’s balance and stream power correspond with variation between erosional-, transport- and depositional-dominated stream reaches.

Field indicators can be evaluated for evidence of channel degradation, aggradation, or stability (Table 4), as a part of a stability assessment for a stream reach (Figure 5). Importantly, stability may not be the goal; instead, effective stream function for maximizing ecological conditions may be the goal, depending upon local site conditions.



**Figure 5:** Levels of stability assessments (Copeland et al. 2001).

Certain issues can lead to fundamental alteration and destabilization of stream systems, with resulting negative consequences to infrastructure and riparian ecosystems. Specifically, *channel straightening* often results in incision, bank instability, lowering of groundwater tables, and shifts in valley-bottom plant communities; *discharge modification* can lead to aggradation, incision, bank instability, and aquatic life impairments through shifts in the flow regime; and *insufficient bank vegetation and large instream wood* can result in bank destabilization, channel widening, increased water temperatures (impairing cold-water fish species), reduced longitudinal profile variability (including frequency and depth of pools), reduced flow resistance, and channel incision. These situations need to be noted in the preliminary field assessment of riparian corridors.

**Table 4:** Possible field indicators of stream instability and stability (adapted from NRCS 2007, Ch3).

**evidence of degradation**

perched tributaries  
 headcuts and nickpoints  
 terraces  
 exposed pipe crossings  
 perched culvert outfalls  
 undercut bridge piers  
 exposed tree roots  
 early-seral vegetation colonization  
 hydrophytic vegetation high on bank  
 narrow and deep channel  
 diversion points have been moved upstream  
 failed revetments due to undercutting

**evidence of aggradation**

buried culverts and outfalls  
 reduced bridge clearance  
 uniform sediment deposition across channel  
 tributary outlets buried in sediment  
 buried vegetation  
 channel bed above the floodplain elevation  
 significant tributary backwater effects  
 hydrophobic vegetation low on bank or dead  
 in floodplain

**evidence of stability**

vegetated bars and banks  
 limited bank erosion  
 older bridges and culverts with at-grade  
 bottom elevations  
 mouth of tributaries at or near mainstem  
 stream grade  
 no exposed pipeline crossings or bridge footings

The initial field assessment should hypothesize about a few key points, specifically:

- What are the dominant fluvial processes in the stream system?
- Is there a problem? If so, is it anthropogenic? Is the issue within the historical range of variability of the stream system?
- What are the factors contributing to the problem? What are potential mitigation strategies?
- What [stream channel state](#) best meets the needs of the reach and watershed, from both ecological and human needs perspectives?

To assist with the preliminary assessment, tools have been developed to assist practitioners in performing basic assessments of riparian areas. An overview is provided in:

- [NRCS 2007, TS3A](#): Stream Corridor Inventory and Assessment Techniques.

## Stream Classification

Stream classification systems are important tools for communication between practitioners through use of a common vocabulary that is based upon the geomorphic condition. Two of the most common approaches for lower-order streams are the Montgomery and Buffington (1997) and Rosgen (1994, 1996) systems. The River Styles Framework (Fryirs and Brierley 2013) provides another classification method. There has been debate and criticism about some classification systems being based on an assessment of form, rather than a quantification of processes. A comparative assessment performed in the Middle Fork John Day River watershed, in the Columbia

River basin, indicates that such criticism may be overstated (Kasprak et al. 2016).

The Montgomery and Buffington system (Figure 6) was developed for mountainous drainage basins, with eight reach-level channel types that directly relate to dominant geomorphic processes and sediment transport regime. The Rosgen stream classification system (Figure 7) is based upon the geomorphic characteristics of entrenchment, width/depth ratio, sinuosity, bed material, and channel slope. For a more in depth description of the Rosgen classification system, including a summary of the associated geomorphic valley types, see [NRCS \(2007\), TS3E](#).




Figure 6: Montgomery and Buffington classification system (NRCS 2007, Ch3).




Figure 7: Rosgen classification system (NRCS 2007, Ch3).

## Stream Channel States and Evolution Models


Stream channel states are different forms that generally occur in response to variations in flow, sediment, and vegetation. These variations are in response to perturbations, such as large floods, wildfires, excessive livestock grazing, loss of large in-channel wood, stream channelization, etc. An early example of the application of channel states in fluvial geomorphology is the channel evolution model.

The *channel evolution model* (Schumm et al. 1984), is a powerful tool for understanding the dynamics of stream disturbance and recovery processes. The method describes the movement of a channel disturbance, such as a headcut, through a channel reach and the consequential evolution of the channel over time and space (Figure 8), providing an evaluation of longitudinal response and restoration potential. At a specific location the channel evolves from an initial stable state (stage 1) through incision (stage 2), widening (stage 3), deposition and stabilization (stage 4), and once again stable (stage 5). Stages 2 and 3 are the most problematic period of evolution, when the most sediment supply is available for transport and restoration options are limited. Using the channel evolution model, past channel states can be understood and future states predicted with a *space for time* substitution – this conceptual model has great value for on-the-ground application during stream restoration planning. Additional information regarding this model is provided in NRCS (2007, Ch3) and SVAP2 (NRCS 2009), as well as the original and other references.

The Natural Channel Design methodology (NRCS 2007, Ch11) draws on lessons learned from the channel evolution model, through its use of successional stages of channel evolution (Figure 9). Understanding the present and potential future successional stages (or states) and stream classifications of a stream can be very helpful for understanding channel stability and trends, and identifying realistic project goals.

Since its introduction, the channel evolution model has been modified by a number of scientists. Simon and Hupp (1987) and Simon (1989) modified the model to include an additional stage

for an anthropogenic-induced, un-incised channelized streams while Watson et al. (2002) extended the method by providing a quantitative method for developing channel-restoration strategies. Cannatelli and Curran (2012) modified the channel evolution model for dam removals, incorporating local hydrological conditions and vegetative growth in the evolution process.



**Figure 8:** Channel evolution model, with channel cross sections illustrating the 5 channel stages (modified from NRCS 2007, Ch3).

Recognizing the ecological value of vegetated multi-thread channels as well as the evolution of stream states as sometimes cyclical, rather than linear, Cluer and Thorne (2013) adapted the channel evolution model into the *stream evolution model* (Figure 10; Table 5). Compared to the channel evolution model, this model adds precursor and late stages for a multi-thread channel pattern as well a cyclical pattern where stream state alternately advances through the standard stages, skips stages, recovers to a previous stage, or repeats stage cycles. Anastomosing wet complexes are typically biologically rich, were common before floodplain settlement in North America during the 19<sup>th</sup> and 20<sup>th</sup> centuries, and, hence, can be a preferred alternative to other restoration strategies in some situations.




Figure 9: Various stream succession stages (NRCS 2007, Ch11).

Drawing from rangeland ecology, it has been proposed that *state and transition models* can be valuable for understanding channel evolution (Phillips 2011; Phillips 2014; Van Dyke 2016). These models provide structure for identifying modes of changes in ecosystems and landscapes, and tools for interpreting past adjustments and predicting future changes. Traditional succession models implemented in ecology are a special case of state-and-transition models, with a linear sequence (Phillips 2011; Figure 11). Drawing from this, the channel evolution model, stream evolution model, and the succession stages identified by Rosgen (Figure 9) can be considered state-and-transition models (Phillips 2014), generally of a linear succession form but also including cyclical and radiation properties in the case of the stream evolution model.

In a variation of evolution models, river evolution diagrams (Brierley and Friers 2015) assess and illustrate system responses to changing conditions,





Figure 10: Stream evolution model (Cluer and Thorne 2013). Stage descriptions are provided in Table 5. Dashed arrows indicate “short circuits” in the normal progression.



**Figure 11:** Archetypal state-and-transition model network structures (Phillips 2011).

as well as plot evolution trajectories. This tool can be valuable with adaptive management, framing decision making in the context of possible future stream states.

Additionally, the flow-channel fitness model (Phillips 2013) was developed to predict the qualitative response of alluvial channels to modified flow regimes, with fitness referring to the “fit” between a given discharge and channel capacity. Changes in discharge, slope, shear stress, and sediment supply are utilized to predict the change in channel state.

**Table 5:** Descriptions of stream evolution model (SEM) stages, with comparison to the channel evolution model (CEM) stages presented in Schumm et al. (1984) (adapted from Cluer and Thorne 2013).

SEM Stage	CEM Stage	Description
0: Anastomosing		Pre-disturbance, dynamically meta-stable network of unbranching channels and floodplain with vegetated islands supporting wet woodland or grassland.
1: Sinuous	1: Pre-modified	Dynamically stable and laterally active channel within a floodplain complex. Flood return period 1-5 year range.
2: Channelized		Re-sectioned land drainage, flood control, or navigation channels.
3: Degrading	2: Degradation	Incising and abandoning its floodplain. Featuring headcuts, knick points or knick zones that incise into the bed, scours away bars and riffles, and removes sediment stored at bank toes. Banks stable geotechnically.
3s: Arrested degradation		Stabilized, confined, canyon-type channels. Incised channel in which bed lowering and channel evolution have been halted because of non-erodible materials (bedrock, tight clays) have been encountered.
4: Degradation and widening	3: Rapid widening	Incising with unstable, retreating banks that collapse by slumping and/or rotational slips. Failed material is scoured away and the enlarged channel becomes disconnected from its former floodplain, which becomes a terrace.
4-3: Renewed incision		Further headcutting within Stage 4 channel.
5: Aggrading and widening	4: Aggradation	Bed rising, aggrading, widening channel with unstable banks in which excess load from upstream together with slumped bank material build and silt beds. Banks stabilizing and berming.
6: Quasi-equilibrium	5: Stabilization	Inset floodplain reestablished, quasi-equilibrium channel with two-stage cross section featuring regime channel inset within larger, degraded channel. Berms stabilize as pioneer vegetation traps fine sediment, seeds, and plant propagules.
7: Laterally active		Channel with frequent floodplain connection develops sinuous course, is laterally active, and has asymmetrical cross section promoting bar accretion at inner margins and toe scour and renewed bank retreat along outer margins of expanding/migrating bends.
8. Anastomosing		Meta-stable channel network. Post-disturbance channel featuring anastomosed planform connected to frequently-inundated floodplain that supports wet woodland or grassland that is bound by set-back terraces on one or both margins.

## Stream Ecological Valuation (SEV)

The Stream Ecological Valuation (SEV) tool was originally developed from a series of workshops in Auckland, New Zealand, and later modified by a technical panel. This assessment method is based on 14 stream functions, specifically: hydraulic functions (natural flow regime, floodplain effectiveness, longitudinal connectivity, groundwater connectivity); biogeochemical functions (water temperature, dissolved oxygen, organic matter input, instream organic particle retention, pollutant decontamination); habitat functions (fish spawning, aquatic fauna); and biodiversity functions (intact fish, invertebrate, riparian vegetation populations). This method covers a wide range in stream functions that are relevant for assessing proper stream function, consequently providing a method that has potential for application for wider geographic areas.

Information regarding this method can be obtained from:

- [Neale et al. \(2011\)](#) Stream Ecological Valuation (SEV): A User's Guide

## Basic Assessment Tools

Basic qualitative assessments can be useful tools for providing a structured evaluation of a riparian corridor. These methods evaluate common issues impacting streams, such as channel condition, hydrologic alteration, canopy cover, pools, and nutrient enrichment (NRCS 2009).

These qualitative assessments are often one of the first steps performed to provide a general approximation of stream condition and develop a basic understanding of the impairments impacting a stream reach of interest. However, it needs to be understood that these tools are only qualitative measures; substantially different results can be obtained by different observers. Additionally, dependence upon such tools is not a substitute for experienced practitioners in stream restoration to thoughtfully assess available information and field conditions to diagnose the condition and hypothesize on impairments and potential restoration strategies.

Available qualitative tools include:

- [SVAP 2](#): Version 2 of the NRCS Stream Visual Assessment Protocol. Provides an initial evaluation of the overall condition of wadeable streams, riparian zones and instream habitat. Assigns a score of 1 through 10 for 16 elements, with 10 representing the highest-quality conditions. Average scores greater than 7 represent good overall stream condition. (NRCS 2009)
- [Proper Functioning Condition \(PFC\)](#): Provides a consistent methodology for considering hydrology, vegetation, and erosion/deposition characteristics in describing the condition of riparian and wetland areas. Condition is described as proper functioning, functional – at risk, nonfunctional, or unknown (Prichard et al. 1998).
- [Morphological Quality Index \(MQI\)](#): A relatively simple, process-based method for evaluating the hydromorphological condition of stream reaches over time (Rinaldi et al. 2015).
- [Pfankuch Method](#): Stream Reach Inventory and Channel Stability Evaluation. Procedure to systemize measurements and evaluations of the resistive capacity of mountain stream channels, evaluate the detachment of bed and bank materials, and to provide information about the capacity of streams to adjust and recover from potential changes in flow and sediment production (Pfankuch 1975).

## FIELD DATA COLLECTION

Field data collection can consist of many different activities. The specific data needing to be collected varies by the stream reach of concern and the specific project objectives. Examples briefly discussed in this guidance include topographic surveying, bankfull identification, discharge and water quality measurements, bed material composition and transport, riparian vegetation identification, and macroinvertebrate and fish sampling. While such data collection and analysis can be essential for assessing dominant mechanisms and impairments, these activities can take a substantial investment of time and money – only the data needed to satisfy the project objectives and minimize failure risk should be collected.

Numerous protocols have been developed for the collection of field data for evaluating the status and trends in stream condition. References for these protocols include:

- [BLM 2015](#) AIM National Aquatic Monitoring Framework: Introducing the Framework and Indicators for Lotic Systems
- [Archer et al. 2014a](#) Effectiveness monitoring for streams and riparian areas: Sampling protocol for stream channel attributes (PIBO)
- [Kershner et al. 2004](#) Guide to Effective Monitoring of Aquatic and Riparian Resources (PIBO)
- [Rosgen 1996](#) Applied River Morphology
- [Harrelson et al. 1994](#) Stream Channel Reference Sites: An Illustrated Guide to Field Technique

Additionally, field data collection through mobile device applications has become popular by some workers. [Camp and Wheaton \(2014\)](#) provide an overview of tools developed at Utah State University.

### Topographic Survey Data

For stream projects, survey methods typically fall into two categories: differential leveling and land surveying. Differential leveling uses a tripod-mounted level (traditional or laser) and measuring tape (Figure 12; [Harrelson et al. 1994](#)). This is an

older but standard technique for stream projects, though survey grade GPS (Figure 13) allows single individuals to collect much more frequent and accurate data points (allowing for a general land survey). Additionally, total stations are essential for data collection in some areas with dense vegetative cover. Airborne-collected LiDAR data are increasingly available at many locations, allowing for unparalleled description of landforms, but these datasets are typically only relevant for measurements above the water surface at the time of data collection. When combined with ground-based data collection for below-water features, validation is needed to assure that the datasets are compatible.

Key advantages of survey-grade GPS is the enhanced capability of georeferencing the survey so that the data points can be easily overlaid with other data layers in GIS or Computer Aided Drafting and Design (CADD). More accurate construction layout can also be performed. A disadvantage of survey-grade GPS is its limited capabilities in areas with vegetative canopy, though this can be mitigated by surveying during leaf-off periods, using an antenna designed to be more effective under canopy, or using a total station for filling in data gaps. To properly georeference the data, an Online Positioning User Service (OPUS) solution can be obtained for the base station location, with this setup location and coordinates consistently used for all project surveying. For a description of the difference between ellipsoid and geoid vertical datum, see this [NGA website](#).




Figure 12: Differential surveying (Harrelson et al. 1994).



**Figure 13:** Survey-grade GPS.

The extent of topographic survey data required to perform the needed analyses depends upon the project objectives and extent. For example, if a project is limited to bank stabilization along a single bank over a short reach, the only survey data that may be needed could be a thalweg and bankfull longitudinal profiles and a few cross sections. Alternatively, if the project is more extensive, for example the restoration of a mile long reach by such features as grade and bank stabilization, pool excavation, and habitat enhancement structures, more survey data will likely be needed to analyze and design the project.

This latter complexity level of project may require a general land survey of the riparian zone, up the 50- or 100-year flood level, so that a hydraulic model with a detailed sequence of cross sections can be developed, as well as development of more complex hydraulic models if they are deemed necessary. This type of survey should not be simply a series of cross sections but rather a feature survey that combines the description of landform features with a varying density grid. The features are surveyed to measure the location of relevant landforms and the grid data is collected to define the shape and gradient between the features. This grid density varies with the amount of variability of the land surface between the features. Typical features surveyed include a longitudinal profile of the channel thalweg, bottom

and top of channel banks, and the bottom and top of terrace slopes.

For both simpler and more complex projects, geometric data should be collected both upstream and downstream of the reach of interest, to assist with the design of project transitions and to help understand potential interactions with neighboring untreated sections. For example, a downstream headcut that shows signs of migration would indicate a strong potential for incision within a restoration reach; a survey should include such features. Additionally, these upstream and downstream areas may be valuable for collecting data on reference conditions.

### Bankfull Stage Identification

The bankfull channel represents the result of the channel-forming discharge being, on average, the most effective discharge for producing and maintaining the channel's geomorphic condition (i.e., width, depth, slope). Not all stream channels display this feature, but perennial alluvial streams typically do for at least portions of their length. There are confounding (and sometimes controversial) issues tied to effective discharge and bankfull width, stage and discharge. Discussions on this are left primarily to the supporting documents, such as the references provided in the Overview of Stream Processes and Restoration section.

Due to the fundamental nature of bankfull discharge, accurate identification of bankfull elevation is often necessary. This elevation is used for the definition and communication of channel shape, as well as physical and biologic processes. Common physical indicators for bankfull elevation are:

- Level of incipient flooding onto an active floodplain
  - Lowest flat floodplain surface, not a higher abandoned surface (terrace) that the stream has incised below
- Elevation of the top of the highest depositional surface of an active bar, such as a point bar
- Break in slope of the bank
- Change in particle size, with finer material deposited on the floodplain

- Change in vegetation, with perennials slightly below, at or above the bankfull level

To properly identify bankfull in the field, it is important to identify bankfull features not just at a point but instead as a continuous feature along a portion of the reach, to reduce the potential for misidentification. A good practice is to mark the continuous surface with pin flags then stand on the far bank and observe the markers for accuracy and consistency.

References for identifying bankfull include:

- [NRCS 2007, Ch5](#) Stream Hydrology
- [Copeland et al. 2001](#) Hydraulic Design of Stream Restoration Projects
- [Rosgen 1996](#) Applied River Morphology
- [Harrelson et al. 1994](#) Stream Channel Reference Sites: An Illustrated Guide to Field Technique.
- Leopold 1994 A View of the River
- Dunne and Leopold 1978 Water in Environmental Planning

Additionally, the following videos illustrate some of the best approaches for identifying bankfull elevation:

- [Identifying Bankfull Stage in Forested Streams in the Eastern United States](#) 2003 (M. Gordon Wolman, William Emmett, Elon Verry, Daniel Marion, Lloyd Swift, Gary Kappesser)
- [A Guide for Field Identification of Bankfull Stage in the Western United States](#) 1995 (Luna Leopold, William Emmett, H. Lee Silvey, David Rosgen)

DVD's containing uncompressed versions of these videos are available from the Forest Service [National Stream and Aquatic Ecology Center](#).

## Discharge Measurements

Discharge measurements are oftentimes collected for stream restoration and rehabilitation work. These data are collected to measure such things as bankfull and low flow discharge, for geomorphic design and habitat assessments. Discharge measurements provide information regarding channel roughness, including how this roughness varies by stage and location.

Discharge can be measured using the traditional velocity-area method as well as with more advanced tools, such as an acoustic doppler current profiler. The velocity-area method divides the stream channel into numerous vertical subsections where depth and average velocity is measured, with the overall discharge computed by summing the incremental subsection values. Details for discharge measurements techniques can be found in:


- [WMO 2010](#) Manual on Stream Gauging
- [Paradiso 2000](#) A Bank-Operated Traveling-Block Cableway for Stream Discharge and Sediment Measurements
- [Harrelson et al. 1994](#) Stream Channel Reference Sites: An Illustrated Guide to Field Technique
- [Buchanan and Somers 1969](#) Discharge Measurements at Gaging Stations

## Water Quality

Inadequate water quality is an impairment that can prevent the achievement of some restoration objectives, such as the establishment or protection of a fishery in a project reach. For example, the lack of shading in or upstream of the restoration reach can lead to excessive peak summertime temperatures for cold water fishes, metal loading from historic mining activities within the watershed can create toxic conditions for aquatic life, and excessive nutrients from riparian livestock grazing and septic systems can cause algae blooms that can depress dissolved oxygen levels.

For cold water fishes, excessive peak summertime temperatures are often the primary impairment. Nationally, increasing trends in stream temperatures have been observed, while decreasing trends are much less common (Kaushal et al. 2010). Stream temperatures typically have a daily (diurnal) cycle (Figure 14). Excessive peak temperatures can have sub-lethal effects (e.g., reductions in long-term growth and survival) and, if high enough, are deadly. If the project objectives are to increase habitat for trout, excessive temperatures would need to be mitigated. With stream temperatures a function of upstream cover and solar radiation input to the stream, upstream

riparian condition can be fundamental for controlling temperature in a reach of interest.



**Figure 14:** Diurnal temperature fluctuations.

Hach kits, for instantaneous measurements of dissolved oxygen, nitrogen and phosphorus, can provide data at fairly low cost, and are simple to use. pH paper and a thermometer can also be effective for measuring basic field parameters. Logging multi-parameter probes can be of great value for assessing the basic water quality of the site. The most common sensors measure temperature, pH, dissolved oxygen, conductivity, and depth. However, this equipment is expensive. Simple and cost effective temperature monitoring systems are available, such as the [Hobo U22](#); equipment is available to collect the data needed to assess limiting conditions for cold water fish species.

If existing data are not available for the stream of interest, it may be necessary to collect water quality samples and have laboratory analyses performed. The U.S. Geological Survey ([USGS variously dated](#)) provides extensive documentation on procedures for the collection of water quality samples. Water quality analyses can be performed at various commercial labs, the EPA, as well as the [USGS National Water Quality Laboratory](#), at the Denver Federal Center.

General references for assessing water quality in streams include:

- [EPA 2012](#) Water Quality Criteria for Aquatic Life and Human Health
- [EPA 2008](#) Aquatic Life Criteria for Contaminants of Emerging Concern
- Drever 1997 The Geochemistry of Natural Waters
- Stumm and Morgan 1996 Aquatic Chemistry – Chemical Equilibria and Rates in Natural Waters

Specific references helpful to practitioners for monitoring water quality include:

- [USFS](#) (internal USFS only) Monitoring Water Quality: Collecting Stream Samples
- [USFS](#) (internal USFS only) Collecting Water Samples for Chemical Analysis: Streams
- [Isaac \(2011\)](#) Stream Temperature Monitoring and Modeling: Recent Advances and New Tools for Managers.
- [Dunham et al. 2005](#) Measuring Stream Temperature with Digital Data Loggers – A User’s Guide.
- [Davis et al. 2001](#) Monitoring Wilderness Stream Ecosystems


## Bed Material Sampling

Knowledge of bed material size distributions is necessary for describing channel type, and quantifying incipient motion, sediment transport capacity, and flow resistance. Bed material size can also indicate the quality of biologic habitats, such as fish spawning opportunities.

Methods vary by material size (i.e. sand versus cobble and gravel), with Bunte and Abt 2001 providing an overall reference for sampling bed material in gravel and cobble-bed channels. Bed material can be characterized using such methods as grid sampling, where particles are measured under a preselected number of grid points (i.e. pebble count, photographic grid count), and aerial sampling, where all particles exposed on the surface of a predefined area are measured (i.e. adhesive sampling, photographic aerial sampling). Additionally, volumetric sampling, where a predefined volume or mass of sediment is collected from the bed and measured using field or laboratory sieving, is a common measurement approach for most bed material sizes.

Simple methods such as pebble counts can be spatially integrated (reach average) or spatially segregated (sampling each geomorphic unit individually). Both surface (armor layer) and subsurface material can be sampled, depending upon the purpose. When salmonid habitat enhancement is a primary objective, sediment sampling to determine the degree of fine sediment intrusion into gravel beds can provide key information on spawning habitat. From the

collected data, a particle size distribution is computed (Figure 15) and such bed material characteristics as  $D_{84}$  (particle size at which 84 percent of the material is finer) and  $D_{50}$  (median particle size) are extracted. Practitioners should pay attention to the location of fine sediments. Sorted sediments are important to the ecology of stream systems. Fines deposited in the margins and slow water areas allow for nutrient retention and development of a diverse macroinvertebrate population. Lumping a total particle count in a cross section might lead to a mischaracterization of a cross section and imply embeddedness of the substrate where this is not actually the case.



**Figure 15:** Example bed material particle size distribution (Bunte and Abt 2001).

References helpful for quantifying bed material size distributions include:

- [NRCS 2007, TS13A](#) Guidelines for Sampling Bed Material
- [Bunte and Abt 2001](#) Sampling Surface and Subsurface Particle Size Distributions in Wadable Gravel- and Cobble-Bed Streams for Analyses in Sediment Transport, Hydraulics, and Streambed Monitoring
- [Copeland et al. 2001](#) (Appendix D) Hydraulic Design of Stream Restoration Projects
- [Harrelson et al. 1994](#) Stream Channel Reference Sites: An Illustrated Guide to Field Technique

Available tools for analyzing bed-material size distributions include:

- [Spreadsheet Tools for River Evaluation, Assessment, and Monitoring](#) Ohio


Department of Natural Resources and Ohio State (Dan Mecklenburg and others)

- [Size-Class Pebble Count Analyzer Spreadsheet](#) USFS National Stream and Aquatic Ecology Center
- [Rivermorph](#): Stream restoration software developed for application of the Rosgen geomorphic channel design method.

## Sediment Transport Measurements

To understand sediment transport processes within a specific restoration reach, it may be necessary to measure sediment transport rates. In general, sediment transport in a stream consists of suspended load and bedload, where suspended load consists of the finer particles that are held in suspension within the water column by turbulent currents and bedload consists of coarser particles that roll, slide or bounce along the streambed. Typically, bedload makes up a larger proportion of total load as drainage area decreases and channel slopes increase (Gray et al. 2010).

Bedload and suspended sediment sampling provide valuable data for developing and calibrating sediment rating curves. Suspended sediment is measured using such devices as a DH-81 handheld depth-integrated sampler. Bedload is measured using such equipment as the Helley-Smith sampler or bedload traps (Figure 16). In gravel-bed streams it has been found that, in comparison to bedload traps, that the Helley-Smith sampler can substantially overestimate bedload transport for less than bankfull flow (Bunte et al. 2004). Technology is also being developed to measure bedload transport continuously, using impact plates (Hilldale et al. 2015).




**Figure 16:** Bedload trap (Bunte et al. 2007).

References to assist with sediment transport data collection include:

- [Hilldale et al. 2015](#) Installation of Impact Plates to Continuously Measure Bed Load: Elwha River, Washington, USA
- [Gray et al. 2010](#) Bedload-Surrogate Monitoring Technologies
- [Bunte et al. 2007](#) Guidelines for Using Bedload Traps in Coarse-Bedded Mountain Streams – Construction, Installation, Operation, and Sample Processing
- [Edwards and Gysson 1999](#) Field Methods for Measurement of Fluvial Sediment

## Riparian Vegetation

Riparian vegetation (Figure 17) offers many benefits to streams, including reduced erosion rates and increased bank stability, increased flow resistance and reduced velocities, increased vadose zone recharge, and the provision of cover, shade, and energy input to streams. Riparian vegetation is essential for healthy benthic macroinvertebrate populations, which in turn provides a critical food resource for fish. Hence, establishing the status of riparian vegetation is an essential component of stream restoration planning and design.



**Figure 17:** Vegetation zones within a riparian cross section (Hoag et al. 2008).

References available for quantifying the status of riparian vegetation include:

- [Stromberg and Merritt 2015](#) Riparian Plant Guilds of Ephemeral, Intermittent, and Perennial Rivers
- [Archer et al. 2014b](#) Effectiveness Monitoring Program for Streams and Riparian Areas: 2014 Sampling Protocol for Vegetation Parameters (PIBO)
- [Burton et al. 2011](#) Multiple Indicator Monitoring of Stream Channels and Streamside Vegetation
- [Hoag et al. 2008](#) Field guide for Identification and Use of Common Riparian Woody Plants of the Intermountain West and Pacific Northwest Regions.
- [Kershner et al. 2004](#) Guide to Effective Monitoring of Aquatic and Riparian Resources
- [Winward 2000](#) Monitoring the Vegetation Resources in Riparian Areas

## Aquatic Organisms

Habitat improvement for aquatic organisms is a common objective of stream restoration and rehabilitation projects. To have measureable objectives in such projects, quantifying aquatic organism populations (Figure 18, Figure 19) is necessary both in the planning phase as well as after construction. Both fish sampling and macroinvertebrate sampling are valuable tools for assessing status. Two common biotic indicators are the Index of Biotic Integrity (IBI), which uses fish surveys to assess human impacts, and the Ephemeroptera, Plecoptera, and Trichoptera (mayfly, stonefly, caddisfly; EPT) index, which uses macroinvertebrate abundance and diversity as indicators of water quality (NRCS 2007).



Figure 18: Fish sampling (NRCS 2007).



Figure 19: Macroinvertebrate sampling equipment (Moulton et al. 2002).

References and websites for assessing aquatic organism populations include:

- [eDNA Sampling](#), for aquatic organism detection. Forest Service National Genomics Center for Wildlife and Fish Conservation
- [Carin et al. 2015](#) Protocol for Collecting eDNA Samples from Streams. USDA Forest Service, Rocky Mountain Research Station.
- [Becker and Russell 2014](#) (internal Forest Service only) Fish Detection and Counting Device: Automated Capacitive Sensing of Aquatic Life in Remote Streams and Rivers
- [Aquatic Insect Encyclopedia](#): Aquatic insects of trout streams
- [NRCS 2007, Ch3](#) Site Assessment and Investigation
- [Moulton et al. 2002](#) Revised Protocols for Sampling Algal, Invertebrates, and Fish Communities as Part of the National Water-Quality Assessment Program (USGS)
- [Davis et al. 2001](#) Monitoring Wilderness Stream Ecosystems
- [Barbour 1999](#) Rapid Bioassessment Protocols for Use in Streams and Wadeable Rivers: Periphyton, Benthic Macroinvertebrates, and Fish

## **ANALYSES FOR STREAM RESTORATION and REHABILITATION**

Stream restoration and rehabilitation analyses are often performed to provide a channel (or channels) that will be in a physical form that is in dynamic equilibrium with its water and sediment load. Alternatively, analyses are also performed to understand the flow dynamics driving erosional, transport, and depositional reaches, with the consideration that variability leading to heterogeneity that can be valuable for ecological function. The focus of analyses is typically determined by the project setting and extent, and goals and objectives. Both existing and proposed conditions are often assessed through analyses.

The most appropriate analyses for stream restoration projects are a function of the general design approach judged to be most appropriate for the setting, goals, and objectives. A *process-based approach* develops the baseline conditions that will allow the stream channel(s) and floodplains to evolve through fluvial processes and riparian succession towards more complex and dynamic habitats. In contrast, a *form-based approach* defines channel pattern, profile, and dimension and uses structural features (such as rock vanes, toe wood, and rip rap) to minimize channel adjustment. However, over reliance on these terms can be problematic since form implies process, with current form being the result of past processes.

The use of a process-based approach has the advantage of allowing the stream and valley to adjust to potential disturbances, such as changes in land use changes, fires, and climate change. Stream restoration often takes the approach of providing single thread streams in restored reaches. However, considering that multithread streams were likely common prior to anthropogenic manipulation (Cluer and Thorne 2013), the development of a multithread channel form in restoration may be best for satisfying ecologically-focused goals and objectives, and process-based design approaches. A process-based approach can often be used on public lands, where adjustments can be adapted to in deference for satisfying ecologically-based management priorities. However this approach is often not appropriate due to societal constraints – if

infrastructure, residences, or highly productive agricultural land are threatened by channel and floodplain adjustments, a form-based approach may be most appropriate.

The general approaches towards stream restoration and rehabilitation has been described by Wohl et al. (2015) as:

1. *field of dreams*, where the desired form of the stream is identified from the goals and objectives and the channel and floodplain are engineered using a form-based design approach
2. *system function*, where emphasis is placed on system processes using a process-based design approach
3. *hybrid keystone*, where crucial elements of a desired form are identified and designed using a form-based approach, but there are also aspects of the stream and its floodplain that are allowed to adjust and evolve over time in response to the introduced form, in a process-based manner

Analysis and design approaches that are generally utilized for restoration and rehabilitation projects are: the analogy method, which bases channel dimensions on a reference reach; the hydraulic geometry method, which relies upon hydraulic geometry relationships to select a dependent design variable (such as channel width and depth); and the analytical method, which uses computational modeling (NRCS 2007, Ch7). Designs are often best developed using a combination of approaches, with the redundancy in proportion to stream variability, and the need to work around limitations in data availability, understanding of physical processes, and computational power.

Guidance for these methodologies can be found in the following references:

- Cui et al. 2011 (in [Simon et al. 2011](#)) Practical Considerations for Modeling Sediment Transport Dynamics in Rivers
- [NRCS 2007, Ch6](#) Stream Hydraulics
- [NRCS 2007, Ch9](#) Alluvial Channel Design
- [NRCS 2007, Ch11](#) Rosgen Geomorphic Channel Design
- [NRCS 2007: Ch12](#) Channel Alignment and Variability Design

- [NRCS 2007: Ch13](#) Sediment Impact Assessments
- [Brierley and Fryirs 2005](#) Geomorphology and River Management: Applications of the River Styles Framework.
- [Soar and Thorne 2001](#) Channel Restoration Design for Meandering Rivers
- [Copeland et al. 2001](#) Hydraulic Design of Stream Restoration Projects

Details of the analysis approach needed for projects can be unclear. For example, if a reference reach approach is used, how is the most appropriate reference reach selected? Are the available reference reaches a good analogy for the actual stream potential? Is a combination of multiple disturbed reference reaches that are showing signs of recovery the best available analogs to utilize for the design? When is a sediment transport analysis needed? At what flows should sediment transport be computed, at bankfull flow or for a range in discharges? When is sediment load low enough so that threshold analysis is adequate? The thoughtful consideration of these and other issues is needed.

This section provides summary guidance for a few key analysis and design techniques. Topics discussed include flow frequency estimates, bankfull characteristics, Rosgen geomorphic channel design, the River Styles fluvial geomorphic approach for assessing river form, condition, and recovery potential, Soar and Thorne restoration design, hydraulic modeling overview, hydrologic and ecologic modeling tools, and flow resistance estimation.

### Bankfull Characteristics

Alluvial streams oftentimes develop a characteristic form, with a bankfull channel (or channels) formed by the dominant channel-forming discharge. Large floods, which transport a great deal of sediment, happen very infrequently, while small events, even though they happen frequently, move much less sediment, leading to a logical conclusion that there is a moderate magnitude and frequency flood event, the channel forming flow, that dominates sediment transport and is responsible for creating the bankfull channel (Wolman and Miller 1960).

This flow rate is the channel forming discharge, which is commonly referred to as bankfull discharge. However, it has been argued that, due to difficulties associated with proper bankfull identification as well as a consequence of unstable channels and nonstationarity (described in the next section), that channel-forming discharge should not be considered the same as bankfull discharge (Copeland et al. 2001). Additionally, appropriate bankfull channel geometry can be complicated by project objectives, such as hydraulic conditions that balance overall sediment conveyance with conditions that can retain spawning gravels. In any case, bankfull characteristics can only be expected in perennial or ephemeral alluvial streams in humid environments, and perennial alluvial streams in semiarid or arid environments. In flashy, arid, intermittent streams, or highly-urbanized watersheds, other mechanisms can be dominant and the bankfull discharge concept may not be applicable (Copeland et al. 2001).

When good indicators of channel-forming flow are present, the most reliable method for determining bankfull discharge is to measure the discharge when the project stream is flowing at or near bankfull. This method is most viable in snowmelt-dominated streams, where the annual flow peak can be more easily predicted. Alternatively, bankfull discharge can be estimated at several stable cross sections by a normal depth assumption, though this method requires an accurate estimate of Manning's  $n$  for bankfull flow. However, the accurate identification of bankfull may be difficult or impossible in highly disturbed reaches.

Bankfull discharge and geometric characteristics can also be estimated using regional regressions based on drainage area and, possibly, other watershed characteristics. However this method can be problematic in mountainous areas where precipitation varies substantially, resulting in drainage area alone being insufficient for prediction. Additionally, stream diversions and reservoirs also alter bankfull characteristics, complicating or prohibiting the development of regional relationships. It has been found that, on a continental scale, that watershed area alone is insufficient for regional bankfull width estimation and that precipitation variability should also be included (Wilkerson et al. 2014). This study also


indicates that differing width regional curve relationships may occur as watershed area ( $A$ ) increases ( $A < 1.9 \text{ mi}^2$ ,  $1.9 < A < 130 \text{ mi}^2$ ,  $A > 130 \text{ mi}^2$ ).

The regional approach for developing bankfull discharge estimates is described in:

- [NRCS 2007, TS5](#) Developing Regional Relationships for Bankfull Discharge Using Bankfull Indices

Typically, bankfull flow corresponds to a 1 to 2.5-year return interval flood, with an average of about 1.5 years (Leopold 1994). Alternatively, it has been argued that bankfull flow occurs less frequently for many streams (Williams 1978). With a range of return intervals associated with bankfull flow, basing bankfull discharge on only a specific return interval event may be inappropriate. Instead, another method should be used to compute bankfull discharge and these results compared to the flow-frequency estimates, for quality assurance. For example, if the return interval of a predicted bankfull discharge is greater than 2 or 2.5 years, than the bankfull channel may have been overestimated (i.e., a terrace feature mistaken for an active floodplain).

Where discharge and sediment transport data are available (or can be reliably simulated), channel forming flow can be computed through use of the effective discharge methodology (Figure 20). This method has been argued to be more reliable and appropriate than assuming that bankfull discharge is equivalent to the channel-forming discharge (Soar and Thorne 2001, Copeland et al. 2001, Soar and Thorne 2011). However, research indicating that effective discharge in some mountain streams is more related to maximum discharge rather than bankfull discharge (Bunte et al. 2014) complicates standard approaches for implementing an effective discharge approach in high-gradient streams.



**Figure 20:** Effective discharge computation (NRCS 2007, Ch5).


The methodology for computing effective discharge is described in:

- [Soar and Thorne 2011](#) Design Discharge for River Restoration
- [NRCS 2007, Ch5](#) Stream Hydrology
- [Soar and Thorne 2001](#) Channel Restoration Design for Meandering Rivers
- [Copeland et al. 2001](#) Hydraulic Design of Stream Restoration Projects

## Flow Frequency Estimates

Stream restorations and rehabilitations typically use bankfull discharge as a primary design discharge, in addition to low flow values for aquatic life. However, less frequent flood events (such as the 10-, 25- and 100-year floods) are also relevant for designs since larger floods contribute the largest individual pulses of sediment loads to the channel as well as provide the high stresses that instream structures are designed to resist. Hence, flow frequency estimates are typically needed for stream designs.

If the project is adjacent to a streamgage that has a sufficient record length, flow frequency estimates (Figure 21) can be obtained from the USGS or computed using the methods presented in Bulletin 17B (IACWD 1982) and outlined in NRCS (2007), Ch5. Importantly, instantaneous peak flow data need to be used in the flow-frequency analysis; the use of average daily flow values can substantially underpredict flow frequency relationships.




**Figure 21:** Flow frequency estimates for the Cache la Poudre River, CO (USGS 06752000).

However, many projects occur on streams that have never been gaged or are distant from the nearest streamgage, with substantially different watershed areas. In these situations it is necessary to use methods developed for ungaged locations. Regional flow frequency estimation techniques, using multivariate regression approaches from streamgaged locations, can be helpful in these circumstances. Based on such regional analyses, approximate flow frequency estimates can be easily obtained from [USGS Streamstats](#), though these values can be substantially over or underestimated; particular attention needs to be paid to the prediction errors when using this tool. To obtain results that can be used with greater confidence, results developed using a custom regional regression approach may be preferred. This methodology is discussed in NRCS (2007), Ch5. Alternatively, in rainfall dominated watersheds, rainfall-runoff models can also be developed for estimating flow-frequency relationships. Such methods should typically not be attempted in watersheds where snowmelt events typically produce the annual peak flows.

Inherent in flow frequency analysis is an assumption of stationarity, specifically that the annual peak flows have a constant mean and variance throughout the record. Violation of this assumption due to changes in land use, such as urbanization, forest fires and conservation practices, as well as climate change and reservoir construction, has repercussions on the use of flow frequency relationships for stream restoration and rehabilitation design. For example, Haucke and Clancy (2011) found that conservation practices can decrease frequent annual flood events, despite corresponding increases in precipitation. Trends in

annual peak discharges in the Continental U.S. are illustrated in Figure 22.



**Figure 22:** Annual peak discharge trends, with record lengths from 85 - 127 years (Hirsch 2011).

References and tools available for flow-frequency prediction, as well as general references for explaining flow-frequency relationships, include:

- [USGS](#): Questions and answers about floods.
- [NRCS 2007, Ch5](#) Stream Hydrology
- [IACWD 1982](#) Guidelines for Determining Flood Flow Frequency (Bulletin 17B)
- [log-Pearson Frequency Analysis Spreadsheet](#) USFS National Stream and Aquatic Ecology Center
- [PKFQWin](#) USGS Flood Frequency Analysis Software, based on methods provided in Bulletin 17B.
- [HEC-SSP](#) U.S. Army Corps of Engineers Hydrologic Engineering Center – Statistical Software Package
- [USGS Streamstats](#) watershed and stream statistics, including approximate flow frequency values, mean flows and minimum flows for ungaged streams.

## Natural Channel Design

The natural channel design method, developed by Dave Rosgen, uses measurements of morphological relations associated with bankfull flow, geomorphic valley type, and geomorphic stream type to develop channel designs (NRCS 2007, Ch11). This technique combines reference reaches, hydraulic geometry relationships, and simple hydraulic modeling to develop design specifications for establishing a reach with appropriate channel dimension, planform pattern, and longitudinal profile. Figure 23 provides a conceptual outline of this design approach.

Various tools are available for the application of this design method. FLOWSED and POWERSED are relatively simple sediment supply and transport models that can predict total annual suspended and bedload sediment yield, as well as the potential for aggradation or degradation (NRCS 2007, Ch11). Additionally, the BANCS model (Bank Assessment for Non-point Consequences of Sediment), which uses the BEHI (Bank Erosion Hazard Index) and NBS (Near-Bank Stress) bank erosion estimation tools, is also available. This model estimates annual bank erosion rates, providing estimates of annual sediment yield (Rosgen et al. 2008).

The availability of a reference reach is fundamental for the application of this methodology. This reference reach is a stable stream that indicates the potential of the design reach (Rosgen 2011). However, considering the wide ranging anthropogenic disturbances in streams, such as livestock grazing in riparian zones and removal of instream wood, it can be difficult or impossible to find a local reference reach that represents full stream potential. Instead, the reference reach is often selected to represent a condition where the stream has adjusted to driving variables and boundary conditions to be self maintaining, in the same stream type, valley type, flow regime, sediment regime, stream bank type, and vegetative community as the design reach (Rosgen 2011).

Regional curves, relationships between bankfull discharge and dimensions with drainage area, are simple linear regressions also used to develop the design. Prediction based on only drainage area can be inappropriate in regions where precipitation varies substantially (such as mountainous watersheds) and where there are substantial flow diversions. Additional predicting variables may need to be included in regional regressions, such as average annual precipitation.

Tools and references available for stream restoration and rehabilitation designs based on the natural channel design method include:

- [Rosgen 2013](#) Natural Channel Design – Fundamental Concepts, Assumptions, and Methods
- [Rosgen et al. 2008](#) River Stability Field Guide
- [NRCS 2007, Ch11](#) Rosgen Geomorphic Channel Design
- [NRCS 2007, TS3E](#) Rosgen Stream Classification Technique: Supplemental Materials
- [Rosgen 2007](#) Watershed Assessment of River Stability and Sediment Supply (WARSSS)
- [Doll et al. 2003](#) Stream Restoration: A Natural Channel Design Handbook
- [Rosgen 1996](#) Applied River Morphology
- [Harrelson et al. 1994](#) Stream Channel Reference Sites: An Illustrated Guide to Field Technique
- [Regional Hydraulic Geometry Curves](#): NRCS Repository of regional curves relating bankfull dimensions with drainage area.
- [Rivermorph](#): Stream restoration software developed for application of the Rosgen geomorphic channel design method.
- [Lessons Learned from Natural Stream Restoration/Enhancement: Insight on Natural Channel Design](#) 2013 (Dick Everhart, Angela Greene)




Figure 23: Schematic illustrating the Natural Channel Design method (NRCS 2007, Ch11).

## River Styles

[River Styles](#)<sup>®</sup> (Figure 24) is a fluvial geomorphic approach for assessing river form, condition, and recovery potential. This method provides a physical template for stream management. As discussed in the method website, this approach was developed around four fundamental principles:

1. Respect stream diversity
2. Work with stream dynamics and change
3. Work with linkages to biophysical processes
4. Use geomorphology as an integrative physical template for river management activities

Tools and references available for stream assessment and management based on the River Styles approach include:

- [Fryirs and Brierley 2013](#) Geomorphic Analysis of River Systems: An Approach to Reading the Landscape.
- [Brierley and Fryirs 2008](#) River Futures: An Integrative Scientific Approach to River Repair.
- [Brierley and Fryirs 2005](#) Geomorphology and River Management: Applications of the River Styles Framework.

- **Works with the natural diversity of river forms and processes.** Due recognition is given to the continuum of river morphology, extending from bedrock-imposed conditions to fully alluvial variants (some of which may comprise unincised valley floors). The River Styles framework can be applied in any environmental setting.
- **Is framed in terms of generic, open-ended procedures that are applied in a catchment-specific manner.** Reaches are not 'pigeon-holed' into rigid categories; rather, new variants are added to the existing range of River Styles based on a set of discrete attributes (i.e. the valley setting, geomorphic unit assemblage, channel planform, and bed material texture).
- **Evaluates river behavior, indicating how a river adjusts within its valley setting.** This is achieved through appraisal of the form-process associations of geomorphic units that make up each River Style. Assessment of these building blocks of rivers, in both channel and floodplain zones, guides interpretation of the range of behavior within any reach. As geomorphic units include both erosional and depositional forms, and characterize all riverscapes, they provide an inclusive and integrative tool for classification exercises.
- **Provides a catchment-framed baseline survey of river character and behavior throughout a catchment.** Application of a nested hierarchical arrangement enables the integrity of site-specific information to be retained in analyses applied at catchment or regional levels. Downstream patterns and connections among reaches are examined, demonstrating how disturbance impacts in one part of a catchment are manifest elsewhere over differing timeframes. Controls on river character and behavior, and downstream patterns of River Styles, are explained in terms of their physical setting and prevailing biophysical fluxes.
- **Evaluates recent river changes in context of longer-term landscape evolution, framing river responses to human disturbance in context of the 'capacity for adjustment' of each River Style.** Identification of reference conditions provides the basis to determine how far from its 'natural' condition the contemporary river sits and interpret why the river has changed. Analysis of reaches at differing stages of geomorphic adjustment at differing localities (i.e. space-time transformation or ergodic reasoning) is applied to interpret evolutionary pathways for reaches of the same type.
- **Provides a meaningful basis to compare type-with-type.** From this, the contemporary geomorphic condition of the river is assessed. Analysis of downstream patterns of River Styles and their changes throughout a catchment, among other considerations, provides key insights with which to determine geomorphic river recovery potential. This assessment, in turn, provides a physical basis to predict likely future river structure and function.

Figure 24: River Styles framework (extracted from [www.riverstyles.com](http://www.riverstyles.com)).

## Soar and Thorne Restoration Design

Soar and Thorne (2001) developed a stream restoration and rehabilitation design procedure that combines a range of techniques, including field reconnaissance, detailed site survey, discharge-frequency analysis, hydraulic geometry analysis, and analytical modeling, such as the

Copeland method (available in HEC-RAS). This design method acknowledges the limitations of analytical methods and assumes the availability of stable reference reaches, to provide such baseline information as the magnitude and frequency of sediment-transporting flow events and the channel-forming discharge. The method is illustrated in Figure 25.




Figure 25: Soar and Thorne (2001) stream restoration design procedure.

## Hydraulic Modeling Overview

Since the variability between stream reaches can be substantial and unforeseen circumstances can lead to unintended consequences, hydraulic modeling can be an important component of a restoration or rehabilitation design. An appropriate hydraulic model can reduce the potential for the project to cause undesirable outcomes.

Hydraulic computational modeling in support of stream designs can consist of a wide range of approaches, from a simple normal depth computation using the Manning's equation, to a 3-dimensional finite element model. Some degree of hydraulic modeling is typically required for all restorations that employ engineering practices, with the degree of model complexity defined by the magnitude and objectives of the project. For example, a short bank stabilization project may only require normal depth and incipient motion computations, while a channel relocation may require at least a one-dimensional finite difference model (such as HEC-RAS) to assess the potential for unintended consequences that could result in project failure. Complicating circumstances, such as a project in the vicinity of a confluence, need to be considered while judging the need for more advanced modeling. In this example, the confluence may result in unexpected flow and sediment dynamics during high flow. Even when a reference reach approach is being implemented in a design, the analogous stream reach is very rarely a perfect match; sufficient hydraulic modeling is often needed to assess unintended consequences of extrapolating reference geometry to the target reach.


It is necessary to weigh the additional data needs for the development of more complex models, as well as the time required to assemble the model. Additionally, the interactions of 3-dimensional flow, sediment mechanics, erodible banks, and riparian vegetation all interact in complex ways that can often be beyond modeled mechanisms. Hence, models are simplifications that are developed to provide some answers to specific questions that arise when developing restoration and rehabilitation designs. They can be most useful in combination with other analysis techniques. Despite these limitations, it can be best to err on the side of caution and opt for the

development of more complex modeling if there is reasonable doubt regarding the modeling needs for a particular project. It can be quite awkward and expensive to deal with ramifications associated with the reconstruction of a failed project that could have been prevented by the development of hydraulic modeling.

Various types of hydraulic modeling options, in increasing order of complexity, are listed below:

1. Normal depth velocity computations, with material entrainment computations (example model: WinXSPro). This method is often used for such applications as rip rap sizing for bank stabilization and in the Rosgen geomorphic channel design methodology.
2. 1-D steady flow modeling (example model: HEC-RAS)
  - a. Shear stress and stream power modeling, to assess sediment conveyance continuity and existing versus proposed conditions. For example, locations of reduced shear stress indicates reaches where aggradation is most likely.
  - b. Sediment transport capacity modeling, to locate reaches where aggradation or degradation are most likely. In general, if sediment supply is in excess of sediment transport capacity, the channel will aggrade, and if capacity is greater than supply, the channel will degrade or armor. This analysis can be part of a sediment impact assessment, as discussed in Copeland et al. (2001) and NRCS (2007) Ch13.
  - c. Sediment transport modeling, to simulate expected channel variability (i.e. scour and deposition). This analysis can be part of a sediment impact assessment, as discussed in Copeland et al. (2001) and NRCS (2007) Ch13.
  - d. Stable channel design analysis, through use of the Copeland method (Figure 26), as well as the Regime and Tractive Force methods. Subroutines for these methods are provided in HEC-RAS.

- e. Water quality modeling, to simulate such constituents as temperature. For example, reductions in stream temperature from channel narrowing and shading can be simulated.



**Figure 26:** Analytical channel design using the Copeland method (Soar and Thorne 2001).

3. 1-D finite difference unsteady flow modeling, to assess the impacts of a hydrograph on hydraulic and sediment transport characteristics.
4. 2-D finite element steady- and unsteady flow modeling, to assess 2-dimensional flow characteristics.
5. 3-D finite element steady- and unsteady flow modeling, to assess 3-dimensional flow characteristics.

General information regarding hydraulic modeling for stream restoration and rehabilitation projects is provided in:

- [Fischenich and McKay 2011](#) Hydrologic Analyses for Stream Restoration Design
- [Brunner 2016](#) HEC-RAS Hydraulic Reference Manual
- [NRCS 2007, Ch6](#) Stream Hydraulics
- [NRCS 2007, Ch9](#) Alluvial Channel Design
- [NRCS 2007: Ch13](#) Sediment Impact Assessments
- [Soar and Thorne 2001](#) Channel Restoration Design for Meandering Rivers
- [Copeland et al. 2001](#) Hydraulic Design of Stream Restoration Projects

## Modeling Tools

Numerous modeling tools have been developed for performing hydrologic and ecologic analyses, including tools for the assessment of environmental flows and instream habitat. Examples are provided in the following sections.

### Hydraulic Analysis and Aquatic Habitat

- [DSS-WISE](#): 2-D hydraulic analyses, with GIS-based decision support tools
- [FishXing](#): Evaluation and assessment tool for fish passage through culverts
- [FLO-2D](#): 2-D mobile bed hydraulic modeling
- [FLOW-3D](#): 1-, 2- and 3-D steady flow simulation
- [HEC-RAS](#): Steady and unsteady 1-D hydraulic modeling of stream systems, including water quality simulations and temperature modeling
- [InSTREAM](#): an individual-based model of trout in a stream environment; predictions of how trout populations respond to many kinds of environmental and biological change
- [MIKE 11](#): 1-D modeling for simulating sediment transport and fluvial morphology, as well as ecological and water-quality assessments
- [MIKE 21C](#): 2-D modeling for simulating bed and bank erosion, scouring, and sedimentation
- [PHABSIM](#): Physical Habitat Simulation. Suite of programs designed to simulate habitat characteristics (depth, velocity, channel indices) in streams as a function of streamflow, and assess suitability for aquatic life
- [REMM](#): Riparian Ecosystem Management Model. A model used to simulate hydrology, nutrient dynamics, and plant growth in riparian areas
- [RHABSIM](#): Riverine Habitat Simulation. River hydraulics and aquatic habitat modeling using IFIM
  - [IFIM](#): Instream Flow Incremental Methodology. An analysis method that associates fish habitat, recreational opportunity, and woody vegetation

response to alternative water management schemes (Bovee et al. 1998). See SEFA

- [River2D](#): 2-D depth-averaged finite element model customized for fish habitat evaluation. Performs PHABSIM-type fish habitat analyses
- [Rivermorph](#): Stream restoration software developed for application of the Rosgen geomorphic channel design method
- [SEFA](#): System for Environmental Flow Analysis. Implements the substance of the Instream Flow Incremental Methodology
- [Sim-Stream](#): Physical habitat simulation model that describes the utility of instream habitat conditions for aquatic fauna, to simulate changes in habitat quality and quantity in response to flow alterations or changes in stream morphology
  - Implements the Mesohabitat Simulation Model ([MesoHABSIM](#))
- [SRH-2D](#): 2-D hydraulic, sediment, temperature, and vegetation modeling
- [SSTEMP](#): Stream Segment Temperature Model. Used to assess the effects of riparian shade, stream diversions, and stream returns on instream temperature, as well as alternative reservoir release proposals
- [WinXSP](#): Channel cross-section analysis

### Bank/Bed Stability and Sediment

- [BANCS](#): tool for the prediction of bank erosion rates (Rosgen et al. 2008)
- [BSTEM](#): spreadsheet tool for bank erosion simulation, including the affects of riparian vegetation (Simon et al. 2011)
- [CONCEPTS](#): model for the simulation of incised channel evolution, the evaluation of the long-term impacts of rehabilitation measures, and the reduction of sediment yield (Langendoen 2011)
- [WARSSS](#): Watershed Assessment of River Stability and Sediment Supply, a web-based assessment tool for evaluating suspended and bedload sediment in streams impaired by excess sediment
- [FLOWSED](#): modeling tool for the prediction of total annual sediment yield (NRCS 2007, Ch11)

- [POWERSED](#): modeling tool to estimate sediment transport capacity (NRCS 2007, Ch11)
- [RUSLE2](#): Revised Universal Soil Loss Equation
- [UBCRM](#): tools that quantifies the effect of bank vegetation on bank strength, and the resulting effects on channel geometry (Miller and Eaton 2011)

### Environmental Flows

- [ELOHA](#): Ecological Limit of Hydrologic Alteration. Provides a framework for assessing and managing environmental flows across regions, when resources are not available to evaluate individual streams (Poff et al. 2010). Colorado pilot study performed on the Roaring Fork and Fountain Creek (Sanderson et al. 2011)
- [HEC-EFM](#): Ecosystem Function Model, to help determine ecosystem responses to changes in flow regime of rivers and wetlands
- [HIP](#): Hydroecological Integrity Assessment Process. A suite of software tools for conducting hydrologic classification of streams, assessing instream flow needs, and analyzing historical and proposed hydrologic alterations
- [IHA](#): Indicators of Hydrologic Alteration. Facilitates hydrologic analysis for environmental flows in an ecologically meaningful manner
- [NATHAT](#): National Hydrologic Assessment Tool. Used to establish a hydrologic baseline, environmental flow standards, and evaluate past and proposed hydrologic modifications

## Watershed Modeling

- [AGWA](#): Automated Geospatial Watershed Assessment Tool (SWAT, KINEROS2)
- [BASINS](#): Better Assessment Science Integrating Point & Non-point Sources. Provides access to water quality databases, applies assessment and planning tools, and runs non-point loading and water quality models within a GIS format
- [HEC-HMS](#): Hydrologic Engineering Center – Hydrologic Modeling System. Simulates precipitation-runoff processes, from small agricultural or urban watersheds to large river basins
- [SWAT](#): Soil and Water Assessment Tool. River basin scale model for assessing the impact of land management practices in large, complex watersheds
- [SWMM](#): Storm Water Management Model. Software for rainfall-runoff simulation in primarily urban watersheds
- [WEAP](#): Water Evaluation and Planning. GIS-based modeling, with subroutines for rainfall-runoff, infiltration, evapotranspiration, crop requirements and yields, surface water/groundwater interactions, and water quality
- [WEPP](#): Water Erosion Prediction Project, a process-based erosion prediction model. [Forest Service WEPP](#) web-based interfaces are available, providing such tools as peak flow estimates for burned areas and erosion prediction from forest roads.
- [WinTR20](#): NRCS software for single event, watershed scale, rainfall-runoff modeling

## Flow Resistance Estimation

Fundamental in hydraulic modeling is flow resistance prediction. In-channel resistance is the result of roughness due to the bed and bank grain material, bedforms (such as dunes and step pools), plan form, vegetation, instream wood, and other obstructions. Floodplain flow resistance is primarily due to vegetation. In-channel resistance typically decreases as stage and discharge increase; resistance coefficients should be selected for the discharge of interest. Inaccurate resistance coefficients can result in inaccurate prediction of flow velocities and travel times, the miscategorization of flow regime, inaccurate design parameters for hydraulic structures, and unnecessary instability in computational modeling.

Manning's  $n$  is the most common resistance coefficient used in the United States, however Darcy Weisbach  $f$  and Chezy  $C$  are sometimes used. These resistance coefficients can be converted from one form to the other using

$$V = \frac{R^{2/3} S_f^{1/2}}{n} = \sqrt{\frac{8gRS_f}{f}} = C\sqrt{RS_f}$$

where  $V$  is the average velocity (m/s),  $R$  is the hydraulic radius (m) =  $A/P_w$ ,  $A$  is the flow area (m<sup>2</sup>),  $P_w$  is the wetted perimeter (m),  $S_f$  is the friction slope,  $g$  is acceleration due to gravity (m/s<sup>2</sup>),  $n$  is the Manning's coefficient,  $f$  is the Darcy-Weisbach friction factor, and  $C$  is the Chezy coefficient.

Flow resistance prediction is inexact, with varying results often obtained by different methodologies and practitioners. Experience is fundamental for the selection of the most appropriate resistance coefficient.

To address this potential variability, multiple methods should be used and the results compared for consistency. Following the three steps below is recommended when predicting flow resistance for 1-dimensional modeling:

1. **Consult a tabular guide** that provides a range of potential resistance values (Brunner 2010; NRCS 2007, Ch 6; Fischenich 2000; Arcement and Schneider 1989).

2. **Consult photographic guidance** (Barnes 1967; Aldridge and Garrett 1973; Hicks and Mason 1998; Yochum et al. 2014).
3. **Apply a quantitative prediction methodology**
  - a. Implement a quantitative prediction method appropriate for your stream type (see below).
  - b. Alternatively, implement a quasi-quantitative approach (Cowan 1956; Arcement and Schneider 1989)

Various tools are available for estimating flow resistance, with methods varying by channel type. The most relevant prediction methodologies are provided below:

### General Guidance

- [USGS](#): Verified Roughness Characteristics of Natural Channels (online photo guide)
- [Brunner 2016](#) HEC-RAS Hydraulic Reference Manual
- [NRCS 2007, Ch6](#) Stream Hydraulics
- [Fischenich 2000](#) Resistance Due to Vegetation.
- [Arcement and Schneider 1989](#) Guide for Selecting Manning's Roughness Coefficients for Natural Channels and Floodplains

### Low-Gradient Channels

(clay-, silt- and sand-bed channels)

In sand-bed channels, bedforms should initially be predicted, using such guidance as Brownlie (1983) and van Rijn (1984). Flow resistance varies by bedform type, as indicated in Table 6.

**Table 6:** Manning's  $n$  in sand-bed channels (compilation provided by Bledsoe 2007).

	bedform	range of Manning's $n$
Subcritical	plane bed	0.012 - 0.014
	ripples	0.018 - 0.03
	dunes	0.02 - 0.04
Transitional	plane bed	0.01 - 0.013
Supercritical	antidune	0.012 - 0.020
	chutes/pools	0.018 - 0.035

- [Arcement and Schneider 1989](#) Guide for Selecting Manning's Roughness Coefficients for Natural Channels and Floodplains
- [van Rijn 1984](#) Sediment Transport, Part III: Bedforms and Alluvial Roughness
- [Brownlie 1983](#) Flow Depth in Sand-Bed Channels
- [Aldridge and Garrett 1973](#) Roughness Coefficients for Stream Channels in Arizona
- [Barnes 1967](#) Roughness Characteristics of Natural Channels

### Mid-Gradient Channels

(~0.2% < slopes < ~2%, gravel- and cobble-bed, riffle-pool and plane bed channels)

- Hicks and Mason 1998 Roughness Characteristics of New Zealand Rivers
- [Bathurst 1985](#) Flow Resistance Estimation in Mountain Rivers
- [Jarrett 1984](#) Hydraulics of High-Gradient Streams
- Hey 1979 Flow Resistance in Gravel-Bed Rivers
- [Aldridge and Garrett 1973](#) Roughness Coefficients for Stream Channels in Arizona
- [Limerinos 1970](#) Determination of Manning's Coefficient from Measured Bed Roughness in Natural Channels.
- [Barnes 1967](#) Roughness Characteristics of Natural Channels

### High-Gradient Channels

(slopes > ~2%, cobble- and boulder-bed, step pool and cascade channels)

- [Yochum et al. 2014](#) Photographic Guidance for Selecting Flow Resistance Coefficients in High-Gradient Channels.
- [Yochum et al. 2012](#) Velocity Prediction in High-Gradient Channels
- [Jarrett 1984](#) Hydraulics of High-Gradient Streams
- [Barnes 1967](#) Roughness Characteristics of Natural Channels

The method described in Yochum et al. (2012) implements the variable  $\sigma_z$ , the standard deviation of the residuals of a bed elevation regression. An illustration of how this variable is computed from a longitudinal profile is shown (Figure 27).

### Floodplains

- [Arcement and Schneider 1989](#) Guide for Selecting Manning's Roughness Coefficients for Natural Channels and Floodplains.




Figure 27: Computation methodology for  $\sigma_z$  (Yochum et al. 2014).

## RESTORATION and REHABILITATION DESIGN FEATURES

---

Design features for stream restoration and rehabilitation are a function of the specific context, the goals and objectives of the project, and the design approach judged to be most appropriate for the situation. In general, a *process-based approach* to stream restoration design develops the baseline conditions that will allow the stream channel(s) and floodplains to evolve through fluvial processes and riparian succession towards more complex and dynamic habitats. In contrast, a *form-based approach* defines channel pattern, profile, and dimension and uses structural features (such as rock vanes, toe wood, and rip rap) to minimize channel adjustment. The use of a process-based approach has the advantage of allowing the stream and valley to adjust to potential disturbances, such as land use changes, fires, and climate change. This approach can often be used on public lands, where adjustments can be adapted to in deference for satisfying ecologically-based management priorities. However this approach is often not appropriate due to societal constraints – if infrastructure, residences, or productive agricultural land are threatened by channel and floodplain adjustments, a form-based approach may be most appropriate.

This section provides guidance for specific planning and design features that are relevant when developing stream restoration and rehabilitation projects. These include ecological and engineered approaches and structures as well as riparian corridor management. Guidance is provided for vegetation, livestock grazing, instream wood, stream habitat and environmental flows, fish passage and screening, beavers, bank stabilization, bed stabilization and stream diversions, planform design, and dam removal.

General references for the design of stream restoration and rehabilitation features are provided in the Overview of Stream Processes and Restoration section.

Stream restoration projects are subject to various regulatory programs. An overview of permitting requirements is provided in:

- [NRCS 2007, Ch17](#) Permitting Overview

### Vegetation


---

Riparian vegetation offers a great variety of benefits to stream channels, including binding soil together to reduce erosion rates and increase bank stability; increasing bank and floodplain flow resistance, reducing near-bank velocities and erosive potential; inducing sediment deposition to support stabilizing fluvial processes; providing shade to decrease solar radiation and stream temperatures, cover for hiding opportunities for fish, and sources of coarse instream wood to the stream channel, for habitat; and feeding energy input to streams in the form of dropped leaves and terrestrial insects. A key difference between braided and non-braided streams is the dominance of bank stabilizing vegetation (Braudrick et al. 2009; Crosato and Saleh 2011; Li and Millar 2011). Well vegetated stream channels with substantial quantities of in-channel wood can, in some cases, lead to stability measured in millennia (Brooks and Brierley 2002); the benefits of vegetation to bank stability should not be underestimated.

Additionally, at a watershed scale there are flood-reduction benefits to well-vegetated riparian corridors. While increases in riparian vegetation typically increase water surface stages along downstream higher-order streams, increased riparian vegetation along headwater streams can decrease flood discharges and stages on the higher-order streams, decreasing flood risk (Anderson 2006). In these situations, the increased roughness of the upstream riparian corridors increases flow resistance and flood attenuation, reducing discharges downstream while increasing flood duration.

In most streams, both woody and herbaceous wetland species are important for bank stabilization (Figure 28), with the combination being substantially more effective at bank stabilization than woody species alone (Hoag et al. 2011). A willow and sedge assemblage forms a highly-reinforced streambank, with the larger-size willow roots behaving like rebar and the very large

quantity of fine sedge roots acting like netting throughout the soil material (Polvi et al. 2014).



**Figure 28:** Channel stability ratings for various vegetative compositions (Wyman et al. 2006).

Since vegetation is an integral part of stream corridors, a revegetation component should be included in all stream restoration and rehabilitation projects. Where grazing exists, livestock management should also be included; otherwise, the wisdom of investment into a project can often be questionable. Additionally, previous channelization projects or induced channel incision may impact appropriate species in some locations – this should be a consideration. The vegetation used in stream corridor projects should typically be native, with the source material collected as close to the project site as possible, to assure inclusion of locally adapted plants and reduce costs. The use of such tools as a stinger (Figure 29) or an electric hammer drill can be valuable for willow pole and bundle plantings, especially in riparian areas with substantial amounts of underlying gravels and cobbles. In addition to willows, it is equally important to establish herbaceous plants, including forbs, sedges and rushes, in the riparian zone. Riparian trees can also provide substantial amounts of bank stabilization (Polvi et al. 2014), though take considerably longer to colonize. Ecological site descriptions and historic photographs are valuable for assessing what vegetative communities to restore.



**Figure 29:** The use of a stinger for vegetative plantings (nativerevegetation.org).

References helpful for understanding the role of plants for bank stabilization, as well as for planning and designing vegetation aspects of projects, include:

- [Polvi et al. 2014](#) Modeling the functional influence of vegetation type on streambank cohesion.
- [Cramer 2012](#) Washington State Stream Habitat Restoration Guidelines
- [Cooper and Merritt 2012](#) Assessing the water needs of riparian and wetland vegetation in the western United States
- [Caplan et al. 2012](#) Growth Response of Coyote Willow (*Salix exigua*) Cuttings in Relation to Alluvial Soil Texture and Water Availability
- [Hoag et al. 2011](#) Description, Propagation, and Establishment of Wetland-Riparian Grass and Grass-Like Species in the Intermountain West
- [Hoag & Ogle 2011](#) The Stinger – A Tool to Plant Unrooted Hardwood Cuttings (Figure 29)
- [Quistberg and Stringham 2010](#) Sedge Transplant Survival in a Reconstructed Channel: Influences of Planting Location, Erosion, and Invasive Species

- [Dosskey et al. 2010](#) The Role of Riparian Vegetation in Protecting and Improving Chemical Water Quality in Streams
- [Dreenen and Fenchel 2010](#) Deep-Planting Techniques to Establish Riparian Vegetation in Arid and Semiarid Regions
- [Hoag & Ogle 2010](#) Willow Clump Plantings
- [Stromberg et al. 2009](#) Influence of Hydrologic Connectivity on Plant Species Diversity Along Southwestern Rivers – Implications for Restoration.
- [Dreesen and Fenchel 2009](#) Revegetating Riparian Areas in the Southwest “Lessons Learned”
- [Hoag 2009](#) Vertical Bundles: A Streambank Bioengineering Treatment to establish willows and dogwoods on streambanks
- [Hoag et al. 2008](#) Field guide for Identification and Use of Common Riparian Woody Plants of the Intermountain West and Pacific Northwest Regions.
- [Sotir and Fischenich 2007](#) Live Stake and Joint Planting for Streambank Erosion Control.
- [NRCS 2007, TS-14I](#) Streambank Soil Bioengineering
- [Hoag 2007](#) How to Plant Willows and Cottonwoods for Riparian Restoration
- [Hoag and Sampson 2007](#) Planting Willow and Cottonwood Poles under Rock Riprap
- [Fischer 2004](#) Using Soil Amendments to Improve Riparian Plant Survival in Arid and Semi-arid Landscapes.
- [Steed and DeWald 2003](#) Transplanting Sedges (*Carex* spp.) in Southwestern Riparian Meadows
- [Shafer and Lee 2003](#) Willow Stake Installation – Example Contract Specifications
- [Hoag & Fripp 2002](#) Streambank Soil Bioengineering Field Guide for Low Precipitation Areas
- [Hoag et al. 2001](#) Users Guide to Description, Propagation, and Establishment of Wetland Plant Species and Grasses for Riparian Areas in the Intermountain West.
- [Fischenich 2001c](#) Plant Material Selection and Acquisition.
- [Sotir and Fischenich 2001](#) Live and Inert Fascine Streambank Erosion Control.
- [Goldsmith et al. 2001](#) Determining Optimal Degree of Soil Compaction for Balancing Mechanical Stability and Plant Growth Capacity
- [Fischenich 2000](#) Irrigation Systems for Establishing Riparian Vegetation

For additional publications and information, please refer to the following websites:

- [Riparian Publications](#): NRCS
- [Wetland Publications](#): NRCS
- [Potential Seed and Plant Sources](#): NRCS

Along urban streams with banks hardened by steel or concrete, floating riverbanks are available for providing, according to their manufacturer Biomatrix Water, “attractive waterscape aesthetic, improved water quality, biodiversity and habitat benefits.” More information is available [here](#).

## Livestock Grazing Management

Livestock grazing in riparian zones can negatively influence herbaceous species composition, productivity, and commonly modifies the structure and composition of woody plant communities (George et al. 2011). The result is often destabilized streambanks and reduced channel cover and shading. The decreased stability leads to overwidened channels, decreased flow depth and, in combination with the decreased shading, substantial increases in peak summer temperatures. Temperature increases are a substantial concern with cold water fishes and are especially problematic for native endangered, threatened, or species of concern. Additionally, stream access paths and loafing areas (shaded areas) within riparian zones have been found to be the most intensive non-bank sources of sediment and phosphorus in streams (Tufekcioglu et al. 2012); these areas can deserve special attention in livestock grazing mitigation efforts. Consequently, exclusion, rest and deferment (Table 8), are typically critical components of stream restoration and rehabilitation projects in grazed areas.

As discussed in George et al. (2011), altered grazing practices designed for maintaining or rehabilitating riparian zone health include:

- 1) controlling the timing and duration of riparian grazing by fencing riparian pastures within existing pastures
- 2) fencing riparian areas to exclude livestock
- 3) change the kind and class of livestock
- 4) reducing grazing duration
- 5) reducing grazing intensity
- 6) controlling season of use

A grazing management planning process is presented (Figure 30). Since willows are some of the most common vegetation types implemented in streambank stabilization, it is especially important to provide grazing practices that encourage willow growth. Different geomorphic stream types and channel evolution phases have varying sensitivities to grazing practices. Guidance for grazing systems that are compatible with willow-dominated plant communities is provided (Table 7).

Available information and guidance for riparian grazing management includes:

- [Wyman et al. 2006](#) Grazing Management Processes and Strategies for Riparian-Wetland Areas
- [Leonard et al. 1997](#) Riparian Area Management – Grazing Management for Riparian-Wetland Areas
- [Ehrhart and Hansen 1997](#) Effective Cattle Management in Riparian Zones: A Field Survey and Literature Review

**Table 7:** Grazing system compatibility with willow-dominated plant communities, as developed by Kovalchik and Elmore (1991), (George et al. 2011).


Grazing practice	Compatibility with willows
Corridor fencing	Highly
Riparian pasture	Highly
Spring (early-season) grazing	Highly
Winter grazing	Highly
Two-pasture rotation	Moderately
Three-pasture rest rotation	Moderately
Three-pasture deferred rotation	Moderately
Spring-fall pastures	Incompatible
Deferred grazing	Incompatible
Late-season grazing	Incompatible
Season-long grazing	Incompatible

Excessive ungulate (hooved mammal) wildlife browsing can cause negative riparian impacts similar to the impacts of domestic livestock grazing. In some locations, a mechanism allowing excessive browsing by elk and deer may be the elimination of large predators, such as cougars and wolves. In areas that have had top predator extirpations, subsequent additional browsing by native ungulates have been shown to have long-term negative impacts on vegetative recruitment and extent, resulting in increased bank erosion, decreased channel depths, and increased channel widths, incision, and braiding (Beschta and Ripple 2012).

**Table 8:** Evaluation and rating of grazing strategies for stream-riparian-related fisheries values, based on observations by Platts (1990). (George et al. 2011)

Strategy	Level to which riparian vegetation is commonly used	Control of animal distribution (allotment)	Stream bank stability	Brushy species condition	Seasonal plant regrowth	Stream-riparian rehabilitative potential	Rating
Continuous season-long (cattle)	Heavy	Poor	Poor	Poor	Poor	Poor	1 <sup>1</sup>
Holding (sheep or cattle)	Heavy	Excellent	Poor	Poor	Fair	Poor	1
Short duration-high intensity (cattle)	Heavy	Excellent	Poor	Poor	Poor	Poor	1
Three herd-four pasture (cattle)	Heavy to moderate	Good	Poor	Poor	Poor	Poor	2
Holistic (cattle or sheep)	Heavy to light	Good	Poor to good	Poor	Good	Poor to excellent	2-9
Deferred (cattle)	Moderate to heavy	Fair	Poor	Poor	Fair	Fair	3
Seasonal suitability (cattle)	Heavy	Good	Poor	Poor	Fair	Fair	3
Deferred rotation (cattle)	Heavy to moderate	Good	Fair	Fair	Fair	Fair	4
Stuttered deferred rotation (cattle)	Heavy to moderate	Good	Fair	Fair	Fair	Fair	4
Winter (sheep or cattle)	Moderate to heavy	Fair	Good	Fair	Fair to good	Good	5
Rest-rotation (cattle)	Heavy to moderate	Good	Fair to good	Fair	Fair to good	Fair	5
Double rest-rotation (cattle)	Moderate	Good	Good	Fair	Good	Good	6
Seasonal riparian preference (cattle or sheep)	Moderate to light	Good	Good	Good	Fair	Fair	6
Riparian pasture (cattle or sheep)	As prescribed	Good	Good	Good	Good	Good	8
Corridor fencing (cattle or sheep)	None	Excellent	Good to excellent	Excellent	Good to excellent	Excellent	9
Rest-rotation with seasonal preference (sheep)	Light	Good	Good to excellent	Good to excellent	Good	Excellent	9
Rest or closure (cattle or sheep)	None	Excellent	Excellent	Excellent	Excellent	Excellent	10


<sup>1</sup>Rating scale based on 1 (poorly compatible) to 10 (highly compatible) with fishery needs.



**Figure 30:** A grazing management planning process (Wyman et al. 2006).

## Large Wood

Streams in forested areas could be expected to have large wood (large woody debris, LWD; Figure 31) present within the channel and floodplain to some extent prior to anthropogenic manipulation, but such wood has been frequently removed with the objectives of increasing flow conveyance, removing hazards to infrastructure and navigation, and (controversially) improving fish migration in streams with debris jams along the Pacific Coast of North America (1950s through early 1970s, Reeves et al. 1991). Removal of large wood has been found to reduce bedform variability (Brooks et al. 2003), with the lack of pools resulting in ecological consequences of reduced hyporheic exchange, increased water temperatures, and fewer available refugia for aquatic life from peak temperatures and winter ice. Increased riparian flow roughness, from large wood as well as streambank and floodplain vegetation, substantially impacts flood wave celerity, and hydrograph dispersion and skew, with increased vegetation resulting in higher Manning's  $n$  values, lower velocities, and lower peak discharges as floodwaves disperse downstream (Anderson et al. 2006). This effect is moderated by flood magnitude, with smaller-magnitude floods more impacted by vegetation than larger floods.



**Figure 31:** Substantial wood loading in a high-gradient stream channel (Fraser Experimental Forest, Colorado).

The presence of substantial amounts of in-channel large wood can increase lateral connectivity with the floodplain while decreasing sediment and nutrient transport downstream, temporarily retaining this material within the riparian zone as opposed to “leaking” this material downstream through a stream system largely devoid of wood

and in a potentially alternative stable state (Wohl and Beckman 2014). The presence of large wood can mitigate, to an extent, the impacts of the greatly-increased release of sediment into smaller stream channels after wildfires through the accumulation of sediment behind jams (Short et al. 2015).

Velocity increases resulting from channel clearing activities have been found to lead to channel widening, reduced sinuosity, increased slope, channel incision, reduced groundwater levels, bed material coarsening, and increased rates of lateral migration (Brooks et al. 2003). Large wood, when present, provides more frequent, larger, and deeper pools (Richmond and Fausch 1995), accumulation of finer sediment (Buffington and Montgomery 1999; Klaar et al. 2011; Jones et al. 2011), increased flow resistance (Shields and Gippel 1995; David et al. 2011), and diversity in hydraulic gradients (Klaar et al. 2011). These morphological and hydraulic adjustments can provide substantial ecological benefits, through increased pool refugia from high flows, summertime temperatures and winter ice, increased cover, accumulation of spawning gravels, and nutrient enrichment.

For example, large wood removal was a consequence of such extensive anthropogenic disturbances in Rocky Mountain streams as railroad tie drives (Figure 32) and placer mining.



**Figure 32:** Railroad tie drives in the Rocky Mountains resulted in instream wood removal and reduction in channel variability (courtesy of the American Heritage Center).

With tie drives, cut ties were driven downstream during peak snowmelt to railroad construction sites, requiring the removal of all large wood to allow passage of the ties and severely altering the natural geomorphic channel features (Ruffing et al. 2015). The similar practices of log drives and


splash damming were utilized to transport logs to downstream mills along the West Coast of the United States, as well as in other areas of North America (Higgins and Reinecke 2015).

A summary of the ecological benefits of instream wood is provided at the following sites:

- [BBC Radio4](#): Nature – Wood and Water
- [Maser and Sedell 1994](#) From the Forest to the Sea: The Ecology of Wood in Streams, Rivers, Estuaries, and Oceans

### Large Wood Structures

The inclusion of large wood into stream designs can be fundamental for satisfying project objectives focused on habitat restoration, since the increase in geomorphic and hydraulic variability benefits ecological diversity. Wood structures, such as windthrow emulation (Figure 33, Figure 35), toe wood (Figure 53), log vanes (Figure 47), log jams (Figure 55), and other large wood features (Figure 34; Figure 36) can provide these benefits in the short term. In the long term, proper management of riparian zones for wood production is needed for providing sustainable wood recruitment to stream channels.




**Figure 33:** Windthrow emulation, with a single log placed between two standing trees to create a pivot and lock point (A), and with the addition of a second log with root wad attached to create an X pattern (B). To increase stability, logs should be  $\geq 1.5$  times the bankfull width (with attached rootwad) or  $\geq 2$  times the bankfull width (without an attached rootwad). (Graphic and guidance from ODF ODFW 2010).

The use of unanchored, strategically-placed large wood, such as windthrow emulations, cost substantially less than anchored wood augmentation. In small- and medium-sized streams in Northern California it was found that unanchored wood projects cost only 22% of the average cost of anchored wood augmentation (Carah et al. 2014), which can allow watershed-

scale implementation. Unanchored wood can also more-closely mimic natural wood-loading processes, leading to greater effectiveness. However, large wood movement can be a risk to bridge and culvert infrastructure. Large wood can also be a recreational hazard. Wohl et al. (2016) provides a framework for managing such risks.



**Figure 34:** Introduced large wood (photo credit: Paul Powers).



**Figure 35:** Typical plan view illustrating windthrow emulation orientations (Graphic from ODF ODFW 2010).



**Figure 36:** Complex timber revetment (photo credit: Tim Abbe, USBR and ERDC 2016).

References and tools helpful for the incorporation of large wood into stream restoration and rehabilitation projects include:

- [USBR and ERDC 2016](#) National Large Wood Manual: Assessment, Planning, Design, and Maintenance of Large Wood in Fluvial Ecosystems: Restoring Process, Function, and Structure
- [Wohl et al. 2016](#) Management of Large Wood in Streams: An Overview and Proposed Framework for Hazard Evaluation
- [Rafferty 2016](#) Computational Design Tool for Evaluating the Stability of Large Wood Structures (NSAEC TN-103). [Tool](#)
- [Use of Wood in Stream Restoration](#) NRCS webinar, 2015 (Jon Fripp, Rob Sampson)
- [Carah et al. 2014](#) Low-Cost Restoration Techniques for Rapidly Increasing Wood Cover in Coastal Coho Salmon Streams
- [Knutson and Fealko 2014](#) Large Woody Material – Risk Based Design Guidelines
- [USBR 2014a](#) Improving Public Safety of Large Wood Installations: Designing and Installing Safer large Wood Structures
- [USBR 2014b](#) Modeling How Large Woody Debris Structures Affect Rivers: Modeling River Changes from Large Wood Structures and Other Instream Structures
- [Cramer 2012](#) Washington State Stream Habitat Restoration Guidelines
- Wohl, E. 2011 (in [Simon et al. 2011](#)): Seeing the Forest and the Trees – Wood in Stream Restoration in the Colorado Front Range, United States
- Abbe and Brooks 2011 (in [Simon et al. 2011](#)) Geomorphic, Engineering, and Ecological Considerations When Using Wood in River Restoration.
- [ODF ODFW 2010](#) Guide to Placement of Wood, Boulders and Gravel for Habitat Restoration
- [NRCS 2007, TS14J](#) Use of Large Woody Material for Habitat and Bank Protection
- [NRCS 2007, TS14H](#) Flow Changing Techniques
- [Shields et al. 2004](#) Large Woody Debris Structures for Sand-Bed Channels
- [NRCS 2001](#) Incorporation of Large Wood Into Engineered Structures
- [D’Aoust and Millar 2000](#) Stability of Ballasted Woody Debris Habitat Structures
- [Hilderbrand et al. 1998](#) Design Considerations for Large Woody Debris Placement in Stream Enhancement Projects
- [Gippel et al. 1996](#) Hydraulic Guidelines for the Re-Introduction and Management of Large Woody Debris in Lowland Rivers
- Reeves et al. 1991 Rehabilitating and Modifying Stream Habitats (in [Influences of Forest Rangeland Management on Salmonid Fishes and Their Habitats](#))

## Stream Habitat and Environmental Flows

In general, fish and other aquatic and riparian corridor species need appropriate and sufficient physical habitat, water quality, and instream flows to thrive. Channelized and incised streams, as well as streams without connections to their floodplains, are fundamental impairments along many stream corridors. The lack of thalweg longitudinal profile complexity is a common physical impairment for cold-water fishes. The removal of instream wood, through channel clearing and snagging activities, has contributed substantially to the lack of cover and complexity. One of the most common water quality impairments is excessive peak summer temperatures, which can be related to flow depletions associated with reservoirs and stream diversions. With substantial competition for water in the semi-arid and arid West, and increasing pressure on water resources in other parts of the United States, sufficient discharge to maintain habitat extent and quality is an ongoing challenge.

The desired biologic response from water quality and riparian management improvements can be substantially delayed behind the time of implementation. For example, macroinvertebrate recovery was found to lag 6 years behind water quality improvements in a stream impacted by coal mine drainage (Walter et al. 2012), and the diversity of macroinvertebrates and fish have been found to be better predicted by watershed land use characteristics from 40 years ago rather than contemporary characteristics (Harding et al. 1998). An extended monitoring program (and patience) may be required to assess the ultimate success of a project.

Fundamental for instream fish habitat is sufficient flow to support natural stream function. Competing water needs often minimizes instream flow for supporting ecologic function and sufficient water availability is an ongoing problem for providing habitat for all aquatic life. Reservoir regulation, irrigation withdrawals, urbanization, and groundwater depletion alter the magnitude, frequency, duration, timing, and rate of change of the natural flow regime, impairing stream function (Poff et al. 1997). Similarly, a natural (or balanced) sediment regime is also required for proper ecosystem function (Wohl et al. 2015).

To improve riparian ecologic function in areas of altered streamflow, methods have been developed for defining natural flow regimes and applying them to the stream systems (Tharme 2003; Olden and Poff 2003; Arthington et al. 2006; Hall et al. 2009; Bartholow 2010; Poff et al. 2010; Richter et al. 2011; Sanderson et al. 2012). However, competing uses for limited water resources will be an ongoing problem for stream restoration projects.

Structures such as deflectors, boulder placements, riprap bank protection, cover structures, and log grade control structures have been used since at least the 1930s to enhance instream habitat by creating pools, cover, and bed stabilization. Reeves et al. (1991) provides a historic overview of habitat enhancement. In an evaluation of 70-year-old structures, Thompson (2002) found a mix of successes and failures of such structures for providing preferred habitat conditions, with deterioration or failure of the structures, variable pool depths that are not as deep as natural pools in adjacent reaches, and rip rap that impaired vegetative growth. However, some habitat benefits are still being realized by 70% of the surviving structures, despite wood logs being extensively implemented in their construction and a greater than 100-year flood experienced. While structures can be beneficial in the shorter term for providing habitat enhancement, natural geomorphic mechanisms are likely more enduring for providing narrowed channels, undercut banks, and instream wood recruitment. Hence, habitat enhancement can be viewed as two pronged, with structures that do not inhibit vegetative growth used to provide shorter term habitat improvements, and vegetative planting and livestock (and wildlife) management used to provide favorable habitat for the longer term.

The following structures and techniques have been used to enhance habitat for fish and other aquatic species:

- Provision of sufficient instream flows.
- Channel modification and reconstruction: Alteration of the channel planform, cross section, and profile, including channel realignment and riparian meadow restoration from incised or channelized conditions (Figure 37).

- Levee modification or removal: Floodplain connectivity reestablishment by modifying or removing levees.
- Side channel and off-channel habitat establishment or enhancement: Construction, restoration, or reconnection of side channels to the main stream channel.



**Figure 37:** Meadow restoration of Whychus Creek, Oregon (photo credit: Russ McMillian).

- Aquatic organism passage restoration: Reestablishing upstream and downstream passage blocked by culverts, flow diversions weirs, and other artificial obstructions (discussed in the following section).
- Toe wood: Wood armoring of streambanks to provide cover, refuge from high velocities, and bank stabilization (Figure 53).
- Beaver reintroduction: Use of reintroduced beaver colonies to recover degraded stream corridors (Figure 38; discussed in the [Beavers section](#)).



**Figure 38:** Beaver dam in a previously-incised stream channel (Trout Creek, Colorado; photo credit: Barry Southerland).

- Spawning gravel cleaning and placement: techniques to increase the quantity and quality of spawning habitat.
- Large wood complexes and log jams: Adding or trapping large wood in stream channels to provide improved morphological and biological conditions and to replace historical wood that was removed (Figure 55).
- Cross vane and W-weirs: Rock weirs installed to maintain pool habitat and channel grade control (Figure 57).
- Log or rock bank vane: Bank vane installed to narrow channels, provide bank stabilization, and to maintain pool habitat (Figure 46, Figure 47, Figure 48).
- Bank-attached boulders, mid-channel boulders, and boulder clusters: Placement of large boulders (>3 ft in diameter), to produce more heterogeneous stream channel morphology and provide refuge from high velocities for fish (Reeves et al. 1991, Shen and Diplas 2010).
- Excavated pools in armored beds on meander bends, with helical flow providing pool maintenance.
- Constructed riffles: Engineered riffles designed to increase hydraulic complexity and habitat, restore fish passage, and stabilize mobile bed streams (Newbery et al. 2011).
- LUNKERS (Little Underwater Neighborhood Keepers Encompassing Rheotactic Salmonids): Provide cover, refuge from high velocities, and bank stabilization; [NRCS 2007, TS140](#)).
- Drop structures: Engineered structures to prevent upstream migration of non-native fish. Gabion and log weir structures need to be avoided, due to poor effectiveness (Thompson and Rahel 1998) and shorter longevity.

Design guidance for some of these habitat-enhancing features is provided in the following sections, as well as in the [Large Wood](#) section. Additional guidance and background material with respect to aquatic habitat enhancement and environmental flows is provided in:

- [Novak et al. 2015](#) Protecting Aquatic Life from Effects of Hydrologic Alteration (Draft)
- [Pierce et al. 2013](#) Response of Wild Trout to Stream Restoration over Two Decades in the Blackfoot River Basin, Montana.
- [Cramer 2012](#) Washington State Stream Habitat Restoration Guidelines
- Biron et al. 2011 (in [Simon et al. 2011](#)): Combining Field, Laboratory, and Three-Dimensional Numerical Modeling Approaches to Improve Our Understanding of Fish Habitat Restoration Schemes
- Newberry et al. 2011 (in [Simon et al. 2011](#)) Restoring Habitat Hydraulics with Constructed Riffles
- [ODF ODFW 2010](#) Guide to Placement of Wood, Boulders and Gravel for Habitat Restoration
- [Flosi et al. 2010](#) California Salmonid Stream Habitat Restoration Manual.
- [Saldi-Caromile et al. 2004](#) Stream Habitat Restoration Guidelines (Washington State)
- [Stewardson et al. 2004](#) Evaluating the Effectiveness of Habitat Reconstruction in Rivers.
- [Sylte and Fischenich 2000](#) Rootwad Composites for Streambank Erosion Control and Fish Habitat Enhancement
- [Fischenich and Morrow 2000](#) Streambank Habitat Enhancement with Large Woody Debris
- [Fischenich and Seal 2000](#) Boulder Clusters
- [Morrow and Fischenich 2000](#) Habitat Requirements for Freshwater Fishes
- Reeves et al. 1991 Rehabilitating and Modifying Stream Habitats (in [Influences of Forest Rangeland Management on Salmonid Fishes and Their Habitats](#))

## Aquatic Organism Passage

Fish and other aquatic organism passage is often included as an objective for stream restoration work, with road crossings and irrigation diversion weirs being common barriers. Passage is important, since anadromous fish require passage to complete their lifecycles and freshwater fish populations need habitat diversity to flourish, with isolated populations more vulnerable to disturbances, such as drought, fire, debris flows, and floods.

Studies have shown that fish often have extensive ranges. For example, cutthroat trout have been observed moving downstream during the onset of winter in the Middle Fork Salmon River by an average of 57 miles (91 km), have been found to migrate 1 to 45 miles (2 to 72 km) on the Blackfoot River on spawning runs, and, on smaller streams, migrations of 1.1 miles (1.8 km) have been measured (Young 2008). Short, isolated reaches often lack critical resources, such as deep pools for refuge from peak summer temperatures and winter refuge from ice. Fish passage allows populations to move to locations where conditions are most suitable.

Fish passage barriers result from a variety of anthropogenic causes. *Road crossings* provide substantial and numerous barriers to fish connectivity. The primary barrier mechanism to upstream passage is high velocity, though shallow depth is also relevant (Warren and Pardew 1998). Crossings that most substantially alter flow from natural conditions may cause the most substantial barriers, which provides a conceptual model for passage design. Fish passage barriers from *irrigation diversion dams* can also be pervasive. For example, the upper Rio Grande between Del Norte and Alamosa has 23 diversions, at a spacing of 2 miles (3 km) on average. This is typical for many Rocky Mountain streams. Additionally, *whitewater parks*, for instream kayaker recreation, feature constricted flow and high velocities that can induce a partial barrier (by size class) to fish passage (Fox et al. 2016).

To gain understanding of how fish attempt to cope with barriers and use fish passage structures, it can be helpful to “think like a fish.” As discussed in Williams et al. 2012, in slow flowing streams migrating fish may likely distribute across the

channel. However, as velocity in flowing streams increases, due to increased gradient or obstructions, upstream migrants tend to swim in the vicinity of the channel edges, near the bank or bed. These upstream-migrating fish hence seek areas with higher velocity gradients. In contrast, downstream migrants tend to swim in regions with the highest channel velocities, with the lowest velocity gradients. Different species have different swimming capabilities, leading to different design requirements for passage structures.

To reduce road crossing barriers, the replacement of culverts with open box structures and bridges is recommended. When culverts are necessary, velocity and length are both relevant (Warren and Pardew 1998), with higher velocities mitigated to an extent by shorter culverts (Belford and Gould 1989). Additionally, elimination of outlet drops (Figure 39), the installation of a removable fishway (Clancy and Reichmuth 1990) or baffles (MacDonald and Davies 2007), and non-circular or open-bottom culverts with wide and natural bed conditions can all be helpful in reducing barriers. The stream simulation method, a procedure for providing natural-bed channel conditions through culverts, was developed by the USFS to provide aquatic organism passage (USFS 2008).



**Figure 39:** Culvert outlet drop, with Coho.

To reduce the impact of diversion barriers, several options are available including diversion consolidation; construction of a diversion weir type that reduces velocity and rate of water surface drop, such as a cross-vane; the installation of a bypass structure when the diversion is not needed; the use of an infiltration gallery or pumped

diversion; and the addition of a properly-maintained fish passage structure (Figure 40; Schmetterling et al. 2002).



**Figure 40:** Pool and weir fishway.

Helpful references discussing barriers and methods for fish passage include:

- [Barnard et al. 2013](#) Water Crossing Design Guidelines (Washington State)
- [Axness and Clarkin 2013](#) Planning and Layout of Small Stream Diversions (USFS)
- [Cramer 2012](#) Washington State Stream Habitat Restoration Guidelines
- [Bunt et al. 2012](#) Performance of Fish Passage Structures at Upstream Barriers to Migration
- Newberry et al. 2011 (in [Simon et al. 2011](#)) Restoring Habitat Hydraulics with Constructed Riffles
- [Flosi et al. 2010](#) California Salmonid Stream Habitat Restoration Manual.
- [USFS 2008](#) Stream Simulation: An Ecological Approach to Providing Passage for Aquatic Organisms at Road-Stream Crossings
- [Mooney et al. 2007](#) Rock Ramp Design Guidelines (USBR)
- [Ficke and Myrick 2007](#) Fish Barriers and Small Plains Fishes – Fishway Design Recommendations and the Impact of Existing Instream Structures
- [NRCS 2007, TS-14N](#) Fish passage and screening design
- [MacDonald and Davies 2007](#) Improving the upstream passage of two galaxiid fish species through a pipe culvert
- [Rosgen 2006](#) Cross-Vane, W-Weir, and J-Hook Vane structures: Description, Design, and Application for Stream Stabilization and River Restoration
- [Clarkin et al. 2005](#) National Inventory and Assessment Procedure For Identifying Barriers to Aquatic Organism Passage at Road-Stream Crossings
- [Saldi-Caromile et al. 2004](#) Stream Habitat Restoration Guidelines (Washington State)
- [Bates et al. 2003](#) Design of Road Culverts for Fish Passage
- [DVWK 2002](#) Fish Passes – Design, Dimensions and Monitoring.
- [Bates 2000](#) Fishway Guidelines for Washington State.
- [Clay 1995](#) Design of Fishways and Other Fish Facilities
- [Clancy and Reichmuth 1990](#) A detachable fishway for steep culverts

USFS & NRCS tutorials and webinars discussing road crossing barriers and mitigation:


- [Stream Simulation Culvert Design and Performance – A USFS Perspective](#) (Dan Cenderelli, Mark Weinhold, Paul Anderson, 2013)
- [RESTORE \(Episode 10\): Aquatic Organism Passage Restoration](#) USFS Region 5 (California) summary of barrier removal
- [A Tutorial on Field Procedures](#) for Inventory and Assessment of Road-Stream Crossings for Aquatic Organism Passage (Michael Love, Ross Taylor, Susan Firor, Michael Furniss)
- [Culvert Case Studies](#): From here and there (Mark Weinhold)
- [The Biology of Culvert Barriers](#): The Biology of Assessment, Monitoring, and Research of Aquatic Organism Passage at Culverted Road-Stream Crossings (8 presentations; 2003)

In situations where species isolation is necessary, for example to isolate cutthroat trout from introduced species, fish passage barriers are required. In a study of the success and failure of

Greenback Cutthroat trout translocations, almost half of the failed projects were unsuccessful due to reinvasions by non-native salmonids (Harig et al. 2000). For barriers to be effective, they must prevent species from jumping over the obstacle, from swimming around the obstacle during high flows, or from swimming through the obstacle, through interstitial spaces (gabions). A key component of an effective barrier includes a splash pad, to minimize fish acceleration.

## Fish Screening

In addition to diverting water, stream diversions can also divert a substantial amount of adult and juvenile fish, resulting in high mortality (Burgi et al. 2006; Roberts and Rahel 2008). This is especially problematic with threatened and endangered fish. Fish screens (Figure 41) allow the diversion of water without the accompanying fish and allow the safe return of the fish to their stream of origin.



**Figure 41:** Fixed, inclined fish screen (courtesy Burgi et al. 2006).

Types vary substantially and include vertical fixed plate screens, non-vertical fixed plate screens, vertical traveling screens, rotary drum screens, pump intake screens, and infiltration galleries. Resources available for designing fish screening facilities for stream diversions include:

- [Befford 2013](#) Pocket Guide for Screening Small Water Diversions
- [Axness and Clarkin 2013](#) Planning and Layout of Small Stream Diversions (USFS)
- [Mesa et al. 2010](#) Biological Evaluations of an Off-Stream Channel, Horizontal Flat-Plate Fish Screen: The Farmers Screen.
- [NRCS 2007, TS-14N](#) Fish Passage and Screening Design
- [Burgi et al. 2006](#) Fish Protection at Water Diversions: A Guide for Planning and Designing Fish Exclusion Facilities
- [Nordlund and Bates 2000](#) Fish Protection Screen Guidelines for Washington State

Vendors of fish screening equipment include:

- [Farmers Screen](#) (FCA)
- [Hydrolox](#) traveling fish screens
- [Intake Screen Inc](#) (ISI)

## Beavers

Through their dam-building activities, North American beavers (*Castor canadensis*) can cause a great deal of morphological and ecological changes in riparian corridors (Figure 42). The conversion of single thread channels to multi-thread within beaver-meadow complexes can reflect a stable state that has been frequently dominant within the historical range of variability of many stream valleys. For millions of years beaver played a major role as a geomorphic agent in floodplain development and salmonid evolution.

The conversion of land from terrestrial to wetland behind beaver ponds alters sediment transport, nutrient cycling, and vegetative succession (Westbrook et al. 2011). These changes can be to the benefit of the riparian ecosystem, potentially supporting stream restoration project objectives. Specifically, beavers ponds can increase baseflow, reduce bank erosion, collect sediment, reduce phosphorus levels, reduce daily temperature fluctuations, and increase mean temperature (potentially increasing temperature to more optimal levels in high-elevation streams). Beaver activity can also increase willow cover; beaver introduction and dam building activities increase water table elevations, create side channels, and distribute willow cuttings that can then propagate asexually throughout the expanded willow-favored landscape (Burchsted et al. 2010, McColley et al. 2012). Additionally, the construction and failure of beaver dams, which promote geomorphic diversity, has been associated with increased cutthroat trout redd construction (Bennett et al. 2014) Beaver ponds can also provide overwinter habitat by providing refugia from winter ice (Collen and Gibson 2001).

However, the potential negative consequences of beaver ponds include increased mean temperatures (potentially displacing salmonids in lower-elevation streams), reduced dissolved oxygen, increased evaporation, loss of spawning sites (in the ponds), and possibly causing barriers to some species of fish during low flow (Collen and Gibson 2001).



**Figure 42:** Beaver-dominated stream corridor (photo credit: Barry Southerland).

Background information and guidance for the incorporation of beavers and beaver-like structures into stream restoration projects include:

- [Pollock et al. 2015](#) The Beaver Restoration Guidebook: Working with Beaver to Restore Streams, Wetlands, and Floodplains
- [MacFarlane et al. 2014](#) The Utah Beaver Restoration Assessment Tool: A Decision Support and Planning Tool
- [Beaver Dam Flow Device Training](#) Training video, by Animal Protection of New Mexico
- [The Beaver Solution](#), by the Lands Council
- [Beaver Solutions](#) A company providing beaver management solutions
- [Beavers: Wetlands and Wildlife](#) Educational not-for-profit for educating people about beavers
- [Beaver Wiki](#) Shared information on the impacts and benefits of beavers in streams
- [Bring Back the Beaver Campaign](#) Occidental Arts and Ecology Center
- [Cheap & Cheerful Stream Restoration – With Beaver](#) Webinar on techniques and research surrounding partnering with beaver in restoration design, from Utah State University (Joe Wheaton and Jeremy Christensen)
- [Cramer 2012](#) Washington State Stream Habitat Restoration Guidelines
- [DeVries et al. 2012](#) Emulating Riverine Landscape Controls of Beaver in Stream Restoration

- [Burchsted et al. 2010](#) The River Discontinuum: Applying Beaver Modifications to Baseline Conditions for Restoration of Forested Headwaters
- [Saldi-Caromile et al. 2004](#) Stream Habitat Restoration Guidelines (Washington State)


While oftentimes beneficial to riparian ecosystems, beaver can be frustrating for landowners and agricultural producers. Beavers' instinctual tendency to block trickling water is often in conflict with such structures as irrigation diversions and road culverts. Additionally, while sub-irrigation of meadows by beaver activity can be highly beneficial for hay production, pond and associated groundwater levels need to be limited, and often reduced for harvest.

Beaver deceivers, a fence that discourages damming due to its large perimeter (Figure 43), and beaver bafflers, a cylindrical wire mesh or perforated pipe device that provides stage control (Figure 44) can be valuable methods for inhibiting dam construction and maintaining or altering water levels. They function by eliminating the trickling sound that beavers instinctually block, or by preventing beaver access. Beaver deceivers need to have a substantial perimeter length; otherwise they will still be blocked, while beaver bafflers can require high maintenance in streams with substantial amounts of fine sediment that can block the inlet perforations.


References helpful for designing such structures include:

- [Pollock et al. 2015](#) The Beaver Restoration Guidebook: Working with Beaver to Restore Streams, Wetlands, and Floodplains
- [Boyles and Savitzky 2008](#) An Analysis of the Efficacy and Comparative Costs of Using Flow Devices to Resolve Conflicts with North American Beavers Along Roadways in the Coastal Plain of Virginia.
- [Simon 2006](#) Solving Beaver Flooding Problems through the Use of Water Flow Control Devices.
- [Langlois and Decker 2004](#) The Use of Water Flow Devices in Addressing Flooding Problems Caused by Beaver in Massachusetts.

- [Brown et al. 2001](#) Control of Beaver Flooding at Restoration Projects
- [Fentress 1997](#) An Improved Device For Managing Water Levels in Beaver Ponds
- [Clemson University 1994](#) The Clemson Beaver Pond Leveler



**Figure 43:** Beaver deceiver (Brown et al. 2001).



**Figure 44:** Beaver baffler (Clemson University 1994).

## Bank Stabilization

Excessive bank erosion is a stream impairment that practitioners are oftentimes asked to address, with bank stabilization being a fundamental treatment for reducing excessive erosion rates and resulting sediment loads. However, bank erosion is a normal process in alluvial streams and fixing a stream in place so that it can no longer migrate can have undesirable consequences. Rather than fixing a stream in place, substantial reduction in bank erosion rates is oftentimes the most realistic and appropriate focus of bank stabilization projects. To this end, defining the acceptable rates of bank erosion is an important consideration when setting objectives and developing project designs.

There are two primary processes involved in bank erosion: hydraulic force and geotechnical failure. Hydraulic action is erosion induced by near-bank shear and steep velocity gradients, as is found at the outer banks of meander bends, while geotechnical failure is often caused by reduced bank strength, soil piping, and undercutting (Knighton 1998). The primary bank instability mechanism involved in a project needs to be identified to assure the most appropriate remediation measure is implemented. Streambank stratigraphy, including the relationship between textural changes in the bank profile and cohesive properties of the soil layers, will help the designer plan more effective bank stabilization measures. This principle applies to both vegetative and structural stabilization measures.

There are numerous types of protruding streambank stabilization structures, including stream barbs, vanes, bendway weirs, spur dikes, and log jams. Description of the various types of structures are included in NRCS (2007) TS-14H, Radspinner et al. (2010), and Biedenharn et al. (1997). In general, they act as deflectors, in that they deflect flow velocities and sediment. Through this deflection, they induce flow resistance and energy dissipation. Stream barbs, vanes, and bendway weirs tend to shift the secondary currents in channel bends (helical flow patterns) away from the banks by forcing overtopping flow perpendicular to the structure alignment, decreasing near-bank flow velocity. These reduced velocities allow planting and recruitment

of bank vegetation, enhancing bank stability. However, a common unintended consequence of protruding streambank stabilization structures is shifts in the channel thalweg causing altered downstream meander translation. Hence, the use of streambank stabilization structures may force the need for additional structural streambank stabilization downstream, which in turn can induce additional bank erosion further downstream.

Besides protruding streambank stabilization measures, longitudinal bank stabilization features are also commonly implemented. Such structures include toe wood and soil bioengineering practices, as well as rock walls and rip rap.

Bank stabilization structures can have direct negative impacts on recreational water users. Guidance for addressing recreational boating needs is provided in:

- [Colburn 2012](#) Integrating Recreational Boating Considerations Into Stream Channel Modification & Design Projects

A principle cause of streambank instability is insufficient vegetative cover. Root systems can reinforce bank material up to 20,000 times more than equivalent sediment without vegetation (Knighton 1998), with vegetative condition explaining much of the variability in bank erosion rates.

Reflecting this natural process, bank stabilization can be most affectively addressed through a combination of both structures and vegetation. Structures can provide immediate relief to excessive erosion rates while vegetation can be more enduring for bank stabilization in the longer term. Hence, a bank stabilization strategy can be viewed as two pronged, with structures that minimize impairments to vegetative growth used to provide shorter term stabilization and vegetative planting implemented to provide minimized erosion rates for the longer term. Such a method also provides greater aquatic habitat benefits.

Bank stabilization structures are most-commonly constructed primarily of rock or wood, though various engineered products are also available. Both rock and wood have advantages and disadvantages. Rock is more enduring but susceptible to shifting and resulting loss of function, and can impair growth of riparian

vegetation. Wood can be more native to a project site, can be more beneficial to aquatic biota, and can be a more flexible material to work with during construction, but is susceptible to buoyant forces and decay.

Both rock and log bank protection measures can require the use of filters, such as geotextile filter fabric, to reduce structural porosity and material piping through the structure. Cable and rebar are also incorporated into structures at times. However, there are legacy issues that can arise when introducing synthetic geotextiles, cable, and rebar into a fluvial setting that should be considered. The long-term fate of such materials should be a consideration.

Limited information is available regarding wood decay rates for instream structures, though wood has been documented as being relatively functional in streambank structures for as long as 70 years (Thompson 2002). Decay rates vary as a function of surface area and water quality. Larger-diameter logs (which have less surface area per wood volume) decay at lower rates (Diez et al. 2002; Spanhoff and Meyer 2004) while wood in streams with higher nutrient levels decay at higher rates (Diez et al. 2002; Gulis et al. 2004; Spanhoff and Meyer 2004). Differing rates of decay can also be expected by species and amount of wet/dry cycling.

When planning the use of any structural measures in stream restoration and rehabilitation projects, it is essential that geomorphic processes and project objectives are first considered before specific structural measures are planned. Oftentimes, professionals have a tendency to default to specific structure types without full consideration of the geomorphic context and suitability for a specific project. Additionally, this tendency can lead to bias for or against specific features, potentially excluding the best remediation practice for a specific circumstance. This practice has led to many inappropriate or less effective designs being implemented.

Terminology describing the various types of deflectors can be confusing and, sometimes, conflicting. Additionally, other types of bank stabilization methods are used in stream restoration and rehabilitation projects, including woody armoring revetments, such as root wads,

toe wood, and logs; soil bioengineering; log jams, rock walls; and rip rap. Descriptions and references for the various types of bank stabilization methods are discussed in the following sections. General guidance for environmentally sensitive bank protection measures are provided below:

- [NCHRP 2004](#): Environmentally Sensitive Channel- and Bank-Protection Measures.

### Stream Barbs

Stream barbs are low dike structures (Figure 45), with tops surfaces that slope from the bank into the channel and extend from the bank no more than 1/3 of the channel width. They are typically angled into the oncoming flow, which diverts flow away from the bank as the flow passes over the structure. Barbs can be constructed of graded riprap (solid) or arrangement of individual boulders (porous). Besides the benefit of reducing near-bank velocities, they can also enhance habitat through creating and maintaining scour pools immediately downstream of the structures. Design guidance for stream barbs is provided in:

- [NRCS 2007, TS-14H](#) Flow Changing Techniques
- [NRCS 2007, TS-14C](#) Stone Sizing Criteria
- [Welch and Wright 2005](#) Design of Stream Barbs
- [Castro and Sampson 2001](#) Design of Stream Barbs



**Figure 45:** Stream barb (courtesy Jon Fripp).

## Vanes

Vanes are a subcategory of barbs. Vanes (Figure 46, Figure 47, Figure 48) are implemented with an upstream orientation of 20 to 30 degrees from the tangent to the bank line, have a crest elevation at or just below the bankfull level of the bank, and slope at 2 to 7 degrees dip towards the tip. Dip angle increases with increasing stream slope and bed material size. Vanes can be constructed of either rock or logs, or a combination. Design guidance for vanes is provided in:

- [Knutson and Fealko 2014](#) Large Woody Material – Risk Based Design Guidelines
- [Bhuiyan et al. 2010](#): Bank-Attached Vanes for Bank Erosion Control and Restoration of River Meanders
- [Bhuiyan et al. 2009](#) Effects of Vanes and W-Weir on Sediment Transport in Meandering Channels
- [NRCS 2007, Chapter 11](#) Rosgen Geomorphic Channel Design
- [NRCS 2007, TS-14G](#) Grade Stabilization Techniques
- [NRCS 2007, TS-14H](#) Flow Changing Techniques
- [NRCS 2007, TS-14C](#) Stone Sizing Criteria
- [NRCS 2007, TS-14J](#) Use of Large Woody Material for Habitat and Bank Protection
- [Johnson et al. 2001](#) Use of Vanes for Control of Scour at Vertical Wall Abutments




Figure 46: J-hook vane (NRCS 2007).



Figure 47: Log vanes at low flow providing bank stabilization and channel narrowing 2 years after construction (Milk Creek, Colorado).



Figure 48: Log J-hook vane providing bank stabilization and pool scour 4 years after construction (Pisgah National Forest, North Carolina; photo credit: Brady Dodd).

## Bendway Weirs

Bendway weirs are rock structures with flat to slightly sloped surfaces (from the bank towards the thalweg) that generally extend from 25% to 50% of the channel width from the bank into the channel (Figure 49; Radspinner et al. 2010). Since these structures protrude further into the channel than barbs, their spacing tends to be further apart. Due to their longer lengths, they are less appropriate than barbs in small radius bends (Radspinner et al. 2010). Bendway weirs are oriented upstream at angles typically between 50 and 80 degrees to the bank tangent (NRCS 2007, TS14H). Design guidance is provided in:

- [Kinzli and Thornton 2009](#) Predicting Velocity in Bendway Weir Eddy Fields
- [NRCS 2007, TS-14H](#) Flow Changing Techniques
- [NRCS 2007, TS-14C](#) Stone Sizing Criteria
- [Julien and Duncan 2003](#) Optimal Design Criteria of Bendway Weirs from Numerical Simulations and Physical Model Studies
- [Winkler 2003](#) Defining Angle and Spacing of Bendway Weirs




**Figure 49:** Bendway weir (Lagasse et al. 2009).

## Spur Dikes

A spur dike is a protruding feature from the stream bank out into the channel, with a horizontal top surface that is typically above the high-flow water level. They are typically oriented perpendicular to the bank but can also be angled either upstream or downstream (Figure 50). Flow patterns and scour pool development in the vicinity of spur dikes, as well as other information relevant for design, are provided in:

- [Lagasse et al. 2009](#) Bridge Scour and Stream Instability Countermeasures: Experience, Selection, and Design Guidance
- [Kuhnle et al. 2008](#) Measured and Simulated Flow near a Submerged Spur Dike
- [Fazli et al. 2008](#) Scour and Flow Field Around a Spur Dike in a 90° Bend
- [NRCS 2007, TS14B](#) Scour Calculations
- [Kuhnle et al. 2002](#) Local Scour Associated with Angled Spur Dikes
- [Kuhnle et al. 1999](#) Geometry of Scour Holes Associated with 90° Spur Dikes
- [Copeland 1983](#) Bank Protection Techniques Using Spur Dikes



**Figure 50:** Spur dike (Walla Walla District USACE via Google Images).

## Bioengineering


Streambank soil bioengineering (Figure 51, Figure 52) is a technology that uses engineering practices combined with ecological principles to assess, design, construct, and maintain living vegetative systems (NRCS 2007, TS14I). A related methodology that uses similar approaches to stabilization is *Induced Meandering* (Zeedyk 2009; Zeedyk and Clothier 2009), which provides riparian restoration techniques for addressing incised stream channels.

In addition to the previous references provided for vegetation, references for the use of soil bioengineering in stream restoration and rehabilitation projects include:

- [Giordanengo et al. 2016](#) Living Streambanks: A Manual of Bioengineering Treatments for Colorado Streams
- [Rafferty 2016](#) Computational Design Tool for Evaluating the Stability of Large Wood Structures (NSAEC TN-103). [Tool](#).
- [Knutson and Fealko 2014](#) Large Woody Material – Risk Based Design Guidelines
- [Soil Bioengineering](#) Washington State Department of Transportation
- [Zeedyk 2009](#) An Introduction to Induced Meandering – A Method for Restoring Stability to Incised Stream Channels.
- [Zeedyk and Clothier 2009](#) Let the Water do the Work – Induced Meandering, and Evolving Method for Restoring Incised Channels
- [NRCS 2007, TS-14I](#) Streambank Soil Bioengineering
- [Eubanks and Meadows 2002](#) A Soil Bioengineering Guide for Streambank and Lakeshore Stabilization
- [Hoag & Fripp 2002](#) Streambank Soil Bioengineering Field Guide for Low Precipitation Areas
- [Sotir and Fischenich 2003](#) Vegetated Reinforced Soil Slope Streambank Erosion Control
- [Allen and Fischenich 2001](#) Brush Mattresses for Streambank Erosion Control
- [Allen and Fischenich 2000](#) Coir Geotextile Roll and Wetland Plants for Streambank Erosion Control



**Figure 51:** Installation of coir fascines (NRCS 2007, TS14I).



**Figure 52:** Rootwad with footer section (Eubanks and Meadows 2002).

## Toe Wood

Toe wood is a method for constructing a bankfull bench or floodplain surface using primarily unmilled wood as the structural component, soil lifts to create the bankfull surface, and vegetation (Figure 53, Figure 54). These materials act in unison to create a stable matrix that provides a well armored constructed floodplain surface using natural materials. After vegetation is well established, toe wood will eventually degrade allowing for natural fluvial processes to continue at a slower rate. Toe wood can provide a substantial quantity of high-quality cover for fish.

The following references can be helpful for toewood design:

- [USBR and ERDC 2016](#) National Large Wood Manual: Assessment, Planning, Design, and Maintenance of Large Wood in Fluvial Ecosystems: Restoring Process, Function, and Structure
- [Rafferty 2016](#) Computational Design Tool for Evaluating the Stability of Large Wood Structures (NSAEC TN-103). [Tool](#).
- [Use of Wood in Stream Restoration](#) NRCS webinar, 2015 (Jon Fripp, Rob Sampson)
- [Knutson and Fealko 2014](#) Large Woody Material – Risk Based Design Guidelines
- [Cramer 2012](#) Washington State Stream Habitat Restoration Guidelines
- Abbe and Brooks 2011 (in [Simon et al. 2011](#)) Geomorphic, Engineering, and Ecological Considerations When Using Wood in River Restoration
- [MN DNR 2010](#) Stream Restoration – Toe Wood-Sod Mat
- [Sotir and Fischenich 2003](#) Vegetated Reinforced Soil Slope Streambank Erosion Control
- [NRCS 2007, TS14J](#) Use of Large Woody Material for Habitat and Bank Protection
- [Shields et al. 2004](#) Large Woody Debris Structures for Sand-Bed Channels
- [NRCS 2001](#) Incorporation of Large Wood Into Engineered Structures
- [D'Aoust and Millar 2000](#) Stability of Ballasted Woody Debris Habitat Structures




Figure 53: Toe wood cross section (Wildland Hydrology).




Figure 54: Two cells of a toe wood plan view. This configuration is intended for high-bank locations, with rock-ballasted sills embedded in the bank.

## Log Jams

Log jams (Figure 55; similar to structures known as engineered log jams, large woody debris structures, and wood complexes) are log structures that deflect erosive flows, increase flow resistance, and promote sediment deposition. These structures also provide habitat for aquatic organisms. They compensate for stream reaches that are deficient of instream wood due to past practices. The large wood used in these structures includes whole trees with attached rootwads, pieces of trees with or without rootwads, and cut logs. Unlike many rock structures, such as stream barbs (Figure 45), log jams are permeable to flow.

In some situations, these structures can significantly raise local water surface elevations (especially if more debris is caught during a flood); this can be problematic or prohibited in some situations. These structures can cause unanticipated local bank erosion and shifts in the river thalweg (which may or may not be a problem), and may encourage avulsions in some situations. They can also be hazardous for recreational river users. If the material in these structures is mobilized, the wood can block downstream bridge or culvert openings.



**Figure 55:** Log jam (photo credit: Paul Powers).


The following references and tools can be helpful for the design of log jams:

- [USBR and ERDC 2016](#) National Large Wood Manual: Assessment, Planning, Design, and Maintenance of Large Wood in Fluvial Ecosystems: Restoring Process, Function, and Structure
- [Rafferty 2016](#) Computational Design Tool for Evaluating the Stability of Large Wood Structures (NSAEC TN-103) [Tool](#).
- [Bouwes et al. 2016](#) Adapting Adaptive Management for Testing the Effectiveness of Stream Restoration: An Intensely Monitored Watershed Example
- [Use of Wood in Stream Restoration](#) NRCS webinar, 2015 (Jon Fripp, Rob Sampson)
- [Knutson and Fealko 2014](#) Large Woody Material – Risk Based Design Guidelines
- [Engineered Log Jam Calculations](#): Spreadsheet tool for the design of engineered log jams (Scott Wright)
- [Cramer 2012](#) Washington State Stream Habitat Restoration Guidelines
- Abbe and Brooks 2011 (in [Simon et al. 2011](#)) Geomorphic, Engineering, and Ecological Considerations When Using Wood in River Restoration
- [Southerland 2010](#) Performance of Engineered Log Jams in Washington State: A Post-Project Appraisal
- [NRCS 2007, TS14J](#) Use of Large Woody Material for Habitat and Bank Protection
- [Saldi-Caromile et al. 2004](#) Stream Habitat Restoration Guidelines (Washington State)
- [Shields et al. 2004](#) Large Woody Debris Structures for Sand-Bed Channels
- [NRCS 2001](#) Incorporation of Large Wood Into Engineered Structures
- [D’Aoust and Millar 2000](#) Stability of Ballasted Woody Debris Habitat Structures

## Rock Walls

Rock walls (Figure 56) can be an effective practice for toe armoring as well as high bank stabilization in constrained locations. References for the design of such structures include:

- [NRCS 2007, TS-14K](#) Streambank Armor Protection with Stone Structures
- [NRCS 2007, TS-14M](#) Vegetated Rock Walls



**Figure 56:** Vegetated rock wall (NRCS 2007, TS-14M).

## Riprap

Rip rap is a basic bank protection tool that can be used alone or in combination with other structural methods. Rip rap is a needed bank stabilization tool in some situations, such as where infrastructure protection is required. The use of rip rap should be minimized, since rip rap can impair vegetative growth and eliminate ecologically-important undercut banks for many decades (Thompson 2002). Generally, rip rap is an ecological impairment in streams, by locally reducing sediment and wood input to stream channels, simplifying geomorphic complexity, and potentially causing local incision, bed material coarsening, and reduction in hyporheic exchange (Reid and Church 2015). However, rip rap has been noted to be beneficial to some species in degraded systems or where little bank complexity already exists. Additionally, the negative impacts of rip rap can be mitigated by burying the rock in an embankment and creating a floodplain and streambanks within a riparian zone beyond this line of riprap protection.

References available for sizing rip rap include:

- [Froehlich 2011](#) Sizing loose rock riprap
- [Lagasse et al. 2009](#) Bridge Scour and Stream Instability Countermeasures: Experience, Selection, and Design Guidance
- [NRCS 2007, TS-14C](#) Stone Sizing Criteria
- [NRCS 2007, TS-14K](#) Streambank Armor Protection with Stone Structures

## Bed Stabilization and Stream Diversions


Grade control is a frequently-used component of stream restoration and rehabilitation projects, to provide for bed stabilization. Incising streams can often lead to increased bank destabilization, since the incised streams increase bank height and lower water tables, changing the plant community composition to a type that provides lower bank stability. This mechanism is inherent in the channel evolution model, as described in the Preliminary Assessment section.

Channel spanning vanes and weirs are common grade control structures, with cross vanes (Figure 57) and large wood (Figure 58; Figure 59) structures provided as examples. Cross vane structures are also useful component for gravity-fed stream diversions. The development of step-pool bedforms in channels, through construction of steps or provision of armoring material, can also be an effective method of channel bed stabilization in small high-gradient channels, such as urbanizing watersheds with altered flow regimes. Bed stabilization structures can act as substantial barriers to some types of aquatic life passage; this should be accounted for in their application.

A common task when using a cross vane or similar structure for a flow diversion is setting the elevation of the structure. It is necessary to build sufficient head to allow a stream diversion during low flow while, at the same time, minimizing drop that could cause barriers to aquatic life. A method to address this need is to select a minimum streamflow at which a specific diversion amount is needed and use a flow rating curve to set a vane elevation that allows the permitted diversion.



**Figure 57:** Cross vane on the Rio Blanco, CO (NRCS 2007, Ch11).



**Figure 58:** Large wood grade-control structure (Knutson and Fealko 2014).



**Figure 59:** Log "rock and roll" channel in the Trail Creek watershed, Colorado (USFS 2015).

For a U-type cross vane structure, the upstream water surface elevation can be estimated using a method developed by Holmquist-Johnson (2011) for discharges less than 2/3 bankfull:

$$h_{weir} = \left[ \frac{Q}{4.386\sqrt{2g} \left(\frac{2}{3}W_u\right) \left(\frac{W_u}{Z_u}\right)^{-0.601} \left(\frac{L_t}{T_w}\right)^{-0.429}} \right]^{2/3}$$

where  $h_{weir}$  is the depth of water over the weir (m) relative to the throat crest,  $Q$  is the discharge over the weir ( $m^3/s$ ),  $g$  is acceleration due to gravity ( $m/s^2$ ), and  $T_w$  is the channel top width (m, Figure 36).  $Z_u$ , the effective weir height (m), is computed as:

$$Z_u = \frac{1}{3} \left( \frac{(T_w - W_t) \tan \phi}{2 \sin \theta} \right) + Z_d$$

where  $W_t$  is the throat width (m),  $Z_d$  is the upstream drop height (m),  $\theta$  is the arm angle, and  $\phi$  is the arm slope (Figure 60). Also,  $L_t$  is the effective weir length along the structure crest (m), can be computed as:

$$L_t = W_t + 2 \left( \frac{(T_w - W_t)}{2} \frac{1}{\sin \theta \cos \phi} \right)$$


and  $W_u$ , the effective weir width (m), is computed as:

$$W_u = W_t + 2 \left( \frac{(Z_u - Z_d) \sin \theta}{\tan \phi} \right)$$

For discharges greater than 2/3 bankfull, the following equation was developed:

$$h_{weir} = \left[ \frac{Q}{9.766\sqrt{2g} \left(\frac{2}{3}W_u\right) \left(\frac{W_u}{Z_u}\right)^{-0.73} \left(\frac{L_t}{T_w}\right)^{-0.359}} \right]^{2/3}$$

These equations were developed using the results of 3-dimensional computational modeling and verified using both laboratory and field data.



**Figure 60:** Variable descriptions for U-vane stage-discharge rating (Holmquist-Johnson 2011).

References helpful for stream diversion structures and bed stabilization (including the development of step-pool channels) include:

- [Knutson and Fealko 2014](#) Large Woody Material – Risk Based Design Guidelines
- [Axness and Clarkin 2013](#) Planning and Layout of Small Stream Diversions (USFS)
- [Colburn 2012](#) Integrating Recreational Boating Considerations Into Stream Channel Modification & Design Projects
- [Scurlock et al. 2012](#) Equilibrium Scour Downstream of Three-Dimensional Grade-Control Structures
- Holmquist-Johnson 2011 Numerical Analysis of River Spanning Rock U-Weirs – Evaluating Effects of Structure Geometry on Local Hydraulics
- [Thomas et al. 2011](#) Effects of Grade Control Structures on Fish Passage, Biological Assemblages and Hydraulic Environments in Western Iowa Streams – A Multidisciplinary Review
- [Thornton et al. 2011](#) Stage-Discharge Relationships for U-, A-, and W-Weirs in Un-Submerged Flow Conditions
- [Zimmermann et al. 2010](#) Step-pool stability – Testing the jammed state hypothesis
- [Chin et al. 2009](#) Linking Theory and Practice for Restoration of Step-pool Streams
- [Holburn et al. 2009](#) Quantitative Investigation of the Field Performance of Rock Weirs
- [Vuyovich et al. 2009](#) Physical Model Study of Cross Vanes and Ice
- [Bhuiyan et al. 2009](#) Effects of Vanes and W-Weir on Sediment Transport in Meandering Channels
- [NRCS 2007, Ch11](#) Rosgen Geomorphic Channel Design
- [NRCS 2007, TS14B](#) Scour Calculations
- [NRCS 2007, TS14G](#) Grade Stabilization Techniques
- [NRCS 2007, TS 14P](#) Gullies and Their Control
- [Chin and Phillips 2006](#) The Self-Organization of Step-Pools in Mountain Streams


- [Saldi-Caromile et al. 2004](#) Stream Habitat Restoration Guidelines
- [Castro and Sampson 2001](#) Design of Rock Weirs

Additionally, the following website provides information on research performed on river-spanning rock structures in coordination with the U.S. Bureau of Reclamation:

- [USBR: River-Spanning Rock Structures Research](#)

## Planform Design

Natural channels are inherently sinuous. Hence, channel relocations require the design of planform characteristics (Figure 61).



- L Meander wavelength
- $M_L$  Meander arc length
- w Average width at bankfull discharge
- $M_A$  Meander amplitude
- $R_c$  Radius of curvature
- $\theta$  Arc angle

**Figure 61:** Schematic illustrating variables describing channel planform characteristics (NRCS 2007, Ch12).

Design guidance for developing appropriate planform geometry is provided in:

- [NRCS 2007, Ch12](#) Channel Alignment and Variability Design.
- [Soar and Thorne 2001](#) Channel Restoration Design for Meandering Rivers

## Dam Removal

Dam removal is increasing being implemented as a primary approach for addressing such impairments as the lack of longitudinal connectivity for aquatic organisms. This is oftentimes in response to concerns (and Endangered Species Act listings) for anadromous fish, such as in the Pacific Northwest. The following links provide information on dam removals for stream restoration:

- [Clearinghouse for Dam Removal Information](#): Online repository for documents about proposed and completed dam removal projects.
- [The Geomorphic Response of Rivers to Dam Removal](#) (Gordon Grant)
- [Undamming the Elwha](#) The Documentary, 2012 (Katie Campbell and Michael Werner)
- [East et al. 2015](#) Large-Scale Dam Removal on the Elwha River, Washington, USA: River Channel and Floodplain Geomorphic Change.
- [Wilcox et al. 2014](#) Rapid Reservoir Erosion, Hyperconcentrated Flow, and Downstream Deposition Triggered by Breaching of 38 m Tall Condit Dam, White Salmon River, Washington.
- [Cannatelli and Curran 2012](#) Importance of Hydrology on Channel Evolution Following Dam Removal: Case Study and Conceptual Model
- [Pearson et al. 2011](#) Rates and Processes of Channel Response to Dam Removal with a Sand-Filled Impoundment.
- [Science Findings 2009](#) A Ravenous River Reclaims its True Course: The Tale of Marmot Dam's Demise.
- [Hoffert-Hay 2008](#) Small Dam Removal in Oregon: A Guide for Project Managers
- [EOEEA 2007](#) Dam Removal in Massachusetts: A Basic Guide for Project Proponents.
- [Lenhart 2003](#) A preliminary Review of NOAA's Community-Based Dam Removal and Fish Passage Projects.
- [Bednarek 2001](#) Undamming Rivers: A Review of the Ecological Impacts of Dam Removal.

- [Smith et al. 2000](#) Breaching a Small Irrigation Dam in Oregon: A Case History.

## **MONITORING and REPORTING**

---

Nationally, more than \$1 billion is spent each year on stream restoration and rehabilitation projects though only 10% of projects report post-project monitoring and assessment (Bernhardt et al. 2005). Consequently, relatively little information has been gathered on the effectiveness of restoration practices. To help develop a greater understanding of the effectiveness of tax dollars spent, the collection and reporting of post-project monitoring data should be priority. Monitoring should be performed to assess fulfillment of project objectives. One of the most important aspects of monitoring streams is to help understand the importance of feedback mechanisms, drawing inferences regarding the impacts of restoration practices. The results should be documented in project reports, at a minimum, and, for more interesting projects, in conference proceedings and case study journal articles.

Guidance for monitoring protocols and other information relevant for post-project monitoring are provided at:

- [BLM 2015](#) AIM National Aquatic Monitoring Framework: Introducing the Framework and Indicators for Lotic Systems
- [Archer et al. 2014a](#) Effectiveness monitoring for streams and riparian areas: Sampling protocol for stream channel attributes (PIBO)
- [Archer et al. 2014b](#) Effectiveness Monitoring Program for Streams and Riparian Areas: 2014 Sampling Protocol for Vegetation Parameters (PIBO)
- [Burton et al. 2011](#) Multiple Indicator Monitoring of Stream Channels and Streamside Vegetation
- [Bonfantine et al. 2011](#) Guidelines and Protocols for Monitoring Riparian Forest Restoration Projects.
- [Rosgen et al. 2008](#) River Stability Field Guide
- [Doyle et al. 2007](#) Developing Monitoring Plans for Structure Placement in the Aquatic Environment (USFS)
- [NRCS 2007, Ch11](#) Rosgen Geomorphic Channel Design

- [NRCS 2007, Ch16](#) Maintenance and Monitoring
- [Guilfoyle and Fischer 2006](#) Guidelines for Establishing Monitoring Programs to Assess the Success of Riparian Restoration Efforts in Arid and Semi-Arid Landscapes
- [Kershner et al. 2004](#) Guide to Effective Monitoring of Aquatic and Riparian Resources (PIBO)
- [Thom and Wellman 1996](#) Planning Aquatic Ecosystem Restoration Monitoring Programs

## **SUMMARY**

---

Guidance for stream restoration and rehabilitation projects has been developed by a wide variety of practitioners and academics. This material is so extensive that it can be difficult for professionals to find the most relevant references available for specific projects. To assist practitioners sort through this extensive literature, this technical note has been developed to provide a guide to the guidance. Through the use of short literature reviews and hyperlinked reference lists, this technical note is a bibliographic repository of information available to assist professionals with planning, analyzing, and designing stream restoration and rehabilitation projects.

## REFERENCES

- Abbe, T., Brooks, A. 2011. Geomorphic, Engineering, and Ecological Considerations When Using Wood in River Restoration. In "Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools" (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 399-418.
- Aldridge, B. N., and J. M. Garrett, 1973. Roughness Coefficients for Stream Channels in Arizona, U.S. Geological Survey Open-File Report, Tucson, Arizona.
- Alexander, G.G., Allan, J.D. 2007. Ecological Success in Stream Restoration – Case Studies from the Midwestern United States. *Environmental Management* 40, 245-255.
- Allen, H.H., Fischenich, C. 2000. Coir Geotextile Roll and Wetland Plants for Streambank Erosion Control. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-04.
- Allen, H.H., Fischenich, C. 2001. Brush Mattresses for Streambank Erosion Control. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-23.
- Anderson, B.G. 2006. Quantifying the Interaction Between Riparian Vegetation and Flooding: From Cross-Section to Catchment Scale. PhD Dissertation. Department of Civil and Environmental Engineering, The University of Melbourne.
- Anderson, B.G., Rutherford, I.D., Western, A.W. 2005. An analysis of the influence of riparian vegetation on the propagation of flood waves. *Environmental Modeling & Software* 21, 1290-1296.
- Arcement, G.J., Schneider, V.R. 1989. Guide for Selecting Manning's Roughness Coefficients for Natural Channels and Flood Plains, U. S. Geological Survey Water-Supply Paper 2339.
- Archer, E.K., Scully, R.A., Henderson, R.; Roper, B.B., Heitke, J.D., Boisjolie, B. 2014. Effectiveness monitoring for streams and riparian areas: sampling protocol for stream channel attributes. PACFISH/INFISH Biological Opinion Effectiveness Monitoring Program (PIBO-EMP) Staff, Multi-federal Agency Monitoring Program; Logan, UT.
- Archer, E.K., Van Wagenen, A.R., Coles-Ritchie, M., Ebertowski, P.; Leary, R.J. 2014. Effectiveness monitoring for streams and riparian areas: sampling protocol for vegetation parameters. PACFISH/INFISH Biological Opinion Effectiveness Monitoring Program (PIBO-EMP) Staff – Multi Federal Agency Monitoring Program; Logan, UT.
- Arthington, A.H., Bunn, S.E., Poff, N.L., Naiman, R.J. 2006. The Challenge of Providing Environmental Flow Rules to Sustain River Ecosystems. *Ecological Applications* 16(4), 1311-1318.
- Axness, D.S., Clarkin, K. 2013. Planning and Layout of Small Stream Diversions. USDA Forest Service, National Technology and Development Program.
- Baldigo, B.P., Warren, D.R., Ernst, A.G., Mulvihill, C.I. 2008. Response of Fish Populations to Natural Channel Design Restoration in Streams of the Catskill Mountains, New York. *North American Journal of Fisheries Management* 28, 954-969.
- Barbour, M.T., Gerritsen, J., Snyder, B.D. Stribling, J.B. 1999. Rapid Bioassessment Protocols for Use in Streams and Wadeable Rivers: Periphyton, Benthic Macroinvertebrates and Fish, Second Edition. U.S. Environmental Protection Agency; Office of Water; Washington, D.C., EPA 841-B-99-002.
- Barnard, R. J., Johnson, J., Brooks, P., Bates, K. M., Heiner, B., Klavas, J. P., Ponder, D.C., Smith, P.D., Powers, P. D. (2013), *Water Crossings Design Guidelines*, Washington Department of Fish and Wildlife, Olympia, Washington.
- Barnes, H.H. 1967. Roughness Characteristics of Natural Channels, U. S. Geological Survey Water-Supply Paper 1849.
- Bartholow, J.M. 2010. Constructing and Interdisciplinary Flow Regime Recommendation. *Journal of the American Water Resources Association* (46) 5, 892-906.
- Bates, K. 2000. Draft Fishway Design Guidelines for Washington State. Washington Department of Fish & Wildlife.
- Bates, K., Barnard, B., Heiner, B., Klavas, J.P., Powers, P.D. 2003. Design of Road Culverts for Fish Passage. Washington Department of Fish and Wildlife.
- Bathurst, J.C. 1985. Flow Resistance Estimation in Mountain Rivers. *Journal of Hydraulic Engineering* 111(4), 625-643.
- Becker, R. and Russell, M.L. 2014. Fish Detection and Counting Device: Automated Capacitive Sensing of Aquatic Life in Remote Streams and Rivers. National Technology and Development Program, 1477 1816 – SDTDC Engineering Management.
- Bednarek, A.T. 2001. Undamming Rivers: A Review of the Ecological Impacts of Dam Removal. *Environmental Management* 27, 6, 803-814.
- Befford, B. 2013. Pocket Guide for Screening Small Water Diversions. U.S. Bureau of Reclamation.
- Bennett, S., Al-Chokhachy, R., Roper, B.B., Budy, P. 2014. Annual Variation of Spawning Cutthroat Trout in a Small Western USA Stream: A Case Study with Implications for the Conservation of Potamodromous Trout Life History Diversity. *North American Journal of Fisheries Management* 34, 1033-1046, doi:10.1080/02755947.2014.938139.
- Beschta, R.L., Ripple, W.J. 2012. The Role of Large Predators in Maintaining Riparian Plant Communities and River Morphology. *Geomorphology* 157-158, 88-98.
- Belford, D.A., and W.R. Gould. 1989. An evaluation of trout passage through six highway culverts in Montana. *North American Journal of Fisheries Management* 9:437-445.
- Bernhardt, E.S., Palmer, M.A., Allan, J.D., Alexander, G., Barnas, K., Brooks, S., Carr, J., Clayton, S., Dahm, C., Follstad-Shah, J., Galat, D., Gloss, S., Goodwin, P., Hart, D., Hassett, B., Jenkinson, R., Katz, S., Kondolf, G.M., Lake, P.S., Lave, R., Meyer, J.L., O'Donnell, T.K., Pagano, L., Powell, B., Sudduth, E. 2005. Synthesizing U.S. River Restoration Efforts. *Science* 208, 636-637.
- Bhuiyan, F., Hey, R.D., Wormleaton, P.R. 2010. Bank Attached Vanes for Bank Erosion Control and Restoration

- of River Meanders. *Journal of Hydraulic Engineering* (136) 9, 583-596.
- Bhuiyan, F., Hey, R.D., Wormleaton, P.R. 2009. Effects of Vanes and W-Weir on Sediment Transport in Meandering Channels. *Journal of Hydraulic Engineering* (135)5, 339-349.
- Biron, P.M., Carre, D.M., Carver, R.B., Rodrigue-Gervais, K., Whiteway, S.L. 2011. Combining Field, Laboratory, and Three-Dimensional Numerical Modeling Approaches to Improve Our Understanding of Fish Habitat Restoration Schemes. In "Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools" (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 209-231.
- Biron, P.M., Carver, R.B., Carre, D.M. 2012. Sediment Transport and Flow Dynamics Around A Restored Pool in a Fish Habitat Rehabilitation Project: Field and 3D Numerical Modelling Experiments. *River Research and Applications* 28, 926-939.
- Bledsoe, B. 2007. CE:413: Environmental River Mechanics. Colorado State University.
- BLM 2015. AIM National Aquatic Monitoring Framework: Introducing the Framework and Indicators for Lotic Systems. Technical Reference 1735-1. U.S. Department of the Interior, Bureau of Land Management, National Operations Center, Denver, CO.
- Bonfantine, K., Zebrowski, J., Egan, A. 2011. Guidelines and Protocols for Monitoring Riparian Forest Restoration Projects. New Mexico Forest and Watershed Restoration Institute, New Mexico Highlands University.
- Bouwes, N., Bennett, S., Wheaton, J. 2016. Adapting Adaptive Management for Testing the Effectiveness of Stream Restoration: An Intensely Monitored Watershed Example. *Essay in Fisheries Magazine*, February 2.
- Bovee, K.D., Lamb, B.L., Bartholow, J.M., Stalnaker, C.B., Taylor, J., Henriksen, J. 1998. Stream Habitat Analysis Using the Instream Flow Incremental Methodology: U.S. Geological Survey Information and Technology Report 1998-0004. 130 p.
- Boyles, S.L., Savitzky, B.A. 2008. An Analysis of the Efficacy and Comparative Costs of Using Flow Devices to Resolve Conflicts with North American Beavers Along Roadways in the Coastal Plain of Virginia. *Proceedings of the 23<sup>rd</sup> Vertebrate Pest Conference*, 47-52.
- Bozek, M.A., Rahel, F.J. 1991. Assessing habitat requirements of young Colorado river cutthroat trout by use of macrohabitat and microhabitat analyses. *Transactions of the American Fisheries Society* 120, 571-581.
- Braudrick, C.A., Dietrich, W.E., Leverich, G.T., Sklar, L.S. 2009. Experimental Evidence for the Conditions Necessary to Sustain Meandering Rivers in Coarse-Bedded Rivers. *Proceedings of the National Academy of Sciences* (106) 40, 16936-16941.
- Brierley, G.J., Fryirs, K.A. 2005. *Geomorphology and River Management: Applications of the River Styles Framework*. Blackwell Publications, Oxford, UK. 398pp
- Brierley, G.J., Fryirs, K.A. 2008. *River Futures: An Integrative Scientific Approach to River Repair*. Island Press, Washington DC. ISBN 9781597261128.
- Brierley, G.J., Fryirs, K.A. 2015. The Use of Evolutionary Trajectories to Guide 'Moving Targets' in the Management of River Futures. *River Research and Applications*, doi:10.1002/rra.2930.
- Briske, D.D., editor. 2011. *Conservation Benefits of Rangeland Practices: Assessment, Recommendations, and Knowledge Gaps*. United States Department of Agriculture, Natural Resources Conservation Service.
- Brooks, A.P., Brierley, G.J. 2002. Mediated Equilibrium: The Influence of Riparian Vegetation and Wood on the Long-Term Evolution and Behaviour of a Near-Pristine River. *Earth Surface Processes and Landforms* 27, 343-367.
- Brooks, A.P., Brierley, G.J., Millar, R.G. 2003. The Long-Term Control of Vegetation and Woody Debris on Channel and Flood-Plain Evolution: Insights from a Paired Catchment Study in Southeastern Australia. *Geomorphology* 51, 7-29.
- Brown, S., Shafer, D., and Anderson, S. 2001. Control of Beaver Flooding at Restoration Projects. Army Corps of Engineers, Wetlands Regulatory Assistance Program, Technical Notes Collection ERDC TN-WRAP-01-01.
- Brownlie, W.R. 1983. Flow depth in Sand-Bed Channels. *Journal of Hydraulic Engineering* 109(7), 959-990.
- Brunner, G.W. 2016. HEC-RAS: River Analysis System Hydraulic Reference Manual. U.S. Army Corps of Engineers, Hydraulic Engineering Center, CPD-69.
- Buchanan, B.P., Nagle, G.N., Walter, M.T. 2013. Long-Term Monitoring and Assessment of a Stream Restoration Project in Central New York. *River Research and Applications* DOI:10.1002/rra.2639.
- Buchanan, T.J., Somers, W.P. 1969. Discharge Measurements at Gaging Stations. U.G. Geological Survey, Techniques of Water-Resources Investigations of the United States Geological Survey, Chapter A8, Book 3, Applications of Hydraulics.
- Buffington, J.M., Montgomery, D.R. 1999. Effects of Roughness on Surface Textures of Gravel-Bed Rivers. *Water Resources Research* 35(11), 3508-3521.
- Bunt, C.M., Castro-Santos, T., Haro, A. 2012. Performance of Fish Passage Structures at Upstream Barriers to Migration. *River Research and Applications* 28, 457-478.
- Bunte, K., Abt, S.R. 2001. Sampling Surface and Subsurface Particle-Size Distributions in Wadable Gravel- and Cobble-Bed Streams for Analyses in Sediment Transport, Hydraulics, and Streambed Monitoring. U.S. Department of Agriculture, Forest Service, Rocky Mountain Research Station, General Technical Report 74.
- Bunte, K., Abt, S.R., Potyondy, J.P., Ryan, S.E. 2004. Measurement of Coarse Gravel and Cobble Transport Using Portable Bedload Traps. *Journal of Hydraulic Engineering* 130(9), 879-893.
- Bunte, K., Abt, S.R., Swingle, K.W., Cenderelli, D.A. 2014. Effective Discharge in Rocky Mountain Headwater Streams. *Journal of Hydrology* 519, 2136-2147, doi:10.1016/j.jhydrol.2014.09.080.

- Bunte, K., Swingle, K.W., Abt, S.R. 2007. Guidelines for Using Bedload Traps in Coarse-Bedded Mountain Streams: Construction, Installation, Operation and Sample Processing. U.S. Department of Agriculture, Rocky Mountain Research Station, General Technical Report 191.
- Burchsted, D., Daniels, M., Thorson, R., Vokoun, J. 2010. The River Discontinuum: Applying Beaver Modifications to Baseline Conditions for Restoration of Forested Headwaters. *BioScience* 60(11), 908-922.
- Burgi, P., Christensen, R., Glickman, A., Johnson, P., Mefford, B. 2006. Fish Protection at Water Diversions – A Guide for Planning and Designing Fish Exclusion Facilities. U.S. Department of Interior, Bureau of Reclamation, Denver, Colorado
- Burton, T.A., Smith, S.J., Cowley, E.R. 2011. Multiple Indicator Monitoring (MIM) of Stream Channels and Streamside Vegetation. U.S. Department of the interior, Bureau of Land Management, Technical Reference 1737-23.
- Camp, R.J., Wheaton, J.M. 2014. Streamlining Field Data Collection with Mobile Apps. *Eos* 95(49).
- Cannatelli, K., Curran, J. 2012. Importance of Hydrology on Channel Evolution Following Dam Removal: Case Study and Conceptual Model. *ASCE Journal of Hydraulic Engineering*, 138(5), 377–390.
- Capesius, J.P., Stephens, V.C. 2009. Regional Regression Equations for Estimation of Natural Streamflow Statistics in Colorado: U.S. Geological Survey Scientific Investigations Report 2009–5136, 46 p.
- Caplan, T.R., Cothorn, K., Landers, C., Hummel, O.C. 2012. Growth Response of Coyote Willow (*Salix exigua*) Cuttings in Relation to Alluvial Soil Texture and Water Availability. *Restoration Ecology*.
- Carah, J.K., Blencowe, C.C., Wright, D.W., Bolton, L.A. 2014. Low-cost restoration techniques for rapidly increasing wood cover in coastal Coho salmon streams. *North American Journal of Fisheries Management* 34, 1003-1013, doi:10.1080/02755947.2014.943861.
- Carim, K. J., Padgett-Stewart, T., Wilcox, T.M., Young, M.K., McKelvey, K.S., Schwartz, M.K. 2015. Protocol for collecting eDNA samples from streams. U.S.D.A. Forest Service, National Genomics Center for Wildlife and Fish Conservation. V2.3 (July 2015).
- Castro, J., Sampson, R. 2001. Design of Rock Weirs. U.S. Department of Agriculture, Natural Resources Conservation Service, Idaho Engineering Technical Note No. 13.
- Castro, J., Sampson, R. 2001. Design of Stream Barbs. U.S. Department of Agriculture, Natural Resources Conservation Service, Idaho Engineering Technical Note No. 12.
- Chin, A., Anderson, S., Collison, A., Ellis-Sugai, B.J., Haltiner, J.P., Hogervorst, J.B., Kondolf, G.M., O'Hirok, L.S., Purcell, A.H., Riley, A.L., Wohl, E.E. 2009. Linking Theory and Practice for Restoration of Step-pool Streams. *Environmental Management*. 43:645–661.
- Chin, A., Phillips, J.D. 2006. The Self-Organization of Step-Pools in Mountain Streams. *Geomorphology* 83, 346-358.
- Clancy, C.G., and D. R. Reichmuth. 1990. A detachable fishway for steep culverts. *North American Journal of Fisheries Management* 10:244-246.
- Clarkin, K., Connor, A., Furniss, M.J., Gubernick, B., Love, M., Moynam, K., WilsonMusser, S. 2005. National Inventory and Assessment Procedure For Identifying Barriers to Aquatic Organism Passage at Road-Stream Crossings. U.S. Department of Agriculture, Forest Service, National Technology and Development Program.
- Clay, C.H. 1995. Design of Fishways and Other Fish Facilities, 2<sup>nd</sup> Edition. American Fisheries Society and CRC Press.
- Clemson University. 1994. The Clemson Beaver Pond Leveler. Clemson University Cooperative Extension Service, AFW Leaflet 1.
- Cluer, B., Thorne, C. 2013. A stream evolution model integrating habitat and ecosystem benefits. *River Research and Applications*, DOI: 10.1002/rra.2631.
- Collen, P., Gibson, R.J. 2001. The general ecology of beavers (*Castor* spp.), as related to their influence on stream ecosystems and riparian habitats, and the subsequent effects on fish – a review. *Reviews in Fish Biology and Fisheries* 10, 439-461.
- Collins, K.E., Doscher, C., Rennie, H.G., Ross, J.G. 2013: The Effectiveness of Riparian Restoration on Water Quality – A Case Study of Lowland Streams in Canterbury, New Zealand. *Restoration Ecology* 21(1), 40-48.
- Conyngham, J., Fischenich, J.C., White, K.D. 2006. Engineering and Ecological Aspects of Dam Removal – An Overview. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program.
- Cooper, David J.; Merritt, David M. 2012. Assessing the water needs of riparian and wetland vegetation in the western United States. Gen. Tech. Rep. RMRS-GTR-282. Fort Collins, CO: U.S. Department of Agriculture, Forest Service, Rocky Mountain Research Station. 125 p.
- Copeland, R.R. 1983. Bank Protection Techniques Using Spur Dikes. U.S. Army Engineer Waterways Experiment Station, HL-83-1.
- Copeland, R.R., McComas, D.N., Thorne, C.R., Soar, P.J., Fripp, J.B. 2001. Hydraulic Design of Stream Restoration Projects. U.S. Army Engineer Research and Development Center, Coastal and Hydraulics laboratory, Vicksburg, MS, ERDC/CHL TR-01-28.
- Cowan, W.L. 1956. Estimating hydraulic roughness coefficients. *Agricultural Engineering* 37, 473-475.
- Cramer, Michelle L. (managing editor). 2012. Stream Habitat Restoration Guidelines. Co-published by the Washington Departments of Fish and Wildlife, Natural Resources, Transportation and Ecology, Washington State Recreation and Conservation Office, Puget Sound Partnership, and the U.S. Fish and Wildlife Service. Olympia, Washington.
- Crosato, A., Saleh, M.S. 2011. Numerical Study on the Effects of Floodplain Vegetation on River Planform Style. *Earth Surface Processes and Landforms* 36, 711-720.
- Cui, Y., Dusterhoff, S.R., Wooster, J.K., Downs, P.W. 2011. Practical Considerations for Modeling Sediment Transport Dynamics in Rivers. In “Stream Restoration in Dynamic

- Fluvial Systems: Scientific Approaches, Analyses, and Tools” (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 503-527.
- D’Aoust, S.G., Millar, R.G. 2000. Stability of Ballasted Woody Debris Habitat Structures. *Journal of Hydraulic Engineering* 126(11), 810-817.
- David, G.C.L., Wohl, E., Yochum, S.E., Bledsoe, B.B. 2011. Comparative Analysis of Bed Resistance Partitioning in High-Gradient Streams. *Water Resources Research* 47.
- Davis, J. C.; Minshall, G. W.; Robinson, C. T.; Landres, P. 2001. Monitoring wilderness stream ecosystems. Gen. Tech. Rep. RMRS-GTR-70. Ogden, UT: U.S. Department of Agriculture, Forest Service, Rocky Mountain Research Station. 137 p.
- DeVries, P., Fetherston, K.L., Vitale, A., Madsen, S. 2012. Emulating Riverine Landscape Controls of Beaver in Stream Restoration. *Fisheries* 37(6), 246-255.
- Diez, J., Elosegı, A., Chauvet, E., Pozo, J. 2002. Breakdown of wood in the Aguera stream. *Freshwater Biology* 47, 2205-2215.
- Doll, B.A., Grabow, G.L., Hall, K.R., Halley, J., Harman, W.A., Jennings, G.D., Wise, D.E. 2003. Stream Restoration: A Natural Channel Design Handbook. NC Stream Restoration Institute, NC State University. 128 pp.
- Dosskey, M.G., Vidon, P., Gurwick, N.P., Allan, C.J., Duval, T.P., Lowrance, R. 2010. The Role of Riparian Vegetation in Protecting and Improving Chemical Water Quality in Streams. *Journal of the American Water Resources Association* 1-18, doi:10.1111/j.1752-1688.2010.00419.x.
- Doyle, J.E., Meyer, K., Wegner, S., Fowler, P. 2007. Developing Monitoring Plans for Structure Placement in the Aquatic Environment – Recommended Report Format, Listing of Methods and Procedures, and Monitoring Project Case Studies. USDA, Forest Service, National Technology & Development Program, 7700 Transportation Mgmt 0777 1811—SDTDC.
- Dreesen, D.R., Fenchel, G.A. 2009. Revegetating Riparian Areas in the Southwest “Lessons Learned.” U.S. Department of Agriculture, Natural Resources Conservation Service, Los Lunas Plant Materials Center, Technical Note No. 70.
- Dreesen, D.R., Fenchel, G.A. 2010. Deep-Planting Techniques to Establish Riparian Vegetation in Arid and Semiarid Regions. *Native Plants* 11(1), 15-22.
- Drever, J.I. 1997. *The Geochemistry of Natural Waters – Surface and Groundwater*, 3<sup>rd</sup> Edition. Prentice-Hall, Inc. Upper Saddle River, New Jersey.
- Dunham, J.; Chandler, G.; Rieman, B.; Martin, D.. 2005. Measuring stream temperature with digital data loggers: a user’s guide. Gen. Tech. Rep. RMRS-GTR-150WWW. Fort Collins, CO: U.S. Department of Agriculture, Forest Service, Rocky Mountain Research Station. 15 p.
- Dunne, T., Leopold, L.B. 1978. *Water in Environmental Planning*. W.H. Freeman and Co., San Francisco, CA.
- DVWK 2002. *Fish Passes: Design, Dimensions, and Monitoring*. Food and Agriculture Organization of the United Nations, Deutscher Verband für Wasserwirtschaft und Kulturbau e.V. DVWK ISBN 3-89554-027-7.
- East, A.E., Pess, G.R., Bountry, J.A., Magirl, C.S., Ritchie, A.C., Logan, J.B., Randle, T.J., Mastin, M.C., Minear, J.T., Duda, J.J., Liermann, M.C., McHenry, M.L., Beechie, T.J., Shafroth, P.B. Large-Scale Dam Removal on the Elwha River, Washington, USA: River Channel and Floodplain Geomorphic Change. *Geomorphology*, 228, 765-786, doi.org/10.1016/j.geomorph.2014.08.028.
- Edwards, T.K., Glysson, G.D. 1999. Field Methods for Measurement of Fluvial Sediment. U.S. Geological Survey Techniques of Water-Resources Investigations, Book 3, Chapter C2.
- Ehrhart, R.C., Hansen, P.L. 1997. Effective Cattle Management in Riparian Zones: A Field Survey and Literature Review. U.S. Department of Interior, Bureau of Land Management, Montana BLM Riparian Technical Bulletin No. 3.
- EPA 2015. Connectivity of Streams & Wetlands to Downstream Waters: A Review & Synthesis of the Scientific Evidence. Office of Research and Development, NCEA, NERL, & NHEERL EPA/600/R-14/475F.
- Ernst, A.G., Warren, D.R., Baldigo, B.P. 2012. Natural-Channel-Design Restorations that Changed Geomorphology Have Little Effect on Macroinvertebrate Communities in Headwater Streams. *Restoration Ecology* 20(4), 532-540.
- Eubanks, C.E., Meadows, D. 2002. A Soil Bioengineering Guide for Streambank and Lakeshore Stabilization. U.S. Department of Agriculture, Technology and Development Program, San Dimas, CA.
- EPA 2008. Aquatic Life Criteria for Contaminants of Emerging Concern: Part I, General Challenges and Recommendations. DRAFT. Environmental Protection Agency, OW/ORD Emerging Contaminants Workgroup.
- EPA 2012. National Recommended Water Quality Criteria. Environmental Protection Agency <http://water.epa.gov/scitech/swguidance/standards/current>
- Fazli, M., Ghodsian, M., Neyshabouri, S.A.A.A. 2008. Scour and Flow Field Around a Spur Dike in a 90° Bend. *International Journal of Sediment Research* (23)1 56-68.
- Ficke, A.D., Myrick, C.A. 2007. Fish Barriers and Small Plains Fishes – Fishway Design Recommendations and the Impact of Existing Instream Structures. CDOW Contract Number IA-CSU-1180-2004, CSU Number 5-30216.
- Fischenich, C. 2000. Resistance Due to Vegetation. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-07.
- Fischenich, C. 2000. Irrigation Systems for Establishing Riparian Vegetation. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-12.
- Fischenich, C, Marrow, J.V. 2000. Reconnection of Floodplains with Incised Channels. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-09.
- Fischenich, J.C., Morrow, J.V. 2000. Streambank Habitat Enhancement with Large Woody Debris. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-13.

- Fischenich, C., Seal, R. 2000. Boulder Clusters. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-11.
- Fischenich, C. 2001a. Stability Thresholds for Stream Restoration Materials. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-29.
- Fischenich, C. 2001b. Impacts of Stabilization Measures. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-32.
- Fischenich, C. 2001c. Plant Material Selection and Acquisition. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-33.
- Fischenich, J.C. 2006. Functional Objectives for Stream Restoration. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-52.
- Fischenich, J.C., McKay, S.K. 2011. Hydrologic Analyses for Stream Restoration Design. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program.
- Fischer, R.A. 2004. Using Soil Amendments to Improve Riparian Plant Survival in Arid and Semi-arid Landscapes. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program. ERDC TN-EMRRP-SR-44.
- FISRWG 1998. Stream Corridor Restoration: Principles, Processes and Practices. Federal Interagency Stream Restoration Working Group. U.S. Department of Agriculture, Natural Resources Conservation Service, National Engineering Handbook, Part 653.
- Flosi, G., Downie, S., Hopelain, J., Bird, M., Coey, R., Collins, B. 2010. California Salmonid Stream Habitat Restoration Manual, 4<sup>th</sup> Edition. State of California, The Resources Agency, California Department of Fish and Game, Wildlife and Fisheries Division
- Fox, B.D., Bledsoe, B.P., Kolden, E., Kondratieff, M.C., Myrick, C.A. 2016. Eco-hydraulic evaluation of a whitewater park as a fish passage barrier. *Journal of the American Water Resources Association*, 1-23, doi:10.1111/1752-1688.12397.
- Frentress, C. 1997. An Improved Device for Managing Water Levels in Beaver Ponds. Texas Parks and Wildlife, Austin, Texas.
- Fryirs, K.A., Brierley, G.J. 2013. Geomorphic Analysis of River Systems: An Approach to Reading the Landscape. John Wiley and Sons, Chichester, UK, 345pp.
- Froehlich 2011 Sizing loose rock riprap to protect stream banks. *River Research and Applications*, DOI: 10.1002/rra.1587.
- George, M.R., Jackson, R.D., Boyd, C.S., Tate, K.W. 2011 A scientific assessment of the effectiveness of riparian management practices. Chapter 5 of Conservation Benefits of Rangeland Practices: Assessment, Recommendations, and Knowledge Gaps. United States Department of Agriculture, Natural Resources Conservation Service.
- Giordanengo, J.H., Mandel, R.H., Spitz, W.J., Bossler, M.C., Blazewicz, M.J., Yochum, S.E., Jagt, K.R., LaBarre, W.J., Gurnee, G.E., Humphries, R., Uhing, K.T. 2016 *Living Streambanks: A Manual of Bioengineering Treatments for Colorado Streams*. Colorado Water Conservation Board, April 13, 2016, 152 pp.
- Gippel, C.J., O'Neill, I.C., Finlayson, B.L., Schnatz, I. 1996. Hydraulic Guidelines for the Re-Introduction and Management of Large Woody Debris in Lowland Rivers. *Regulated Rivers: Research & Management* 12, 223-236.
- Goldsmith, W., Silva, M., Fischenich, C. 2001. Determining Optimal Degree of Soil Compaction for Balancing Mechanical Stability and Plant Growth Capacity. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-26.
- Gray, J.R., Laronne, J.B., Marr, J.D.G. 2010. Bedload Surrogate Monitoring Technologies. U.S. Geological Survey Scientific Investigations Report 2010-5091, 37 p.
- Guilfoyle, M.P., Fischer, R.A. 2006 Guidelines for Establishing Monitoring Programs to Assess the Success of Riparian Restoration Efforts in Arid and Semi-Arid Landscapes. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-50.
- Gulis, V., Rosemond, A.D., Suberkropp, K., Weyers, H.S., Benstead, J.P. 2004. Effects of nutrient enrichment on the decomposition of wood and associated microbial activity in streams. *Freshwater Biology* 49, 1437-1447.
- Hall, A.A., Rood, S.B., Higgins, P.S. 2009. Resizing a River: A Downscaled, Seasonal Flow Regime Promotes Riparian Restoration. *Restoration Ecology* (19)3, 351-359.
- Hauke, J., Clancy, K.A. 2011. Stationarity of Streamflow Records and Their Influence on Bankfull Regional Curves. *Journal of the American Water Resources Association*, 1-10.
- Harding, J.S., Benfield, E.F., Bolstad, P.V., Helfman, G.S., Jones, E.B.D. 1998. Stream Biodiversity: The Ghost of Land Use Past. *Proceedings of the National Academy of Sciences* 95, 14843-14847.
- Harig, A.L., Fausch, K.D., Young, M.K. 2000. Factors influencing success of greenback cutthroat trout translocations. *North American Journal of Fisheries Management* 20, 994-1004.
- Harig, A.L., Fausch, K.D. 2002. Minimum habitat requirements for establishing translocated cutthroat trout populations. *Ecological Applications* 12(2), 535-551.
- Harrelson, C.C., Rawlins, C.L., Potyondy, J.P. 1994. Stream Channel Reference Sites: An Illustrated Guide to Field Technique. U.S. Department of Agriculture, Rocky Mountain Research Station, General Technical Report RM-245.
- Helfman, G.S. 2007. *Fish Conservation: A guide to understanding and restoring global aquatic biodiversity and fishery resources*. Island Press, Washington D.C.
- Henner, C., Langlois, S., Decker, T. 2004. The Use of Water Flow Devices in Addressing Flooding Problems Caused by Beaver in Massachusetts. Massachusetts Division of Fisheries and Wildlife.

- Hey, R.D. 1979. Flow Resistance in Gravel Bed Rivers, ASCE Journal of the Hydraulics Division, 105(4), 365-379.
- Hicks, D.M., Mason, P.D. 1998. Roughness Characteristics of New Zealand Rivers, 2<sup>nd</sup> Edition, Water Resource Publications.
- Higgins, D., Reinecke, S. 2015. Effects of Historical Logging on Rivers in the Lake States. U.S. Forest Service, National Stream and Aquatic Ecology Center, StreamNotes, November 2015.
- Hilldale, R.C., Carpenter, W.O., Goodwiller, B., Chambers, J.P., Randle, T.J. 2015. Installation of Impact Plates to Continuously Measure Bed Load: Elwha River, Washington, USA, ASCE Journal of Hydraulic Engineering, 141(3), 2015.141.
- Hirsch, R.M. 2011. A Perspective on Nonstationarity and Water Management. Journal of the American Water Resources Association 47(3), 436-446.
- Hoag, J.C. 2007. How to Plant Willows and Cottonwoods for Riparian Restoration. U.S. Department of Agriculture, Natural Resources Conservation Service, Plant Materials Technical Note 23.
- Hoag, J.C. 2009. Vertical Bundles: A Streambank Bioengineering Treatment to establish willows and dogwoods on streambanks. U.S. Department of Agriculture, Natural Resources Conservation Service, Plant Materials Technical Note 53.
- Hoag, C., Fripp, J. 2002. Streambank Soil Bioengineering Field Guide for Low Precipitation Areas. U.S. Department of Agriculture, Natural Resources Conservation Service, Plant Materials Center & National Design, Construction and Soil Mechanics Center.
- Hoag, J.C., Ogle, D.G. 2010. Willow Clump Plantings. U.S. Department of Agriculture, Natural Resources Conservation Service, Plant Materials Technical Note No. 42.
- Hoag, J.C., Ogle, D.G. 2011. The Stinger: A Tool to Plant Unrooted Hardwood Cuttings. U.S. Department of Agriculture, Natural Resources Conservation Service, Plant Materials Technical Note No. 6.
- Hoag, J.C., Sampson, R.W. 2007. Planting Willow and Cottonwood Poles under Rock Riprap. U.S. Department of Agriculture, Natural Resources Conservation Service, Plant Materials Technical Note No. 21.
- Hoag, C., Tilley, D., Darris, D., Pendergrass, K. 2008. Field Guide for the Identification and Use of Common Riparian Woody Plants of the Intermountain West and Pacific Northwest Regions. U.S. Department of Agriculture, Natural Resources Conservation Service, Plant Materials Program.
- Hoag, J.C., Tilley, D., Ogle, D., St. John, L. 2011. Description, Propagation, and Establishment of Wetland-Riparian Grass and Grass-Like Species in the Intermountain West. U.S. Department of Agriculture, Natural Resources Conservation Service, Plant Materials Program, Technical Note 38.
- Hoag, J.C., Wyman, S.K., Bentrup, G., Holzworth, L., Ogle, D.G., Carleton, J., Berg, F., Leinard, B. Users Guide to Description, Propagation, and Establishment of Wetland Plant Species and Grasses for Riparian Areas in the Intermountain West. (2001) USDA NRCS, Plant Materials TN-38.
- Hoffert-Hay, D. 2008. Small Dam Removal in Oregon: A Guide for Project Managers. Oregon Watershed Enhancement Board.
- Holburn, E., Varyu, D., Russell, K. 2009. Quantitative Investigation of the Field Performance of Rock Weirs. Bureau of Reclamation, Denver Technical Service Center, Sedimentation and River Hydraulics Group, SRH-2009-46.
- Holmquist-Johnson, C.L. 2011. Numerical Analysis of River Spanning Rock U-Weirs: Evaluating Effects of Structure Geometry on Local Hydraulics. Dissertation. Colorado State University, Fort Collins, CO.
- Horan, D.L., Kershner, J.L., Hawkins, C.P., Crowl, T.A. 2000. Effects of habitat area and complexity on Colorado river cutthroat trout density in Uinta mountain streams. Transactions of the American Fisheries Society 129, 1250-1263.
- Interagency Advisory Committee on Water Data. 1982. Guidelines for Determining Flood Flow Frequency: Bulletin #17B for the Hydrology Subcommittee. U.S. Department of the Interior, Geological Survey, Office of Water Data Coordination, Reston, Virginia.
- Isaak, D.J. 2011. Stream Temperature Monitoring and Modeling: Recent Advances and New Tools for Managers. StreamNotes. U.S. Forest Service, Stream System Technology Center, July 2011.
- James, L.A., Rathburn, S.L., Whittecar, G.R. (editors) 2009. Management and Restoration of Fluvial Systems with Broad Historical Changes and Human Impacts. GSA Special Papers 451.
- Jarrett, R.D. 1984. Hydraulics of High-Gradient Streams. Journal of Hydraulic Engineering 110 (11), 1519-1539.
- Jellison, B., Emme, T., Cundy, T. 2007. Response of Prairie Stream Riparian Buffers to Livestock Exclusion and Short-Duration Grazing in Northeast Wyoming – A Pre- and Post-Photographic Comparison. Wyoming Game and Fish Department, Sheridan Regional Office.
- Johnson, P.A., Hey, R.D., Tessier, M., Rosgen, D.L., 2001. Use of Vanes for Control of Scour at Vertical Wall Abutments. Journal of Hydraulic Engineering (127) 9, 772-778.
- Johnstone, H.C., Rahel, F.J. 2003. Assessing temperature tolerance of Bonneville cutthroat trout based on constant and cycling thermal regimes. Transactions of the American Fisheries Society 132:92-99.
- Julien, P.Y. 2002. River Mechanics. Cambridge University Press, Cambridge, UK.
- Julien, P.Y., Duncan, J.R. 2003. Optimal Design Criteria of Bendway Weirs from Numerical Simulations and Physical Model Studies. Colorado State University, Department of Civil and Environmental Engineering, Fort Collins, CO.
- Jones, T.A., Daniels, L.D., Powell, S.R. 2011. Abundance and Function of Large Woody Debris in Small, Headwater Streams in the Rocky Mountain Foothills of Alberta, Canada. River Research and Applications 27, 297-311.

- Kasprak, A., Hough-Snee, N., Beechie, T., Bouwes, N., Brierley, G., Camp, R., Fryirs, K., Imaki, H., Jensen, M., O'Brien, G., Rosgen, D., Wheaton, J. 2016. The blurred line between form and process: A comparison of Stream Channel Classification Frameworks. *PLOS One*, doi:10.1371/journal.pone.0150293.
- Kaushal, S.S., Likens, G.E., Jaworski, N.A., Pace, M.L., Sides, A.M., Seekell, D., Belt, K.T., Secor, D.H., Wingate, R.L. 2010. Rising stream and river temperatures in the United States. *Frontiers in Ecology and Environment* 8(9), 461-466, doi:10.1890/090037.
- Kershner, J.L., Archer, E. K., Coles-Ritchie, M., Cowley, E.R., Henderson, R.C., Kratz, K., Quimby, C.M., Turner, D.L., Ulmer, L.C., Vinson, M.R. 2004. Guide to Effective Monitoring of Aquatic and Riparian Resources. U.S. Department of Agriculture, Rocky Mountain Research Station. General Technical Report RMRS-GTR-121. 57 p.
- KIESD 2011. Stream Restoration. *Sustain: A Journal of Environmental and Sustainability Issues*. 24, Spring/Summer 2011.
- Kinzli, K-D, Thornton, C.I. 2010. Predicting Velocity in Bendway Weir Eddy Fields. *River Research and Applications* (26), 823-834.
- Klaar, H.J., Hill, D.F., Maddock, I., Milner, A.M. 2011. Interactions Between Instream Wood and Hydrogeomorphic Development Within Recently Deglaciated Streams in Glacier Bay National Park, Alaska. *Geomorphology* 130, 208-220.
- Knighton, D. 1998. *Fluvial Forms and Processes: A New Perspective*. Oxford University Press, New York, NY.
- Kondolf, G.M., Wolman, M.G. 1993. The sizes of salmonid spawning gravels. *Water Resources Research* 29(7), 2275-2285.
- Kondratieff, M.C., Myrick, C.A. 2006. How high can brook trout jump? A laboratory evaluation of brook trout jumping performance. *Transactions of the American Fisheries Society* 135, 361-370.
- Kovalchick, B. L., and W. Elmore. 1991. Effects of cattle grazing systems on willow-dominated plant associations in central Oregon. In: W. P. Clary, E. D. McArthur, D. Bedunah, and C. L. Wambolt [eds.]. *Proceedings of the Symposium on Ecology and Management of Riparian Shrub Communities*. Ogden, UT, USA: US Department of Agriculture, Forest Service, Intermountain Forest and Range Experiment Stations. INTGTR-289. p. 111-119.
- Kuhnle, R.A., Alonso, C.V., Shields, F.D. 1999. Geometry of Scour Holes Associated with 90° Spur Dikes. *Journal of Hydraulic Engineering* (125) 9, 972-978.
- Kuhnle, R.A., Alonso, C.V., Shields, F.D. 2002. Local Scour Associated with Angled Spur Dikes. *Journal of Hydraulic Engineering* (128) 12, 1087-1093.
- Kuhnle, R.A., Jia, Y., Alonso, C.V. 2008. Measured and Simulated Flow near a Submerged Spur Dike. *Journal of Hydraulic Engineering* (134) 7, 916-924.
- Lagasse, P.F., Clopper, P.E., Pagán-Ortiz, J.E., Zevenbergen, L.W., Arneson, L.A., Schall, J.D., Girard, L.G. 2009. *Bridge Scour and Stream Instability Countermeasures: Experience, Selection and Design Guidance*, 3rd Edition. U.S. Department of Transportation, Federal Highway Administration, FHWA NHI HEC-23.
- Lenhart, C.F. 2003. A Preliminary Review of NOAA's Community-Based Dam Removal and Fish Passage Projects. *Coastal Management* 31, 79-98.
- Leonard, S., Kinch, G., Elsbernd, V., Borman, M., Swanson, S. 1997. *Riparian Area Management – Grazing Management for Riparian-Wetland Areas*. U.S. Department of Interior, Bureau of Land Management, National Applied Resources Sciences Center, Denver, CO, Technical Reference 1737-14.
- Leopold, L.B. 1994. *A View of the River*. Harvard University Press, Cambridge, Massachusetts.
- Leopold, L.B., Wolman, M.G., Miller, J.P. 1964. *Fluvial Processes in Geomorphology*. Dover Publications, Mineola, N.Y.
- Levell, A.P., Chang, H. 2008. Monitoring the Channel Process of a Stream Restoration Project in an Urbanizing Watershed: A Case Study of Kelley Creek, Oregon, USA. *River Research and Application* 24, 169-182.
- Li, S.S., Millar, R.G. 2011. A Two-Dimensional Morphodynamic Model of Gravel-Bed River with Floodplain Vegetation. *Earth Surface Processes and Landforms* 36, 190-202.
- Limerinos J.T. 1970. Determination of the Manning Coefficient from Measured Bed Roughness in Natural Channels. U.S. Geological Survey Water Supply Paper 1898-B.
- Langendoen, E.J. 2011. Application of the CONCEPTS Channel Evolution Model in Stream Restoration Strategies. In "Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools" (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 487-502.
- EOEEA 2007. *Dam Removal in Massachusetts: A Basic Guide for Project Proponents*. Massachusetts Executive Office of Energy and Environmental Affairs.
- MacDonald, J.I., Davies, P.E. 2007. Improving the upstream passage of two galaxiid fish species through a pipe culvert. *Fisheries Management and Ecology* 14:221-230.
- Macfarlane W.W., Wheaton J.M., Jensen, M.L.. 2014. *The Utah Beaver Restoration Assessment Tool: A Decision Support and Planning Tool*. Ecogeomorphology and Topographic Analysis Lab, Utah State University, Prepared for Utah Division of Wildlife Resources, Logan, Utah, 135 pp.
- MacWilliams, M.L., Tompkins, M.R., Street, R.L., Kondolf, G.M., Kitanidis, P.K. 2010: Assessment of the Effectiveness of a Constructed Compound Channel River Restoration Project on an Incised Stream. *Journal of Hydraulic Engineering* 136(12), 1042-1052.
- Major, J.J., O'Conner, J.E., Podolak, C.J., Keith, M.K., Grant, G.G., Spicer, K.R., Pittman, S., Bragg, H.M., Wallick, J.R., Tanner, D.Q., Rhode, A., Wilcock, P. 2012. *Geomorphic Response of the Sandy River, Oregon, to Removal of Marmot Dam*. U.S. Department of Interior, U.S. Geological Survey, Professional Paper 1792.

- Maser, C, Sedell, J.R. 1994. From the Forest to the Sea: The Ecology of Wood in Streams, Rivers, Estuaries, and Oceans. St. Lucie Press, Delray Beach. Florida, USA.
- McColley, S.D., Tyers, D.B., Sowell, B.F. 2012. Aspen and Willow Restoration Using Beaver on the Northern Yellowstone Winter Range. *Restoration Ecology* 20 (4), 450-455.
- Mesa M.G., Rose, B.P., Copeland, E.S. 2010: Biological Evaluations of an Off-Stream Channel, Horizontal Flat-Plate Fish Screen – The Farmers Screen. U.S. Geological Survey Open-File Report 2010-1042.
- Millar, R.G., Eaton, B.C. 2011. Bank Vegetation, Bank Strength, and Application of the University of British Columbia Regime Model to Stream Restoration. In “Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools” (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 475-485.
- MN DNR 2010. Stream Restoration: Toe Wood Sod Mat Minnesota Department of Natural Resources, Understanding Our Streams: Toe Wood-Sod Mat Factsheet.
- Montgomery, D.R., Buffington, J.M., 1997. Channel Reach Morphology in Mountain Drainage Basins. *Geological Society of America Bulletin* 109 (5), 596–611.
- Montgomery, D.R., MacDonald, L.H. 2002. Diagnostic approach to stream channel assessment and monitoring. *Journal of the American Water Resources Association*, 38(1), 1-16.
- Mooney, D.M., Holmquist-Johnson, C.L., Broderick, S. 2007. Rock Ramp Design Guidelines. U.S. Department of Interior, Bureau of Reclamation, Denver, CO.
- Morrow, J.V., Fischenich, C. 2000. Habitat Requirements for Freshwater Fishes. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP SR-06.
- Moulton, S.R., Kennen, J.G., Goldstein, R.M., Hambrook, J.A. 2002. Revised Protocols for Sampling Algal, Invertebrates, and Fish Communities as Part of the National Water-Quality Assessment Program. U.S. Geological Survey Open File Report 02-150.
- Newbury, R., Bates, D., Alex, K.L. 2011. Restoring Habitat Hydraulics with Constructed Riffles. In “Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools” (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 353-366.
- Niezgoda, S.L., Johnson, P.A. 2007. Case Study in Cost-Based Risk Assessment for Selecting Stream Restoration Design Method for a Channel Relocation Project. *Journal of Hydraulic Engineering* 133(5), 468-481.
- Niezgoda, S.L., Wilcock, P.R., Baker, D.W., Mueller-Price, J., Castro, J., Curran, J.C., Wynn-Thompson, T., Schwartz, J.S., Shields, F.D. 2014. Defining a Stream Restoration Body of Knowledge as a Basis for National Certification. *Journal of Hydraulic Engineering* 140, 123-136.
- Nordlund, B., Bates, K. 2000. Fish Protection Screen Guidelines for Washington State (draft). Washington Department of Fish and Wildlife.
- Novak, R., Kennen, J.G., Abele, R.W., Baschon, C.F., Carlisle, D.M., Dlugolecki, L., Flotermersch, J.E., Ford, P., Fowler, J., Galer, R., Gorgon, L.P., Hansen, S.N., Herbold, B., Johnson, T.E., Johnston, T.E., Konrad, C.P., Leamond, B., Seelbach, P.W. 2015. Protecting Aquatic Life from Effects of Hydrologic Alternation. Jointly prepared by the U.S. Environmental Protection Agency and U.S. Department of the Interior, U.S. Geological Survey. EPA Report 822-P-15-002 USGS Scientific Investigations Report 2015-5160.
- NRCS 2007. Stream Restoration Design. U.S. Department of Agriculture, Natural Resources Conservation Service, National Engineering Handbook, Part 654. 210-VI-NEH.
- NRCS 2009. Stream Visual Assessment Protocol Version 2. U.S. Department of Agriculture, Natural Resources Conservation Service, National Biology Handbook, Subpart B, Conservation Planning, Part 614.
- Olden, J.D., Poff, N.L. 2003. Redundancy and the Choice of Hydrologic Indices for Characterizing Streamflow Regimes. *River Research and Applications* 19, 101-121.
- ODF ODFW 2010 Guide to Placement of Wood, Boulders and Gravel for Habitat Restoration. Oregon Department of Forestry & Oregon Department of Fish and Wildlife.
- Palmer, M.A., Bernhardt, E.S., Allan, J.D., Lake, P.S., Alexander, G., Brooks, S., Carr, J., Clayton, S., Dahm, C.N., Follstad Shah, J., Galat, D.L., Loss, S.G., Goodwin, P., Hart, D.D., Hassett, B., Jenkinson, R., Kondolf, G.M., Lave, R., Meyer, J.L., O'Donnell, T.K., Pagano, L., Sudduth, E. 2005. Standards for Ecologically Successful River Restoration. *Journal of Applied Ecology* 42, 208-217.
- Paradiso, J.J. 2000. A bank-operated traveling-block cableway for stream discharge and sediment measurements. General Technical Report RMRS-GTR-44. Fort Collins, CO: U.S. Department of Agriculture, Forest Service, Rocky Mountain Research Station. 36p
- Pearson, A.J., Snyder, N.P., Collins, M.J. 2011. Rates and Processes of Channel Response to Dam Removal with a Sand-Filled Impoundment. *Water Resources Research* 47, W08504, doi:10.1029/2010WR009733.
- Pfankuch, D. J. 1975. Stream reach inventory and channel stability evaluation. U.S. Department of Agriculture Forest Service. Region 1. Missoula, Montana.
- Phillips, J.D. 2011. Predicting modes of spatial change from state-and-transition models. *Ecological Modeling* 222, 475-484.
- Phillips, J.D. 2013. Geomorphic responses to changes in instream flows: The flow-channel fitness model. *River Research and Applications*, 29, 1175-1194, doi:10.1002/rra.2602.
- Phillips, J.D. 2014. State transitions in geomorphic responses to environmental change. *Geomorphology* 204, 208-216, doi:10.1016/j.geomorph.2013.08.005.
- Pierce, R., Podner, C., Carim, K. 2013. Response of Wild Trout to Stream Restoration over Two Decades in the

- Blackfoot River Basin, Montana. Transactions of the American Fisheries Society 142, 68-81.
- Piper, K.L., Hoag, J.C., Allen, H.H., Durham, G., Fischenich, J.C., Anderson, R.O. 2001. Bioengineering as a Tool for Restoring Ecological Integrity to the Carson River. U.S. Army Corps of Engineers, Wetlands Regulatory Assistance Program.
- Platts, W. S. 1990. Managing fisheries and wildlife on rangelands grazed by livestock: a guide and reference document for biologists. Reno, NV, USA: Nevada Department of Wildlife. 462 p.
- Powers, P. 2015. Case Study: Restoration of the Camp Polk Meadow Preserve on Whychus Creek. US Forest Service StreamNotes, June 2015, pp 1-5.
- Polvi, L.E., Wohl, E., Merritt, D.M. 2014. Modeling the functional influence of vegetation type on streambank cohesion. Earth Surface Processes and Landforms, doi:10.1002/esp.3577.
- Poff, Boris; Koestner, Karen A.; Neary, Daniel G.; Merritt, David. 2012. Threats to western United States riparian ecosystems: A bibliography. Gen. Tech. Rep. RMRS-GTR-269. Fort Collins, CO: U.S. Department of Agriculture, Forest Service, Rocky Mountain Research Station. 78 p.
- Poff, N.L., Allan, J.D., Bain, M.B., Karr, J.R., Prestegard, K.L., Richter, B.D., Sparks, R.E., Stromberg, J.C. 1997. The Natural Flow Regime. Bioscience 47(11), 769-784.
- Poff, N.L., Richter, B.D., Arthington, A.H., Bunn, S.E., Naiman, R.J., Kendy, E., Acreman, M., Apse, C., Bledsoe, B.P., Freeman, M.C., Henriksen, J., Jacobson, R.B., Kennen, J.G., Merritt, D.M., O'Keefe, J.H., Olden, J.D., Rogers, K., Tharme, R.E., Warner, A. 2010. The Ecological Limits of Hydrologic Alteration (ELOHA): A New Framework for Developing Regional Environmental Flow Standards. Freshwater Biology 55: 147-170.
- Pollock, M.M., Lewallen, G., Woodruff, K., Jordan, C.E., and Castro, J.M. (Editors) 2015. The Beaver Restoration Guidebook: Working with Beaver to Restore Streams, Wetlands, and Floodplains. Version 1.0. United States Fish and Wildlife Service, Portland, Oregon. 189 pp.
- Powers, P. 2015. Case Study: Restoration of the Camp Polk Meadow Preserve on Whychus Creek. StreamNotes. U.S. Forest Service, National Stream and Aquatic Ecology Center, June 2015, pp 1-5.
- Prichard, D., Anderson, J., Correll, C., Fogg, J., Gebhardy, K., Krapf, R., Leonard, S., Mitchell, B., Staats, J. 1998. A User Guide for Assessing Proper Functioning Condition and Supporting Science for Lotic Areas. U.S. Department of Interior, Bureau of Land Management, Technical Reference 1737-15.
- Purcell, A.H., Friedrich, C., Resh, V.H. 2002. An Assessment of a Small Urban Stream Restoration Project in Northern California. Restoration Ecology 10(4), 685-694.
- Quistberg, S.E., Stringham, T.K. 2010. Sedge Transplant Survival in a Reconstructed Channel: Influences of Planting Location, Erosion, and Invasive Species. Restoration Ecology 18, 401-408, DOI: 10.1111/j.1526-100X.2009.00607.x.
- Rahman, D.M., Muramoto, Y. 1999. Prediction of Maximum Scour Depth Around Spur-Dike-Like Structures. Annual Journal of Hydraulic Engineering 43, 623-628.
- Reeves, G.H., Hall, J.D., Roelofs, T.D., Hickman, T.L., Baker, C.O. 1991. Rehabilitating and Modifying Stream Habitats. American Fisheries Society Special Publication 19, 519-557.
- Reid, D., Church, M. 2015. Geomorphic and ecological consequences of riprap placement in river systems. Journal of the American Water Resources Association, 1-17, doi:10.1111/jawr.12279.
- Rey, F., Burylo, M. 2014. Can bioengineering structures made of willow cuttings trap sediment in eroded marly gullies in a Mediterranean mountainous climate? Geomorphology 204, 564-572.
- Richardson E.V., Simons, D.B., Lagasse, P.F. 2001. River Engineering for Highway Encroachments. U.S. Department of Transportation, Federal Highway Administration, FHWA NHI 01-004 HDS 6.
- Richmond, A.D., Fausch, K.D. 1995. Characteristics and Function of Large Woody Debris in Subalpine Rocky Mountain Streams in Northern Colorado. Canadian Journal of Fisheries and Aquatic Science 52, 1789-1802.
- Richter, B.D., Davis, M.M., Apse, C., Konrad, C. 2011. A Presumptive Standard for Environmental Flow Protection. River Research and Applications, doi:10.1002/rra.1511.
- Rinaldi, M. Surian, N., Comiti, F., Bussetini, M., Bellelli, B., Nardi, L., Lastoria, B., Golfieri, B., 2015. Guidebook for the evaluation of stream morphological conditions by the Morphological Quality Index (MQI), Deliverable 6.2, Part 3, of REFORM (REstoring rivers FOR effective catchment Management).
- Roberts, J.J., Rahel, F.J. 2008. Irrigation Canals as Sink Habitat for Trout and Other Fishes in a Wyoming Drainage. Transactions of the American Fisheries Society 137, 951-961.
- Rosenfeld, J.S., Boss, S. 2001. Fitness consequences of habitat use for juvenile cutthroat trout: energetic costs and benefits in pools and riffles. Canadian Journal of Fisheries and Aquatic Sciences 58, 585-593.
- Rosenfeld, J. 2003. Assessing the habitat requirements of stream fishes: An overview and evaluation of different approaches. Transactions of the American Fisheries Society 132, 953-968.
- Rosgen, D.L. 1994. A classification of natural rivers. Catena 22, 169-199.
- Rosgen, D.L. 1996. Applied River Morphology. Wildland Hydrology, Fort Collins, Colorado.
- Rosgen, D.L. 2006. Cross-vane, w-weir and j-hook vane structures: Description, design and application for stream stabilization and river restoration. Wildland Hydrology, Fort Collins, Colorado.
- Rosgen, D.L. 2007. Watershed Assessment of River Stability and Sediment Supply (WARSSS). Wildland Hydrology.
- Rosgen, D.L. 2006. Cross-Vane, W-Weir and J-Hook Vane Structures: Description, Design and Application for Stream Stabilization and River Restoration. Wildland Hydrology, Fort Collins, Colorado.

- Rosgen, D., Silvey, H.L., Frantila, D. 2008. River Stability Field Guide. Wildland Hydrology, Fort Collins, Colorado.
- Rosgen, D.L. 2013. Natural Channel Design: Fundamental Concepts, Assumptions, and Methods. In "Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools" (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 69-93.
- Ruffing, C.M., Daniels, M.D., Dwire, K.A. 2015. Disturbance legacies of historic tie-drives persistently alter geomorphology and large wood characteristics in headwater streams, southeast Wyoming. *Geomorphology* 231, 1-14, doi:10.1016/j.geomorph.2014.10.029.
- Ryan, D. F.; Calhoun, J. M., tech. eds. 2010. Riparian adaptive management symposium: a conversation between scientists and management. Gen. Tech. Rep. PNW-GTR-830. Portland, OR: U.S. Department of Agriculture, Forest Service, Pacific Northwest Research Station. 135 p.
- Saldi-Caromile, K., Bates, K., Skidmore, P., Barenti, J., Pineo, D. 2004. Stream Habitat Restoration Guidelines: Final Draft. Co-published by the Washington Departments of Fish and Wildlife and Ecology and the U.S. Fish and Wildlife Service. Olympia, Washington.
- Sanderson, J.S., Rowan, N., Wilding, T., Bledsoe, B.P., Miller, W.J., Poff, N.L. 2012. Getting to Scale With Environmental Flow Assessment: The Watershed Flow Evaluation Tool. *River Research and Applications* 28, 1369-1377.
- Schiff, R., Benoit, G., MacBroom, J. 2011. Evaluating Stream Restoration: A Case Study from Two Partially Developed 4th Order Connecticut, U.S.A. Streams and Evaluation Monitoring Strategies. *River Research and Applications* 27, 431-460.
- Schmetterling, D.A., Pierce, R.W., Liermann, B.W. 2002. Efficacy of three Denil fish ladders for low-flow fish passage in two tributaries to the Blackfoot River, Montana. *North American Journal of Fisheries Management* 22:929-933.
- Schumm, S.A., Harvey, M.D., Watson, C.A. 1984. Incised Channels: Morphology, Dynamics, and Control. Water Resources Publications, Lone Tree, CO. ISBN: 9781887201643.
- Scurlock, S.M., Thornton, C.J., Abt, S.R. 2012. Equilibrium Scour Downstream of Three-Dimensional Grade-Control Structures. *Journal of Hydraulic Engineering* 138(2), 167-176.
- Shafer, D., Lee, A. 2003. Willow Stake Installation: Example Contract Specifications. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program.
- Shen, Y., Diplas, P. 2010. Modeling unsteady flow characteristics of hydropeaking operations and their implications on fish habitat. *Journal of Hydraulic Engineering* 136(12), 1053-1066.
- Shields, F.D., Gippel, C.J. 1995. Prediction of Effects of Woody Debris Removal on Flow Resistance. *Journal of Hydraulic Engineering* 121(4), 341-354.
- Shields, F.D., Morin, N., Cooper, C.M. 2004. Large Woody Debris Structures for Sand-Bed Channels. *Journal of Hydraulic Engineering* 130(3), 208-217.
- Simon, A. 1989. A model of channel response in disturbed alluvial channels. *Earth Surface Processes and Landforms* 14(1), 11-26.
- Simon, A., Bennett, S.J., Castro, J.M. 2011. Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools. American Geophysical Union, Washington D.C.
- Simon, A., Pollem-Bankhead, N., Thomas, R.E. 2011. Development and Application of a Deterministic Bank Stability and Toe Erosion Model for Stream Restoration. In "Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools" (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 453-474.
- Simon, L.J. 2006. Solving Beaver Flooding Problems through the Use of Water Flow Control Devices. Proceedings of the 22<sup>nd</sup> Vertebrate Pest Conferences, 174-180.
- Simon, A., Hupp, C.R. 1987. Geomorphic and vegetative recovery processes along modified Tennessee streams: An interdisciplinary approach to distributed fluvial systems. *Forest Hydrology and Watershed Management Publ* 167, 251-262.
- Skidmore, P.B., Thorne, C.B., Cluer, B.L., Pess, G.R., Castro, J.M., Beechie, T.J., Shea, C.C. 2011. Science Base and Tools for Evaluating Stream Engineering, Management, and Restoration Proposals. U.S. Department of Commerce, NOAA Tech. Memo. NMFS-NWFSC-112, 255 p.
- Smith, L.W., Dittmer, E., Prevost, M., Burt, D.R. 2000. Breaching a Small Irrigation Dam in Oregon: A Case History. *North American Journal of Fisheries Management* 20, 205-219.
- Soar, P.J., Thorne, C.R. 2001. Channel Restoration Design for Meandering Rivers, U.S. Army Engineer Research and Development Center, Flood Damage Reduction Research Program, Vicksburg, MS, ERDC/CHL CR-01-1.
- Soar, P.J., Thorne, C.R. 2011. Design Discharge for River Restoration. In "Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools" (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 123-149.
- Sotir, R.B., Fischenich, C. 2001 Live and Inert Fascine Streambank Erosion Control. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP-SR-31.
- Sotir, R.B., Fischenich, J.C. 2003. Vegetated Reinforced Soil Slope Streambank Erosion Control. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP-SR-30.
- Sotir, R.B., Fischenich, J.C. 2007. Live Stake and Joint Planting for Streambank Erosion Control. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, ERDC TN-EMRRP-SR-35.
- Southerland, W.B. 2010. Performance of Engineered Log Jams in Washington State – Post Project Appraisal. 2<sup>nd</sup>

- Joint Interagency Conference, Las Vegas, NV, June 27 – July 1, 2010.
- Spanhoff, B., Meyer, E.I. 2004. Breakdown rates of wood in streams. *Journal of the North American Benthological Society* 23(2), 189-197.
- Steed, J.E., DeWald, L.E. 2003. Transplanting Sedges (*Carex* spp.) in Southwestern Riparian Meadows. *Restoration Ecology* 11(2), 247-256, DOI: 10.1046/j.1526-100X.2003.00193.x.
- Stewardson, M., Cottingham, P., Rutherford, I., Schreiber, S. 2004: Evaluating the Effectiveness of Habitat Reconstruction in Rivers. Cooperative Research Centre for Catchment Hydrology. Report 04/11.
- Stromberg, J.C., White, M.S., White, J.M., Shorrock, D., Fischer, R.A. 2009. Influence of Hydrologic Connectivity on Plant Species Diversity Along Southwestern Rivers – Implications for Restoration. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, TN-EMRRP-SR-55.
- Short, L.E., Gabet, E.J., Hoffman, D.F. 2015. The role of large woody debris in modulating the dispersal of a post-fire sediment pulse. *Geomorphology* 246, 351-358, doi:10.1016/j.geomorph.2015.06.031.
- Stumm, W., Morgan, J.J. 1996. *Aquatic Chemistry: Chemical Equilibria and Rates in Natural Waters*, 3<sup>rd</sup> Edition. John Wiley & Sons, Inc. New York, New York.
- Sylte, T., Fischenich, C. 2000. Rootwad Composites for Streambank Erosion Control and Fish Habitat Enhancement. U.S. Army Corps of Engineers, Ecosystem Management and Restoration Research Program, TN-EMRRP-SR-21.
- Tharme, R.E. 2003. A Global Perspective on Environmental Flow Assessment: Emerging Trends in the Development and Application Of Environmental Flow Methodologies for Rivers. *River Research and Applications* 19, 397-441.
- Thom, R.M., Wellman, K.F. 1996. Planning Aquatic Ecosystem Restoration Monitoring Programs. U.S. Army Corps of Engineers, Institute for Water Resources, 96-R-23.
- Thomas, J.T., Culler, M.E., Dermis, D.C., Pierce, C.L., Papanicolaou, A.N., Stewart, T.W., Larson, C.J. 2011. Effects of Grade Control Structures on Fish Passage, Biological Assemblages and Hydraulic Environments in Western Iowa Streams – A Multidisciplinary Review. *River Research and Applications*. DOI: 10.1002/rra.1600.
- Thompson, D.M. 2002. Long-Term Effect of Instream Habitat-Improvement Structures on Channel Morphology Along the Blackledge and Salmon Rivers, Connecticut, USA. *Environmental Management* 29(1), 250-265.
- Thornton, C.I., Meneghetti, A.M., Collins, K., Abt, S.R., Mcurlock, S.M. 2011. Stage-Discharge Relationships for U-, A-, and W-Weirs in Un-Submerged Flow Conditions. *Journal of the American Water Resources Association*. doi: 10.1111/j.1752-1688.2010.00501.x.
- Tufekcioglu, M., Schultz, R.C., Zaines, G.N., Isenhardt, T.M., Tufekcioglu, A. 2012. Riparian Grazing Impacts on Streambank Erosion and Phosphorus Loss via Surface Erosion. *Journal of the American Water Resources Association*.
- U.S. Army Engineer Research and Development Center, Vicksburg, MS. Welch, S., Wright, S. 2005. Design of Stream Barbs. U.S. Department of Agriculture, Natural Resources Conservation Service, Oregon Engineering Technical Note 23.2.
- USBR 2001. Endangered Fish Passage at the Public Service Company of New Mexico (PNP) Diversion Dam on the San Juan River. U.S. Bureau of Reclamation, Upper Colorado Region, Western Colorado Area Office, Grand Junction, CO.
- USBR 2005. Appraisal Study, Fish Passage improvements, Bohannon Creek Diversions 3, 4 and 6, Lemhi River Basin, Idaho. U.S. Bureau of Reclamation, Pacific Northwest Region, Snake River Area Office Salmon Field Station and Pacific Northwest Region Design Group.
- USBR 2006. Price-Stubb Fish Passage: Final Environmental Assessment. U.S. Bureau of Reclamation.
- USBR and ERDC (Bureau of Reclamation and U.S. Army Engineer Research and Development Center) 2016. *National Large Wood Manual: Assessment, Planning, Design, and Maintenance of Large Wood in Fluvial Ecosystems: Restoring Process, Function, and Structure*. 628 pages + Appendix.
- USFS 2015. Trail Creek NFF Project, U.S. Department of Agriculture, Forest Service.
- Knutson, M., Fealko, J. 2014. Large Woody Material – Risk Based Design Guidelines. Bureau of Reclamation, Pacific Northwest Region, Resource & Technical Services, Boise, Idaho.
- USBR 2014a. Improving Public Safety of Large Wood Installations: Designing and Installing Safer large Wood Structures. The Knowledge Stream Research Update, Research and Development Office, Bulletin 2014-29.
- USBR 2014b Modeling How Large Woody Debris Structures Affect Rivers: Modeling River Changes from Large Wood Structures and Other Instream Structures. The Knowledge Stream Research Update, Research and Development Office, Bulletin 2014-28.
- USFS 2008. Stream Simulation: An Ecological Approach to Providing Passage for Aquatic Organisms at Road-Stream Crossings. U.S. Department of Agriculture, Forest Service, National Technology and Development Program, 0877 1801-SDTDC.
- U.S. Geological Survey, variously dated, National Field Manual for the Collection of Water-quality Data: U.S. Geological Survey Techniques of Water-Resources Investigations, Book 9, Chapters A1-A9.
- Van Dyke, C. 2016. Nature's complex flume: Using a diagnostic state and transition framework to understand post-restoration channel adjustment of the Clark Fork River, Montana. *Geomorphology* 254, 1-15, doi:10.1016/j.geomorph.2015.11.007.
- van Rijn, L.C. 1984. Sediment Transport, Part III: Bed forms and Alluvial Roughness. *Journal of Hydraulic Engineering* 110(12), 1733-1754.

- Vuyovich, C.M., Tuthill, A.M., Gagnon, J.J. 2009. Physical Model Study of Cross Vanes and Ice. U.S. Army Engineer Research and Engineering Laboratory, Cold Regions Research and Engineering Laboratory, TR-09-7.
- Walter, C.A., Nelson, D., Earle, J.I. 2012. Assessment of Stream Restoration: Sources of Variability in Macroinvertebrate Recovery throughout an 11-year Study of Coal Mine Drainage Treatment. *Restoration Ecology* 20(4) 431-440.
- Warren, H.L., Pardew, M.G. 1998. Road crossings as barriers to small-stream fish movement. *Transactions of the American Fisheries Society* 127:637-644.
- Watson, C.C., D.S. Biedenbarn, and B.P. Bledsoe, 2002. Use of Incised Channel Evolution Models in Understanding Rehabilitation Alternatives. *Journal of the American Water Resources Association* 38(1), 151-160.
- Weber, R., Fripp, J. 2012. Understanding Fluvial Systems: Wetlands, Streams and Flood Plains. U.S. Department of Agriculture, Natural Resources Conservation Service, Technical Note No. 2.
- Wilcox, A.C., O'Connor, J.E., Major, J.J. 2014. Rapid Reservoir Erosion, Hyperconcentrated Flow, and Downstream Deposition Triggered by Breaching of 38 m Tall Condit Dam, White Salmon River, Washington. *Journal of Geophysical Research: Earth Surface* 119, 1376-1394, doi:10.1002/2013JF003073.
- Williams, B.K., and E.D. Brown. 2012. Adaptive Management: The U.S. Department of the Interior Applications Guide. Adaptive Management Working Group, U.S. Department of the Interior, Washington, DC.
- Williams, J.G., G. Armstrong, C. Katopodis, M. Larinier, F. Travade. 2012. Thinking Like a Fish: A Key Ingredient for Development of Effective Fish Passage Facilities at River Obstructions. *River Research and Applications* 28, 407-417.
- Winkler, M.F. 2003. Defining Angle and Spacing of Bendway Weirs. U.S. Army Corps of Engineers, ERDC/CHL CHETN-IX-12.
- WQCD 2010. Aquatic Life Use Attainment, Policy Statement 10-1. Appendix B: Benthic Macroinvertebrate Sampling Protocols. Colorado Department of Public Health and Environment, Water Quality Control Division.
- Westbrook, C.J., Cooper, D.J., Baker, B.W. 2011. Beaver Assisted River Valley Formation. *River Research and Applications*. doi:10.1002/rra.1359.
- Wilkerson, G.V., Kandel, D.R., Perg, L.A., Dietrich, W.E., Wilcock, P.R., Whiles, M.R. 2014. Continental-Scale Relationship Between Bankfull Width and Drainage Area for Single-Thread Alluvial Channels. *Water Resources Research* 50, doi:10.1002/2013WR013916.
- Williams, G.P. 1978. Bank-Full Discharge of Rivers. *Water Resources Research* 14(6), 1141-1154.
- Winward, A.H. 2000. Monitoring the Vegetation Resources in Riparian Areas. U.S. Department of Agriculture, Forest Service, Rocky Mountain Research Station, RMRS-GTR-47.
- WMO 2010. Manual on Stream Gauging. World Meteorological Organization, Volume I – Fieldwork, WMO-No. 1044.
- Wohl, E. 2010. Mountain Rivers Revisited, Water Resource. Monograph Series, vol. 19, 573 pp., AGU, Washington, D. C., doi:10.1029/WM019.
- Wohl, E. 2011. What Should These Rivers Look Like? Historical Range of Variability and Human Impacts in the Colorado Front Range, USA. *Earth Surface Processes and Landforms* 36, 1378-1390.
- Wohl, E. 2011. Seeing the Forest and the Trees – Wood in Stream Restoration in the Colorado Front Range, United States. In “Stream Restoration in Dynamic Fluvial Systems: Scientific Approaches, Analyses, and Tools” (edited by Simon, A., Bennett, S.J., Castro, J.M.) American Geophysical Union, Washington D.C., 399-418.
- Wohl, E., Beckman, N.D. 2014. Leaky Rivers: Implications of the Loss of Longitudinal Fluvial Disconnectivity in Headwater Streams. *Geomorphology* 205, 27-35, doi:10.1016/j.geomorph.2011.10.022.
- Wohl, E., Bledsoe, B.P., Jacobson, R.B., Poff, N.L., Rathburn, S.L., Walters, D.M., Wilcox, A.C. 2015. The Natural Sediment Regime in Rivers: Broadening the Foundation for Ecosystem Management. *BioScience* 65(4), 358-371.
- Wohl, E., Bledsoe, B.P., Fausch, K.D., Kramer, N., Bestgen, K.R., Gooseff, M.N. 2016. Management of large wood in streams: An overview and proposed framework for hazard evaluation. *Journal of the American Water Resources Association* 1-21, doi:10.1111/1752-1688.12388.
- Wohl, E.E., Bledsoe, B.P., Merritt, D.M., Poff, N.L. 2006. River Restoration in the Context of Natural Variability. In *StreamNotes*, US Forest Service, Stream Systems Technology Center, April 2006.
- Wohl, E., Lane, S.N., Wilcox, A.C. 2015. The Science and Practice of River Restoration. *Water Resources Research*, 51, doi:10.1002/2014WR016874.
- Wolman, M.G., Miller, J.P. 1960. Magnitude and Frequency of Forces in Geomorphic Processes. *The Journal of Geology* 68(1), 54-74.
- Wyman, S., Bailey, D., Borman, M., Cote, S., Eisner, J., Elmore, W., Leinard, B., Leonard, S., Reed, F., Swanson, S., Van Riper, L., Westfall, T., Wiley, R., Winward, A. 2006. Riparian Area Management: Grazing Management Processes and Strategies for Riparian-Wetland Areas. U.S. Department of the Interior, Bureau of Land Management, National Science and Technology Center, Denver, CO, Technical Reference 1737-20. BLM/ST/ST-06/002+1737.
- Yochum, S., Bledsoe, B. 2010. Flow Resistance Estimation in High-Gradient Streams. 2<sup>nd</sup> Joint Federal Interagency Conference, Las Vegas, NV, June 27- July 1.
- Yochum, S.E., Bledsoe, B.P., David, G.C.L., Wohl, E. 2012. Velocity Prediction in High-Gradient Channels. *Journal of Hydrology*. 424-425, 84-98, doi:10.1016/j.jhydrol.2011.12.031.
- Yochum, S.E., Comiti, F., Wohl, E., David, G.C.L., Mao, L. 2014. Photographic Guidance for Selecting Flow Resistance Coefficients in High-Gradient Channels. U.S.

- Department of Agriculture, Forest Service, Rocky Mountain Research Station, General Technical Report, RMRS-GTR-323.
- Young, M.K. 1996. Summer movement and habitat use by Colorado river cutthroat (*Oncorhynchus clarki pleuriticus*) in small, montane streams. Canadian Journal of Fisheries and Aquatic Sciences 53, 1403-1408.
- Young, M.K. 2008. Colorado River cutthroat trout: a technical conservation assessment. Gen. Tech. Rep. RMRS-GTR-207. USDA Forest Service, Rocky Mountain Station. Fort Collins, CO. 123 p.
- Zeedyk, B. 2009. An Introduction to Induced Meandering: A Method for Restoring Stability to Incised Stream Channels. The Quivira Coalition and Zeedyk Ecological Consulting, 4<sup>th</sup> Edition.
- Zeedyk, B., Clothier, V. 2009. Let the Water Do the Work: Induced Meandering, an Evolving Method for Restoring Incised Channels. The Quivira Coalition.
- Zimmermann, A., Church, M., Hassan, M.A. 2010. Step-Pool Stability: Testing the Jammed State Hypothesis. Journal of Geophysical Research, Vol 115, F02008.

## APPENDIX A: Table of Contents for NRCS Stream Restoration Design, NEH Part 654

### NRCS 2007

#### Chapter:

- 1: Introduction: Ecological and Physical Considerations for Stream Projects
- 2: Goals, Objectives, and Risk
- 3: Site Assessment and Investigation
- 4: Stream Restoration Design Process
- 5: Stream Hydrology
- 6: Stream Hydraulics
- 7: Basic Principles of Channel Design
- 8: Threshold Channel Design
- 9: Alluvial Channel Design
- 10: Two-Stage Channel Design
- 11: Rosgen Geomorphic Channel Design
- 12: Channel Alignment and Variability Design
- 13: Sediment Impact Assessments
- 14: Treatment Technique Design
- 15: Project Implementation
- 16: Maintenance and Monitoring
- 17: Permitting Overview

#### Appendix A: Postscript

#### Appendix B: References

#### Technical Supplement:

- 2: Use of Historic Information for Design
- 3A: Stream Corridor Inventory and Assessment Techniques
- 3B: Using Aerial Videography and GIS for Stream Channel Stabilization in the Deep Loess Region of Western Iowa
- 3C: Streambank Inventory and Evaluation
- 3D: Overview of United States Bats
- 3E: Rosgen Stream Classification Technique—  
Supplemental Materials
- 5: Developing Regional Relationships for Bankfull Discharge Using Bankfull Indices
- 13A: Guidelines for Sampling Bed Material
- 13B: Sediment Budget Example
- 14A: Soil Properties and Special Geotechnical Problems Related to Stream Stabilization Projects
- 14B: Scour Calculations
- 14C: Stone Sizing Criteria
- 14D: Geosynthetics in Stream Restoration
- 14E: Use and Design of Soil Anchors
- 14F: Pile Foundations
- 14G: Grade Stabilization Techniques
- 14H: Flow Changing Techniques
- 14I: Streambank Soil Bioengineering
- 14J: Use of Large Woody Material for Habitat and Bank Protection

- 14K: Streambank Armor Protection with Stone Structures
- 14L: Use of Articulating Concrete Block Revetment Systems for Stream Restoration and Stabilization Projects
- 14M: Vegetated Rock Walls
- 14N: Fish Passage and Screening Design
- 14O: Stream Habitat Enhancement Using LUNKERS
- 14P: Gullies and Their Control
- 14Q: Abutment Design for Small Bridges
- 14R: Design and Use of Sheet Pile Walls in Stream Restoration and Stabilization Projects
- 14S: Sizing Stream Setbacks to Help Maintain Stream Stability

#### Case Studies:

- 1: Chalk Creek, Summit County, Utah
- 2: Goode Road/Cottonwood Creek, Hutchins, Texas
- 3: Little Elk River, Price County, Wisconsin
- 4: Silver Creek, Silver Creek, New York
- 5: Rose River, Madison County, Virginia
- 6: Big Bear Creek, Lycoming County, Pennsylvania
- 7: Spafford Creek, Otisco Lake Watershed, New York
- 8: Copper Mine Brook, Burlington, Connecticut
- 9: Little Blue River, Washington County, Kansas
- 10: Newaukum River, Lewis County, Washington
- 11: Streambank Stabilization in the Red River Basin, North Dakota
- 12: Grade Control Structures in Western Iowa Streams
- 13: Owl Creek Farms, North Branch of the Kokosing River, Knox County, Ohio
- 14: Streambank Stabilization in the Merrimack River Basin, New Hampshire
- 15: Streambank Stabilization in the Guadalupe River Basin, Santa Clara County, California
- 16: Coffee Creek, Edmond, Oklahoma
- 17: Stream Barbs on the Calapooia River, Oregon
- 18: Wiley Creek, Sweet Home, Oregon

## APPENDIX B: Glossary of Fluvial Geomorphology Terms

*Adapted from a compilation developed by Janine Castro, Paul Bakke, Rob Sampson, and others.*

**Aggradation:** A persistent rise in the elevation of a streambed caused by sediment deposition.

**Alluvial Fan:** A gently sloping, usually convex landform shaped like an open fan or a segment of a cone, composed predominately of coarse-grained soils deposited by moving water. The stream deposits a fan wherever it flows from a narrow mountain valley onto a plain or broad valley, or wherever the stream gradient suddenly decreases. Being constructed of sediment transported by the stream, alluvial fans tend to be highly dynamic, with high rates of channel avulsion and rapid responses to channel obstructions or man-made alterations.

**Alluvial Stream:** Self-formed channels composed of clays, silts, sand, gravel, or cobble and characterized by the ability to alter their boundaries and their patterns in response to changes in discharge and sediment supply.

**Anastomosing Channel:** A channel that is divided into one or more smaller channels, which successively meet and then redivide. This channel type differs from a braided channel in that the islands separating sub-channels are relatively stable and well vegetated.

**Anthropogenic:** caused or influenced by human actions.

**Armoring:** The development of a coarse surface layer in a stream bottom. The gradual removal of fines from a stream, leaving only the large *substrate* particles, caused by a reduction in the sediment load. This is sometimes referred to as pavement.

**Avulsion:** A significant and abrupt change in channel alignment resulting in a new channel across the floodplain. Channel straightening or relocating, as well as the construction of dikes or levees, are common contributing factors in channel avulsions.

**Bankfull Discharge:** Sometimes referred to as the effective flow or ordinary high water flow. It is the channel forming flow. For most streams the bankfull discharge is the flow that has a recurrence interval of approximately 1.5 years in the annual

flood series. Most bankfull discharges range between 1.0 and 1.8, though in some areas it could be lower or higher than this range. It is the flow that transports the most sediment for the least amount of energy.

**Bar:** Accumulation of sand, gravel, cobble, or other alluvial material found in the channel, along the banks, or at the mouth of a stream where a decrease in velocity induces deposition.

**Attached** – diamond-shaped bar with flow on one side and remnants of a channel on the floodplain side.

**Diagonal** – Elongated bodies with long axes oriented obliquely to the flow. They are roughly triangular in cross-section and often terminate in riffles.

**Longitudinal** – Elongated bodies parallel to local flow, of different shape, but typically with convex surfaces. Common to gravelly braided streams.

**Point** – Found on the inside of meander bends. They are typically attached to the streambank and terminate in pools.

**Transverse** – Typically solitary lobate features that extend over much of the active stream width but may also occur in sequence down a given reach of river. They are produced in areas of local flow divergence and are always associated with local deposition. Flow is distributed radially over the bar. Common to sandy braided streams.

**Baseflow:** Flow in a channel during periods between the runoff events, generated by moisture in the soil or groundwater.

**Base Level of a Stream:** The elevation below which a river can no longer erode, i.e. the level of its mouth.

**Bedload:** The part of a stream's sediment load that is moved on or immediately above the stream bed, such as the larger or heavier particles (boulders, cobbles, gravel) rolled along the bottom. The part of the load that is not continuously in suspension or solution.

**Bed Material:** The material of which a streambed is composed.

**Bioengineering:** An approach to strengthening the streambank soil or improving its erosion resistance by utilizing live plant materials, mostly woody

shrubs and trees. Although non-living materials such as wood or fabric may also be part of the design, bioengineering technique relies mostly on the long-term integrity of the live plants and their rooting systems for its streambank stabilization function.

**Braided Channel:** A stream characterized by flow within several channels which successively meet and redivide, which are divided by unvegetated islands. Braiding may be an adjustment to a sediment load too large to be carried by a single channel or having insufficient riparian vegetation to maintain stable channel banks. Braided channels often occur in deltas of rivers or in the outflow from a glacier.

**Channel:** A natural or artificial waterway of perceptible extent that periodically or continuously contains moving water. It has a definite bed and banks which serve to confine the water.

**Channel Confinement:** Lateral constriction of a stream channel.

**Channel Depth:** The vertical distance from the bankfull elevation to the channel bed.

**Channel Forming Flow:** See “Bankfull Discharge.”

**Channelization:** Straightening a stream or dredging a new channel into which the flow of the original channel is diverted.

**Channel Scour and Fill:** Terms used to define erosion and sedimentation during relatively short periods of time, whereas aggradation and degradation apply to similar processes that occur over a longer period of time. Scour and fill applies to events measures in minutes, hours, days, perhaps even seasons, whereas aggradation and degradation apply to persistent trends over a period of years or decades.

**Channel Stability:** A relative measure of the resistance of a stream to aggradation or degradation. Stable streams do not change appreciably from year to year. An assessment of stability helps determine how well a stream will adjust to and recover from mild to moderate changes in flow or sediment transport.

**Channel Width:** The horizontal distance along a transect line from bank to bank at the bankfull elevation, measured at right angles to the direction of flow.

**Chute Cutoff:** A new channel formed by the truncating of a meander bend across the floodplain. The channel flow bypasses the meander bend by cutting straight through it.

**Colluvium:** A general term for loose deposits of soil and rock moved by gravity.

**Crossover:** The point of inflection in a meander where the thalweg intersects the centerline of the stream. A riffle.

**Cross-section:** A line across a stream perpendicular to the flow along which measurements are taken.

**Cross-Sectional Area:** The area of a stream channel taken perpendicular to the channel centerline. Often taken at the bankfull elevation or top of bank for channel capacity.

**Cubic Foot per Second (cfs):** A unit of stream discharge. It represents one cubic foot of water moving past a given point in one second.

**D<sub>50</sub>, D<sub>84</sub>, D<sub>100</sub>:** The particle size for which 50, 84 and 100 percent, respectively, of the sample is finer. D<sub>50</sub> is thus the median size, while D<sub>100</sub> is the maximum size. D<sub>84</sub> represents one standard deviation above the median in a typical sediment size distribution, and thus is often used in design calculations to represent the population of “large” streambed particles.

**Debris Fan:** A gently sloping, usually convex landform shaped like an open fan or a segment of a cone, composed predominately of mixed-sized materials deposited by debris flows (landslides). Debris fans tend to form at the junctions of narrow mountain valleys and larger, broader valleys, or wherever the valley gradient suddenly decreases, allowing deposition. Being constructed of debris flow deposits, debris fans can be active or inactive (static), depending on current landslide rates. Inactive fans are characterized by highly incised channels and low avulsion rates. In contrast to alluvial fans, debris fans may be comprised of material too coarse to be readily mobilized by stream flow.

**Degradation:** The geologic process by which streambeds are lowered in elevation and streams are detached from their floodplains. Also referred to as entrenched or incised streams

**Deposition:** The settlement or accumulation of material out of the water column and onto the streambed or floodplain. This process occurs when

the energy of flowing water is unable to transport the sediment load.

**Discharge:** Rate of flow expressed in volume per unit of time, for instance, in cubic feet per second or liters per second. Discharge is the product of the mean velocity and the cross-sectional area of flow. One cubic meter per second is equal to 35.3 cubic feet per second (cfs).

**Dissolved Load:** The chemical load contained in stream water; that acquired by solution or by decomposition of rocks followed by solution.

**Drainage Area or Basin:** The area so enclosed by a topographic divide that surface runoff from precipitation drains into a stream above the point specified.

**Effective Discharge:** The discharge responsible for the largest volume of sediment transport over a long period of record. Effective discharge is computed from long-term flow statistics and the sediment transport to discharge relationship. It is typically in the range of a 1- to 3-year flood event, and in many settings has been shown to correspond to the bankfull discharge.

**Embeddedness:** The degree to which boulders, cobble, or gravel are surrounded by fine sediment. This indicates the suitability of stream substrate as habitat for benthic macroinvertebrates and for fish spawning and egg incubation. Evaluated by visual observation of the degree (percent) to which larger particles are surrounded by fine sediment.

**Energy Dissipation:** The loss of kinetic energy of moving water due to channel boundary resistance; form resistance around such features as large rock, instream wood, and meanders; and spill resistance from flow dropping from steps.

**Entrenchment:** The vertical containment of a river and the degree in which it is incised in the valley floor. A stream may also be entrenched by the use of levees or other structures.

**Entrenchment Ratio:** Measurement of entrenchment. It is the floodprone width divided by the bankfull discharge width. The lower the entrenchment ratio the more vertical containment of flood flows exists. Higher entrenchment ratios depict more floodplain development.

**Erosion:** A process or group of processes whereby surface soil and rock is loosened, dissolved or worn away and moved from one place to another by natural processes. Erosion usually involves

relatively small amounts of material at a time; but, over a long time periods, can involve very large volumes of material.

**Fine Sediment:** Clay, silt and sand sized particles.

**Floodplain:** The nearly flat area adjoining a river channel that is constructed by the river in the present climate and overflows upon during events greater than the bankfull discharge.

**Floodprone Area:** The active floodplain and the low terraces. Using the Rosgen methodology, the elevation of floodprone is qualitatively defined as 2 times the maximum bankfull depth.

**Flow:** The movement of stream water and other mobile substances from place to place. Syn: Discharge.

**Baseflow** – see above.

**Hyporheic Flow** – That portion of the water that infiltrates the stream bed and moves horizontally through and below it. It may or may not return to the stream channel at some point downstream. Also known as subsurface flow.

**Instantaneous Flow** – The discharge measured at any instant in time.

**Interstitial Flow** – That portion of the surface water that infiltrates into the stream bed and banks, and moves through the substrate pores.

**Low Flow** – The lowest discharge recorded over a specified period of time; also known as minimum flow.

**Mean Flow** – The average discharge at a given stream location, computed for the period of record by dividing the total volume of flow by the length of the specified period.

**Minimum Flow** – The lowest discharge recorded over a specified period of time.

**Peak Flow** – The instantaneous highest discharge recorded over a specified period of time.

**Fluvial:** Pertaining to streams or produced by stream action.

**Geomorphic Equilibrium:** The “sediment-transport continuity” of a stream, wherein the quantity and size of sediment transported into the reach is approximately the same as the quantity and size of sediment transported out of the reach. If a stream is in geomorphic equilibrium, the

processes of bank erosion and channel migration will occur only gradually, such that the shape, profile and planform patterns remain similar over time.

**Geomorphology:** the scientific study of landforms and the processes that shape them.

**Gradient** (stream): Degree of inclination of a stream channel parallel to stream flow; it may be represented as a ratio, percentage, or angle.

**Head Cut:** A break in slope along a stream profile which indicates an area of active erosion. Niagara Falls is an example of a very large head cut. Also known as “Nick Point.”

**Hydraulic Geometry:** A quantitative way of describing the channel changes in width, depth, and velocity relative to discharge.

**Hydraulic Jump:** An abrupt, turbulent rise in the water level of a flowing stream, occurring at the transition from shallow, fast flow to deeper, slower flow.

**Hydraulic Radius:** The cross-sectional area of a stream divided by the wetted perimeter. In relatively wide channels (width/depth > ~20), it is approximately equal to average depth.

**Hydraulics:** Refers to water, or other liquids, in motion and their action.

**Hydrograph:** A curve showing discharge over time.

**Hyporheic Zone:** The zone of saturated sediment adjacent to and underneath the stream. It is directly connected to the stream, and stream water continually exchanges into and out of the hyporheic zone as hyporheic flow.

### Ice Types

**Anchor Ice** – Ice formed on the stream bed materials when, due to outward radiation in evening, they become colder than the water flowing over them.

**Frazil Ice** – Needle-like crystals of ice that are slightly lighter than water, but carried below the surface due to turbulence. This causes a milky mixture of ice and water. When these crystals touch a surface that is even a fraction of a degree below freezing, they instantly adhere and form a spongy, often rapidly growing, mass.

**Hinge Ice** – A marginal sheet of surface ice attached to the bank materials and extending

toward the center of a stream but not spanning it completely.

**Incised Channel:** A stream channel that has deepened and as a result is disconnected from its floodplain.

**Instream Wood:** Wood material accumulated or placed in a stream channel, providing opportunity for habitat, and enhanced bedforms and flow resistance.

**Invert:** Refers to the bottom, inside surface of a pipe, log, or other object. Occasionally used to refer to the bottom or base elevation of a structure.

**Laminar Flow:** A flow, in which all particles or filaments of water move in parallel paths, characterized by the appearance of a flat, ripple free surface. In nature, this is only seen in very thin sheet flow over smooth surfaces (such as in parking lots) or in imperceptibly creeping flow (such as in the Florida Everglades). Opposite of turbulent flow.

**Large Woody Debris (LWD):** Any large piece of relatively stable woody material having a least diameter greater than 10cm and a length greater than 1 m that intrudes into the stream channel.

**Longitudinal Profile:** A profile of a stream or valley, drawn along its length from source to mouth; it is the straightened-out, upper edge of a vertical section that follows the winding of the stream or valley. A graph of the vertical fall of the stream bed or water surface measured along the course of the stream.

**Manning’s Roughness Coefficient:** A measure of frictional resistance to water flow. Also called Manning’s “n,” it is defined by Manning’s equation for flow in open channels.

**Mean Annual Discharge:** Daily mean discharge in units per second averaged over a period of years.

**Meander:** A reach of stream with a ratio of channel length to valley length greater than 1.5. By definition, any value exceeding unity can be taken as evidence of meandering, but 1.5 has been widely accepted by convention.

**Meander Pattern:** A series of sinuous curves or loops in the course of a stream that are produced as a stream shifts from side to side over time across its floodplain.

**Near Bank Region:** Sometimes referred to as the terrace side of the stream or the concave bank side

or the top of the meander wave. This bank area is opposite the point bar and most susceptible to erosion. This area is referred to sometimes as the near bank region because it is the location in the channel where the thalweg come closest to the bank.

**Neck Cutoff:** The loss of a meander resulting from an avulsion across the intervening land separating adjacent meander bends.

**Nick Point:** See “headcut.”

**Particle Size Distribution:** The composition of the material along the streambed is sampled; from this sample a plot of particle size or weight versus frequency in percent is plotted.

**Planform:** The characteristics of a river as viewed from above (in an aerial photo, on a map, etc.), which are generally expressed in terms of pattern, sinuosity (channel length/valley length) and individual meander attributes such as amplitude, wavelength and radius of curvature.

**Point Bar:** Usually the side opposite the concave bank. The point bar is the depositional feature that facilitates the movement of bedload from one meander to the next. The point bar extends at the loss of the near bank region.

**Pool:** A portion of the stream with reduced current velocity (during base flow), with deeper water than adjacent areas.

**Radius of Curvature:** radius of a curve fitting a stream channel’s thalweg planform.

**Reach:** (a) Any specified length of stream. (b) A relatively homogeneous section of a stream having a repetitious sequence of physical characteristics and habitat features. (c) A regime of hydraulic units whose overall profile is different from another reach.

**Recurrence Interval:** Interchangeably used with “return period”; a statistic based on frequency analysis derived from annual or partial duration peak flow series that describes the average interval (in years) between events equaling or exceeding a given magnitude.

**Reference Site** (Stream Geomorphology Context): The reference site is a stable morphological stream type in the system. This type may- or may not- be in a pristine state. The majority of time it is not pristine; however, the important geomorphologic, and most likely

vegetative components, are there to sustain a long-term stable stream type. The reference site would fall within the range of natural variability for geomorphic type and bedload transport.

**Riffle:** A shallow, rapid section of stream where the water surface is broken into waves by obstructions that are wholly or partly submerged.

**Riparian:** Relating to or living on or near the bank of a watercourse. These zones range in width from narrow bands in arid or mountainous areas to wide bands which occur in low-gradient valleys and more humid regions.

**Roughness Element:** Large obstacles in a channel that deflect flow and affect a local increase in shear stress, causing scour and deposition.

**Salmonids:** a family of ray-finned fish (Salmonidae), including salmon, trout, and chars.

**Scour:** The process of mobilizing and transporting away material from the bed or banks of a channel through the action of flowing water. Scour can result in erosion if the scoured material is not replaced by material transported in from upstream.

**Sediment:** Any mineral or organic matter of any size in a stream channel. Sizes:

Name	Size	
	(mm)	(inches)
boulder	>256	>10
cobble	64 - 256	2.5 - 10
gravel	2 - 64	0.08 - 2.5
sand	0.062 - 2	
silt	0.004 - 0.062	
clay	<0.004	

**Sediment Load:** The sum total of sediment available for movement in a stream, whether in suspension in the water column (suspended load) or in contact with the bottom (bedload).

**Sediment Transport:** The rate of sediment movement through a given reach of stream

**Shear Strength:** The characteristic of soil that resists internal deformation and slippage. Shear strength is a function of soil cohesion, root structure, water content, rock content, and layering.

**Shear Stress:** Results from the tangential pull of flowing water on the streambed and banks. The energy expended on the wetted boundary of the stream increases proportionally with the energy slope and water depth.

**Sinuosity:** The ratio of stream channel length (measured in the thalweg) to the down-valley distance, or is also the ratio of the valley slope to the channel slope. When measured accurately from aerial photos, channel sinuosity may also be used to estimate channel slope (valley slope/sinuosity).

**Stage:** Elevation of water surface above any chosen reference plane. Also known as water level or gage height.

**Stage-Discharge Relationship:** The functional (mathematical, or graphical) relationship between water discharge and corresponding stage (water-surface elevation). Also called a stage-discharge "rating curve."

**Stationarity:** An assumption imbedded in such hydrologic analysis as flood-frequency analysis that annual floods are independent and identically distributed over time. However, cycles and trends in flood and other climatological records indicate nonstationarity can be the norm.

**Stream:** A natural water course of any scale, from the smallest creek to the largest river.

**Perennial Stream** – one that flows continuously throughout the year.

**Intermittent or Seasonal Stream** – One that flows only at certain times of the year or along a discontinuous sequence of reaches.

**Ephemeral Stream** – One that flows only briefly, as a direct result of precipitation.

**Substrate:** Mineral and organic material that forms the bed of a stream.

**Suspended Load:** That part of the sediment load whose immersed weight is carried by the fluid, suspended above the bed.

**Terrace:** A previous floodplain which has been disconnected from a stream channel because of channel incision.

**Thalweg:** The line connecting the lowest points along a streambed, as a longitudinal profile. The path of maximum depth in a river or stream.

**Toe:** The base of a streambank or terrace slope.

**Transport Velocity:** The velocity of flow required to maintain particles of a specific size and shape in motion along the streambed. Also known as the critical velocity.

**Tributary:** Any channel or inlet that conveys water into a stream.

**Turbulence:** The motion of water where local velocities fluctuate widely in all three dimensions, resulting in abrupt changes in flow directions. It causes surface disturbances and uneven surface levels, and often masks subsurface areas due to the entrainment of air. Virtually all flow in rivers is turbulent flow. Opposite of laminar flow.

**Velocity:** The distance that water travels in a given direction during a given interval of time.

**Wetted Perimeter:** The length of the wetted contact between a stream of flowing water and the stream bottom and banks in a vertical plane at right angles to the direction of flow.

**Width to Depth Ratio:** The bankfull width divided by the average bankfull depth.